

This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://Appliance Factory Parts).



# PANASONIC NI-S200TS Owner's Manual


[Shop genuine replacement parts for PANASONIC  
NI-S200TS](#)



[Find Your PANASONIC Small Appliance Parts - Select From 148 Models](#)

----- Manual continues below -----

# Panasonic®



NI-S650TR

CONFORMS TO UL STD. 1005  
CERTIFIED TO CSA STD. C22.2 NO.81

## Electric Steam Iron Operating Instructions Manuel d'utilisation Fer à vapeur électrique

Model No./N<sup>os</sup> de modèle NI-S300TR/S650TR/S655TR/S200TS

### English

#### Safety Information

SAFE USE OF THE IRON	2
IMPORTANT SAFETY INSTRUCTIONS	2-3

#### Operation

COMPONENTS IDENTIFICATION	4
INSTRUCTIONS FOR THE PROPER USE OF THE RETRACTABLE POWER CORD	5
HELPFUL IRONING TIPS	5-6
HOW TO FILL WITH WATER	6
HOW TO USE AS A STEAM IRON	6-7
HOW TO USE AS A DRY IRON	7
HOW TO USE THE "SPRAY" FEATURE	7-8
HOW TO USE THE "JET OF STEAM" FEATURE	8
HOW TO USE THE "VERTICAL STEAM" FEATURE	9
SELF-CLEANING	9-10
STAY CLEAN VENTS	10
ELECTRONIC 3-WAY AUTO SHUT-OFF FUNCTION	10

#### Maintenance

HOW TO CARE FOR YOUR IRON	11
---------------------------	----

#### General Information

SPECIFICATIONS	11
FABRIC IRONING CHART	12
LIMITED WARRANTY	13

### Français

#### Renseignements sur la sécurité

Utilisation sans risque du fer à repasser	14
Mesures de sécurité	14-16

#### Fonctionnement

Identification des composants	4
Précautions à prendre lors de l'utilisation de l'enrouleur de cordon	16
Conseils pour le repassage	16-17
Remplissage	17
Utilisation du fer à vapeur	18
Utilisation pour le repassage à sec	19
Utilisation du vaporisateur	19
Utilisation de la fonction « jet de vapeur »	19-20
Vapeur à la verticale	20
Nettoyage automatique	20-21
Événements toujours propres	21
Fonction d'arrêt automatique électronique à 3 voies	21

#### Entretien du fer

Entretien du fer	22
------------------	----

#### Renseignements généraux

Données techniques	22
Tableau de repassage des tissus	23
Certificat de garantie limitée Panasonic	24

### READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THE IRON

Il est recommandé de lire attentivement et de conserver ce manuel avant d'utiliser l'appareil

For assistance, please call : 1-800-211-PANA(7262) (U.S.A / Puerto Rico)  
or contact us at <http://www.panasonic.com/contactinfo>  
or visit us at <http://www.panasonic.com/help>  
Please register via the Internet at: [www.panasonic.com/register](http://www.panasonic.com/register)

For assistance, please call : 905-624-5505 or visit us at <http://www.panasonic.ca> (Canada)  
Pour obtenir de l'aide, composez le: 905-624-5505 ou visitez notre site à [www.panasonic.ca](http://www.panasonic.ca)

i82005-0N61E

## SAFE USE OF THE IRON

### Your safety and the safety of others are very important

We have provided important safety messages in this manual and on your appliance.

Always read and obey all safety messages.



This is the safety alert symbol. It is used to alert you to potential hazards that can kill or injure you and others. The safety messages will follow the safety alert symbol and either the word "WARNING" or "CAUTION".

These words mean:



**You can be killed or seriously injured if you don't follow these instructions.**



**You can be exposed to a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.**

The safety messages will tell you what the potential hazard is, how to reduce the chance of injury, and what can happen if the instructions are not followed.

### Thank you for purchasing a Panasonic Iron

Your iron is an appliance to be used only for ironing fabrics on an ironing board.

## IMPORTANT SAFETY INSTRUCTIONS



**To reduce the risk of burns, electric shock, fire, or injury to persons:**

When using your iron, basic safety precautions should always be followed, including the following:

### READ ALL INSTRUCTIONS BEFORE USING THE IRON

1. Use the iron only for its intended purpose, for ironing fabrics on ironing board. To protect against burns or injury to persons, do not iron or steam fabrics while being worn on the body.
2. To protect against the risk of electric shock, do not immerse the iron or cord in water or other liquids.
3. The iron should always be turned to "OFF" before plugging or unplugging from outlet. Never yank Cord to disconnect from outlet; instead, grasp Plug and pull to disconnect.
4. Do not allow Cord to touch hot surfaces. Allow the iron to cool completely before storing. Retract Cord into Cord Reel Unit when storing.
5. The Power Cord and Plug may present a risk of personal injury when the Cord is allowed to retract freely. Always hold the Plug and Cord with one hand while pressing the Cord Wind Button with the other hand, and retract the Cord slowly to

reduce the risk of the Cord "WHIPPING", which has the potential risk of causing injury to the face, eyes, etc.. (NI-S300TR/S650TR/S655TR only)

Never allow children to play with the iron or the retractable Power Cord.

6. Always disconnect iron from electrical outlet when filling or emptying water and when not in use.
7. To avoid the risk of electric shock, do not operate iron with a damaged Cord or if the iron has been dropped or damaged. Do not disassemble the iron. Incorrect reassembly can cause a risk of electric shock when the iron is used. For repair, take it to a qualified serviceperson.
8. Close supervision is necessary for this appliance when used by or near children. Do not leave iron unattended while connected or on an ironing board.
9. Burns can occur from touching hot metal parts, hot water, or steam. Use caution when turning the steam iron upside down. Hot water may leak from the iron.
10. To protect against burns or injury to persons, do not direct steam toward the body when ironing or self-cleaning.
11. The iron must be used and rested on a stable surface. When placing the iron on its Heel Rest, ensure that the surface on which the Heel Rest is placed is stable.
12. Do not use the appliance when the Cord is entangled. The supply Cord might be damaged as a result.

## SPECIAL INSTRUCTIONS



### WARNING

To reduce the risk of electric shock or fire:

1. To avoid a circuit overload, do not operate another high wattage appliance on the same circuit.
2. If an extension cord is absolutely necessary, use a cord rated a minimum of 10 amperes. Cords rated for less amperage may overheat and should not be used. Care should be taken to arrange the cord so that it cannot be accidentally pulled or tripped over.



### CAUTION

To reduce the risk of personal injury and damage to your iron:

1. Never use steam iron cleaning products in the iron, as they may damage working parts of the iron.
2. Do not use water additives or substitute water such as linen or scented water in the steam iron. They can stain fabrics.
3. If the Steam/Dry Selector is not in the Dry position after using, remaining water will move into the Soleplate and can result in burns the next time the iron is used.
4. Don't use the Steam or Jet of Steam, while AC Cord is unplugged, water will remain inside the Soleplate which will cause staining.  
Do not use Steam or Jet of Steam while Temperature Selector Dial is set to "OFF".

# SAVE THESE INSTRUCTIONS


For proper use of your iron, read remaining safety cautions and operation instructions.

## COMPONENTS IDENTIFICATION IDENTIFICATION DES COMPOSANTS

### NI-S300TR/S650TR/S655TR

Spray Mist Button  
Touche de vaporisation

Steam/Dry Selector  
Commutateur d'intensité  
de vapeur/à sec



Dry	Low Steam	High Steam
À sec	Vapeur faible	Vapeur forte

Water Fill Opening  
Couvercle de  
remplissage

Spray Nozzle  
Orifice de  
vaporisation

Soleplate  
Semelle

Water Level Indication " MAX " Line  
Indicateur de niveau maximal d'eau

Water Reservoir (Water Window)  
Réservoir d'eau

Jet of Steam Button (Vertical Steam Button)  
(NI-S650TR/S655TR/S300TR only)

Touche de jet de vapeur (Jet à la verticale)  
(NI-S650TR/S655TR/S300TR seulement)

Handle (with rubber, NI-S650TR/S655TR only)  
Poignée (avec caoutchouc, NI-S650TR/S655TR seulement)

Cord Wind Button (NI-S650TR/S655TR/S300TR only)  
Touche d'enrouleur de cordon  
(NI-S650TR/S655TR/S300TR seulement)

**WARNING Instruction**  
Please read WARNING before use.  
**Étiquette d'avertissement**  
Veuillez lire les avertissements  
avant d'utiliser le fer.

AC Power Cord  
Cordon d'alimentation

Cord Reel Unit  
Enrouleur de cordon

Heel Rest  
Talon

Plug  
Fiche

Thermostat Operating Indicator Light  
Voyant de fonctionnement du thermostat


Temperature Selector Dial  
Cadran du sélecteur de la température

Temperature Select Indicator  
Indicateur de sélection de température

### NI-S200TS

Spray Mist Button  
Touche de vaporisation

Heel Rest  
Talon



**INSTRUCTIONS FOR THE PROPER USE OF THE RETRACTABLE  
POWER CORD (NI-S300TR/S650TR/S655TR Only) Please see WARNING on pages 2-3**

- (1) Unwind the Power Cord far enough to plug into a wall outlet, allowing enough length to operate the iron.
- (2) If the Power Cord seems hard to unwind due to improper winding, pull firmly until it is released.
- (3) When retracting the Power Cord, always hold the Plug with one hand while pressing the Cord Wind Button with the other hand, and retract the Cord slowly.
- (4) If the Cord does not retract completely, pull it out slightly and wind it again while guiding it into the Reel.

**READ THIS INSTRUCTION BOOK THOROUGHLY BEFORE USING YOUR  
Panasonic IRON TO BECOME FAMILIAR WITH THE IRON FEATURES**

**HELPFUL IRONING TIPS**

The Temperature Selector Dial of the Panasonic iron has words, dots and steam symbols.

- a) The numbers are indicated as 1 (lowest setting) through 5 (highest setting). For general information on the number settings, refer to the Heel Rest. For more detailed information, refer to page 12 of this instruction book.
- b) The dots are symbols for 3 temperature ranges:


- Low Temperature
- Medium Temperature
- High Temperature

Some fabrics are labeled with these dots as a guide for selecting the proper ironing temperature setting.

- c) The steam symbols are used for selecting steam settings. For further details, refer to pages 6-10



As a guide to the Fabric Care Symbols, the following symbols are printed for your information.



A symbol crossed out indicates that the article of clothing must not be subjected to the particular treatment.

EXAMPLE:(DO NOT BLEACH) ~~✱~~

Before ironing, sort the garments according to the different heat settings required.

Iron fabrics that require a lower temperature first.

Do not touch plastic buttons with a hot iron because they may melt.

Be careful around zippers and similar items to prevent the Soleplate from being scratched.

## HOW TO FILL WITH WATER

# ! WARNING


Be sure the iron is unplugged from the electrical outlet before filling with water.

1. Move the Steam/Dry Selector to the Dry position to avoid water leakage.

Open the Water Fill Opening. Hold the iron as shown and fill the iron with water up to "MAX" line (about 6.3 ounces/180ml).

Use a cup for filling (see Note).

2. Do not overfill. Check for the correct water fill level with the iron in the vertical position.
3. Close the Water Fill Opening, or water will splash from Water Reservoir when ironing.



### Note:

Most tap water can be used in this iron. If water is very hard, distilled or demineralized water should be used. Do not use water processed through home water softening systems because this water contains minerals that may be harmful to the iron. Do not use water additives or substitute water such as linen or scented water in the steam iron. They can stain fabrics or damage the iron.


## HOW TO USE AS A STEAM IRON

1. Fill the iron as described in "HOW TO FILL WITH WATER".
2. Position the iron vertically and be sure the Temperature Selector Dial is set to "OFF".
3. Plug the AC Cord into the electrical outlet.
4. Set the Temperature Selector Dial to the "☁" or "☁☁" (steam) zone.
  - "☁" zone: Low Steam, for thin or delicate fabrics requiring a small amount of steam.
  - "☁☁" zone: High Steam, for fabrics requiring a lot of steam (i. e. thick materials, items with stubborn wrinkles).
5. Preheat the iron until the Indicator Light goes out, usually about 1-2 minutes.

This Light will go on and off during ironing to indicate that the temperature chosen by the Temperature Selector Dial is being maintained.
6. Hold the iron horizontally and move the Steam/Dry Selector into the steam position.

Steam/Dry Selector is regulated as follows.

**NOTE: 3 Position Steam/Dry Selector .**




(Right : for High Steam, Center: for Low Steam )

Temperature Zone	Steam/Dry Selector Position

Now steam ironing can begin

7. Whenever the iron is positioned vertically, the steaming action will stop.



## **CAUTION**

Do not use the Steam/Dry Selector unless the iron is sufficiently hot to produce steam, otherwise water will leak out through the vents instead.

### **HOW TO USE AS A DRY IRON**

1. Move the Steam/Dry Selector to the Dry position.
2. Position the iron vertically, set the Temperature Selector Dial to " OFF " .
3. Plug in the iron.
4. Set the Temperature Selector Dial to the desired position.  
(Refer to the **FABRIC IRONING CHART** in this manual on page 12 )
5. Preheat the iron until the Indicator Light goes out, usually about 1-2 minutes.


### **HOW TO USE THE "SPRAY" FEATURE**


**Note:** Before using the spray feature, check the fabric label for ironing instructions because some fabrics may be spotted or stained with moisture.

The spray feature is particularly helpful for removing stubborn wrinkles and where extra dampening is needed.


**The spray may be used with steam or dry ironing.**





1. Simply pump the Spray Mist Button  when spray is desired.  
If the spray doesn't work immediately, keep pumping until it does.
2. To get a finer spray, pump the Button vigorously.  
To get a more powerful spray, pump the Button more slowly. For best results, use a quick, full stroke.



## HOW TO USE THE "JET OF STEAM" FEATURE (NI-S300TR/S650TR/S655TR Only)

The "Jet of Steam" feature provides extra steam which goes deep into the garment and is helpful for removing stubborn wrinkles. The "Jet of Steam" feature operates properly only in the "  " indication area of the Temperature Selector Dial when steam or dry ironing ( If used at lower setting, water spotting will occur because the iron is not hot enough to change water to steam ). If you have not used the " Jet of Steam " feature for a long time, it is necessary to clean the inside of the iron before using this feature on any clothes to be ironed. Simply test the " Jet of Steam " feature several times away from the ironing board and clothes to be ironed. This will prevent brown spotting or water spotting on the clothes.

1. Fill the iron as described in "HOW TO FILL WITH WATER ".
2. Position the iron vertically and be sure the Temperature Selector Dial is set to "OFF " .  
Plug the AC Power Cord into the electrical outlet.
3. Set the Temperature Selector Dial to the "  " indication area.
4. Preheat the iron until the Indicator Light goes out, usually about 1-2 minutes.
5. Simply pump the " Jet of Steam Button " when steam is desired. Pump the " Jet of Steam Button " several times at the beginning of each ironing session.
6. Allow at least 2-5 seconds between uses of the "Jet of Steam Button " to prevent water spotting. Use a press cloth if necessary.




## CAUTION

Do not use the "Jet of Steam Button " until the Thermostat Operating Indicator Light turns off after setting the Temperature Setting Dial to " MAX ". Hot water may leak from the Soleplate and burns may result, and it may cause corrosion.

## HOW TO USE THE 'VERTICAL STEAM' FEATURE (NI-S650TR/S655TR Only)

To get better results when using vertical steam, hang the garment on a clothes hanger. Curtains and drapes may also be steamed once they're hung. Hold the iron away from your body, close to but not touching the fabric. Pull the fabric tight with your free hand and pump the Vertical Steam Button (Jet of Steam Button) at 2-5 seconds intervals as you pass the iron over the wrinkled fabric.




## **! WARNING**

- Never iron clothes on the body or point your iron at anyone when steaming.
- Keep hands and body away from steam areas while using vertical steam feature.

## SELF-CLEANING (NI-S300TR/S650TR/S655TR Only)

With the self-cleaning feature you can flush out mineral residue from the steam generating chamber and the steam vents, refreshing your iron each time for a longer steaming life. It is very important to operate the self-cleaning feature after each steam ironing to prevent mineral accumulations from hardening.

1. Check water level. Water level should be at 1/2 full mark.  
When water level is less than half full, fill with water according to the instructions in "HOW TO FILL WITH WATER".
2. Preheat at " MAX " setting (for about 1-2 minutes).  
Make sure that the Steam/Dry Selector is in the Dry position.
3. Set the Dial to " OFF " and remove the AC plug.
4. Hold the iron horizontally over the sink.
5. Pump the "Jet of Steam Button " quickly (at least 3 times per second) about 20-30 times.
6. While self-cleaning, tilt the iron up and down slowly to help clean the entire inside and let the water drip out of the soleplate vents.
7. Check that all water and steam have completely stopped coming out of the soleplate vents. After self-cleaning is finished, empty any remaining water from the Water Reservoir by turning the iron upside down .
8. Iron on a towel to remove any drops of water remaining on the bottom of iron.
9. Allow the iron to cool and store on its Heel Rest. Never store an iron on its Soleplate or with water in it.
10. If water still remains inside the Soleplate after self-cleaning operation, dry out the iron by setting the iron on the " MAX " setting, to vaporize the remaining water. After the iron is dry, follow the instructions under " AFTER EACH USE " .



## **STAY CLEAN VENTS (NI-S650TR/S655TR Only)**

The built-in Anti Calcium System (Calc Cut) in the Water Reservoir continuously reduces scale buildup in the vaporizing chamber of the iron.

This system makes it possible to use the steam function for a long period of time and prevents steam vents from clogging.

## **ELECTRONIC 3-WAY AUTO SHUT - OFF FUNCTION (NI-S300TR/S650TR/S655TR Only)**

# **WARNING**

The Auto Shut-Off feature (or setting the thermostat to OFF) is not intended to take the place of unplugging the cord. Disconnect the electric iron when not in use !

Even though the iron is unplugged, the soleplate is still hot. Be sure to rest the iron on its heel, away from fabric.

1. When the iron is not moved with its Soleplate facing down or on its side for approx. 1 minute, the iron will automatically shut off power to the heater.
2. When the iron is not moved on its Heel Rest for approx. 10 minutes, the iron will automatically shut off power to the heater.
3. To resume ironing and turn the iron back on, simply move the iron in any manner. If the iron has been left in the auto shut off mode for more than 10 minutes. Allow the iron to reheat until the Indicator Light goes out.

**NOTE:** The Auto Shut-Off System works regardless of position of the Temperature Selector Dial.

## HOW TO CARE FOR YOUR IRON

### AFTER EACH USE

1. Set the Temperature Selector Dial to " OFF".
2. Turn the iron off and unplug.
3. Empty the iron immediately after using.

Do not store the iron with water in it.

4. Move the Steam/Dry Selector into the Dry position.

If the Steam/Dry Selector is not in the Dry position after using, remaining water will move into the Soleplate and damage the Soleplate and may result in burns during the next initial use of the iron.

5. Wait until the iron has cooled before storing it, and always set it on the Heel Rest to protect the Soleplate from scratches, corrosion or stains.
6. After letting iron cool completely, push the Cord Wind Button to wind the cord. Store the iron vertically in a safe place after winding cord completely. ( NI-S300TR/S650TR/S655TR Only )

Please see **IMPORTANT SAFETY INSTRUCTIONS** on page 2 items 4 and 5.

### OUTSIDE SURFACE OF IRON

After unplugging and cooling the iron, simply wipe off with a damp cloth and if necessary, use a mild detergent.




**NEVER USE ANY HARSH CLEANERS.**

### SOLEPLATE

Starch and other residue may be easily removed from the Soleplate with a damp cloth. To avoid scratching the finish never use a metallic pad to clean the Soleplate, and never place the iron on a rough surface.

If synthetics are ironed at too high a temperature, not only is the fabric usually ruined, but the iron Soleplate is often covered with the melted remains of the synthetic fabric.

The best way to remove synthetic residue from the Soleplate is to heat the iron and to iron over an old cotton rag.



## CAUTION

Never use steam iron cleaners in the iron, since they may damage the working parts of the iron.

## SPECIFICATIONS

Model	NI-S300TR	NI-S650TR	NI-S655TR	NI-S200TS
Power Source	120 V ac 60 Hz			120 V ac 60 Hz
Power Consumption	10 A, 1200 W			10 A, 1200 W
Net Weight	2.6 lb (1.2 kg)			2,4 lb (1,1 kg)

## FABRIC IRONING CHART

- NOTES: 1. Check fabric for specific ironing instructions, Always follow manufacturer's instructions.
2. Iron blended fabrics at setting for lower-temperature fiber or for the highest-percentage fiber.
3. Use caution, some synthetics may melt at high temperature.

Temperature Selector Setting	Fabric	Ironing Recommendations
<b>1</b> (Acrylic)	<b>ACRYLIC</b> * ACRILAN * CRESLAN * ORLON <b>ACETATE</b> <b>METALLICS</b> <b>SUEDE</b>	Dry iron on reverse side, or use a press cloth on top of fabric. Don't sprinkle water directly on fabric to avoid spots. To iron suede, cover with brown paper and use it as a press cloth.
<b>2</b> (Silk)	<b>NYLON</b> * ANTORON * CAPROLAN <b>SILK</b>	Dry iron on reverse side.
<b>3</b> (Wool)	<b>WOOL</b> <b>VELVET</b>	Steam ironing is suggested. Never iron until completely dry, but leave it with a little moisture. To iron velvet, use steam but do not let the iron touch the fabric. Hold it slightly above the surface.
<b>4</b> (Cotton)	<b>COTTON</b>	Steam ironing is suggested. Sprinkle water on the fabric, depending on its thickness. Iron dark fabric on reverse side to avoid unwanted sheen.
<b>5</b> (Linen)	<b>LINEN</b>	Steam ironing is suggested. Iron dark fabrics on reverse side to avoid unwanted sheen.

\* Trademarks of Fiber Manufacturers.

## LIMITED WARRANTY (Canada)

Panasonic Canada Inc.

5770 Ambler Drive, Mississauga, Ontario L4W 2T3

### PANASONIC PRODUCT – LIMITED WARRANTY

## EXCHANGE PROGRAM

Panasonic Canada Inc. warrants this product to be free from defects in material and workmanship under normal use and for a period as stated below from the date of original purchase agrees to, at its option either (a) repair your product with new or refurbished parts, (b) replace it with a new or a refurbished equivalent value product, or (c) refund your purchase price. The decision to repair, replace or refund will be made by Panasonic Canada Inc.

Electric Iron	One (1) year
---------------	--------------

This warranty is given only to the original purchaser, or the person for whom it was purchased as a gift, of a Panasonic brand product mentioned above sold by an authorized Panasonic dealer in Canada and purchased and used in Canada, which product was not sold "as is", and which product was delivered to you in new condition in the original packaging.

**IN ORDER TO BE ELIGIBLE TO RECEIVE WARRANTY SERVICE HEREUNDER, A PURCHASE RECEIPT OR OTHER PROOF OF DATE OF ORIGINAL PURCHASE, SHOWING AMOUNT PAID AND PLACE OF PURCHASE IS REQUIRED**

#### LIMITATIONS AND EXCLUSIONS

This warranty **ONLY COVERS** failures due to defects in materials or workmanship, and **DOES NOT COVER** normal wear and tear or cosmetic damage. The warranty **ALSO DOES NOT COVER** damages which occurred in shipment, or failures which are caused by products not supplied by Panasonic Canada Inc., or failures which result from accidents, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, improper maintenance, power line surge, lightning damage, modification, introduction of sand, humidity or liquids, commercial use such as hotel, office, restaurant, or other business or rental use of the product, or service by anyone other than a Authorized Servicer, or damage that is attributable to acts of God.

THIS EXPRESS, LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL PANASONIC CANADA INC. BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY. (As examples, this warranty excludes damages for lost time, travel to and from the Authorized Servicer, loss of or damage to media or images, data or other memory or recorded content. This list of items is not exhaustive, but for illustration only.)

In certain instances, some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or the exclusion of implied warranties, so the above limitations and exclusions may not be applicable. This warranty gives you specific legal rights and you may have other rights which vary depending on your province or territory.

#### CONTACT INFORMATION

For product information and operation assistance, please contact:

Our Customer Care Centre: Telephone #: 1-800-561-5505  
Fax #: (905) 238-2360  
Email link: "Support → contact us → email" on [www.panasonic.ca](http://www.panasonic.ca)

For defective product exchange within the warranty period, please contact the original dealer or our Customer Care Centre.