


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://www.appliancefactoryparts.com).



REVOACE GBC1708WDC Owner's Manual

[Shop genuine replacement parts for REVOACE
GBC1708WDC](#)




[Find Your REVOACE Grill Parts - Select From 56 Models](#)

----- Manual continues below -----

OWNER'S MANUAL

Outdoor LP Gas Barbecue Cooker

Model No. GBC1708WDC



FOR YOUR SAFETY

1. Improper installation, alteration, or use may cause injury or death.
2. Read the instructions and maintenance information before installing the equipment.
3. Failure to follow instructions may result in fire, explosion, or death.
4. This instruction manual contains important information for the safe assembly and use of the appliance.
5. Read and follow the instructions for the appliance.
6. Follow all warnings and instructions when using the appliance.
7. Keep this manual for future reference.



FOR YOUR SAFETY

1. Do NOT store flammable liquids or gases in this or any other appliance.
2. An LP cylinder should NOT be stored in this or any other appliance.



Never operate the

Table of Contents

Important Safeguards	Page 2
Limited Warranty	3
Expanded View & Hardware	4
Assembly Instructions	5
Installing LP Gas Tank	10
Operating Instructions	10
Cleaning and Care	11
Troubleshooting	13



Important Safeguards Warning

- ▲ This grill is for outdoor use only, and should not be used in a building, garage or any other enclosed area.
- ▲ Do NOT operate, light or use this appliance within ten feet (3.05 m) of walls, structures or buildings.
- ▲ For residential use only. This grill is NOT for commercial use.
- ▲ This grill is not intended for and should never be used as a heater. TOXIC fumes can accumulate and cause asphyxiation.
- ▲ This grill is safety certified for use in the United States and/or Canada only. Do NOT modify for use in any other location. Modification is a safety hazard and will void your warranty.
- ▲ This grill is for use with liquid propane (LP) gas only. The conversion to or attempted use of natural gas in this LP gas grill is a safety hazard and will void your warranty.
- ▲ LP gas characteristics:
 - a. LP gas is flammable and hazardous if handled improperly. Become aware of the characteristics before using any LP gas.
 - b. LP gas is explosive under pressure, heavier than air, and settles/pools in low areas.
 - c. LP gas in its natural state has no odor. For your safety, an odorant is added that smells like rotten cabbage.
 - d. Contact with LP gas can cause freeze burns to skin.
- ▲ Apartment dwellers: Check with management to learn the requirements and fire codes for using a LP gas grill in your apartment. Do NOT use outside on the ground floor with a ten foot (3.05 m) clearance from any structure. Do NOT use on or under balconies.
- ▲ LP gas cylinder needed to operate. Only cylinders marked "propane" may be used.
- ▲ The LP gas cylinder must be constructed and marked in accordance with the *Specifications for LP-gas Cylinders of the Department of Transportation (D.O.T.)* or the National Standard of Canada, *CAN/CSA-B339, Cylinders, Spheres and Tubes for the Transportation and Commission*.
- ▲ LP gas cylinder must be arranged for vapor withdrawal.
- ▲ The LP gas cylinder must have a listed overfilling prevention device (OPD).
- ▲ Only use LP gas cylinders equipped with a cylinder connection device compatible with the connection for outdoor cooking.
- ▲ The LP gas cylinder must have a cylinder collar to protect the cylinder valve.
- ▲ Never use an LP gas cylinder with a damaged body, valve, collar or footing.
- ▲ Dented or rusted LP gas cylinders may be hazardous and should be checked by your LP gas supplier prior to use.
- ▲ The LP gas cylinder should not be dropped or handled roughly.
- ▲ LP gas cylinders must be stored outdoors out of the reach of children and must not be stored in a building, garage or other enclosed area. A cylinder must never be stored where temperatures can reach over 125°F.
- ▲ Do NOT insert any tool or foreign object into the valve outlet or safety relief valve. You may damage the valve and cause a gas leak which may result in an explosion, fire, severe personal injury or death.
- ▲ Do NOT block holes in sides or back of grill.
- ▲ Never keep an LP gas cylinder in a hot car or trunk. Heat will cause the gas pressure to increase, which may open the valve and cause a gas leak.
- ▲ Place dust cap on cylinder valve outlet whenever the cylinder is not in use. Only install the type of dust cap on the cylinder valve outlet with the cylinder valve. Other types of caps or plugs may result in leakage of propane.
- ▲ If grill is not in use, the gas must be turned off at the supply cylinder and disconnected.
- ▲ Do NOT store a spare LP gas cylinder under or near this appliance.
- ▲ Never fill the cylinder beyond 80 percent full. A fire causing serious injury or damage to property may occur if the above instructions are not followed.
- ▲ Never attempt to attach this grill to the self-contained LP gas system of a camper trailer, motor home or house.
- ▲ Never use charcoal, lighter fluid, lava rocks, gasoline, kerosene or alcohol with this product.
- ▲ Your grill has been checked at all factory connections for leaks. Re-check all connections as described in the "Operation and Maintenance" section of the shipping can loosen connections.
- ▲ Check for leaks even if your unit was assembled for you by someone else.




Important Safeguards Warning

- ▲ This grill should be thoroughly cleaned and inspected on a regular basis.
- ▲ Clean and inspect the hose before each use of the appliance. If there is evidence of abrasion, wear, cuts or leaks, operation.
- ▲ Use only the regulator and hose assembly provided. Use only the replacement regulator and hose assembly specified in the manual.
- ▲ Use only RevoAce Inc. Limited factory-authorized parts. The use of any part that is not factory-authorized can be void of warranty.
- ▲ Do NOT operate this appliance without reading “Operating Instructions” in this manual.
- ▲ Do NOT touch metal parts of grill until they have completely cooled to avoid burns, unless you are wearing protective mittens, etc.).
- ▲ Do NOT install or use in or on boats or recreational vehicles.
- ▲ When cooking, fire extinguishing materials should be readily accessible. In the event of an oil/grease fire, do NOT use water. Use type BC dry chemical fire extinguisher or smother with dirt, sand or baking soda.
- ▲ Do NOT use grill in high winds.
- ▲ Never lean over the grill when lighting.
- ▲ Do NOT leave a lit grill unattended. Keep children and pets away from grill at all times.
- ▲ Do NOT leave grill unattended while preheating or burning off food residue on high. If grill has not been cleaned, a fire may damage the product.
- ▲ Do NOT place empty cooking vessels on the appliance while in operation.
- ▲ Use caution when placing anything on the grill while the appliance is in operation.
- ▲ Do NOT attempt to move grill when in use. Allow the grill to cool before moving or storing.
- ▲ LP gas cylinder must be properly disconnected and removed prior to moving this grill.
- ▲ Storage of grill indoors is permissible only if the cylinder is disconnected, removed from the grill and properly stored.
- ▲ Always open grill lid carefully and slowly as heat and steam trapped within grill can cause severe burns.
- ▲ Do NOT attempt to disconnect the gas regulator from the cylinder or any gas fitting while the grill is in use.
- ▲ Always place your grill on a hard, non-combustible, level surface. An asphalt or blacktop surface may not be acceptable.
- ▲ Move gas hoses as far away as possible from hot surfaces and dripping hot grease.
- ▲ Keep all electrical cords away from a hot grill.
- ▲ After a period of storage and/or nonuse, check for leaks, burner obstructions and inspect for any abrasion, wear or damage.
- ▲ Failure to open lid while igniting the grill’s burners, or not waiting 5 minutes to allow the gas to clear if the grill does not light, may cause an explosive flame-up.
- ▲ Never operate grill without its heat plates installed.
- ▲ Always use a meat thermometer to ensure food is cooked to a safe temperature.
- ▲ Use protective gloves when assembling this product.
- ▲ Do NOT force parts together as this can result in personal injury or damage to the product.
- ▲ Never cover entire cooking area with aluminum foil.
- ▲ Deaths, serious injury or damage to property may occur if the above is not followed exactly.

Limited Warranty

RevoAce Inc. Limited (“RA”) warrants to the original retail purchaser of this product, and to no other person, that if the product is properly installed, maintained, and operated in accordance with the printed instructions accompanying it, then for a period of five (5) years or (1) year for all remaining parts from the date of purchase, all parts in such product shall be free from defects in material and workmanship. This warranty requires reasonable proof of your date of purchase. Therefore, you should retain your sales slip or invoice. This Limited Warranty does not cover the repair or replacement of parts, which prove defective under normal use and service and which RA shall determine.

Expanded View



Parts List

1	Handle	G1203-010	13	Igniter*	B0217-H08	25	Cart Fram Wire B (2)
2	Temperature Gauge	B0104-JRE	14	Right Side Shelf	G1308-050	26	Cart Fram Wire A
3	Lid*	G1308-010	15	Left Side Shelf	G1203-010	27	LP Gas Ta
4	Cooking Grid	G0900-030	16	Grease Cup	B0219-A01	28	Cart Fram
5	Heat Plate	G1308-040	17	QCC Clip*	G1103-020	29	Left Low

Assembly Instructions

1

DO NOT RETURN TO PLACE OF PURCHASE.

For assistance, call **1-800-694-0013** toll-free. Please have your owner's manual and model number available for reference.

Note: The model number is printed on a label which can be found on the inside door, back or side of the cart assembly.

Assembly Tips:

1. Select an area where you will assemble this product. To protect components, choose a smooth surface that's free of cracks or openings.
2. Spread out all parts.
3. Tighten all hardware connections by hand first. Then, before completing each step, go back and fully tighten all hardware. Be careful not to over-tighten. That could damage surfaces or strip threads.
4. For best results, complete each step in the order presented.



To complete assembly you will need:

- (1) Leak detection solution (instructions on how to make the solution are included in the "Operating Instructions" section of this manual).
- (1) Precision-filled LP gas grill tank with Acme Type 1 external threaded valve connection (standard grill size) (not included).

Typical assembly is approximately one hour.


2

Assemble Left and Right




3

Attach Front Panel





4


Attach Cart Frame Support




5 Attach Axle and Wheels




6 Attach LP Gas Tank Retainer



7 Attach Cart Frame Support Wire A





8 Attach Handle, Handle Heat and Heat Plate Supports



9

Attach Grill Body Assembly




D  x 4


I  x 4

K  x 4

10

Attach LP Gas Tank Heat Hook




C  x 1

11

Loosen Screws


Note: Leave 5 mm of bolt threads exposed.



12



Attach Left Side Shelf

Note: Leave 5 mm of bolt threads exposed.




13 Attach Right Side Shelf


Note: Leave 5 mm of bolt threads exposed.




14 Tighten Screws



15 Attach Warming Rack and Control Knobs




16 Insert Heat Plate and Cooking




17

Insert Grease Cup Support and Grease Cup




Installing LP Gas Tank

To operate, you will need one precision-filled standard grill LP gas tank with external valve threads.




Inserting and Secure LP Gas Tank

1. Place precision-filled LP gas tank upright into the notches in the right cart frame so the tank valve is facing the gas line connection.
2. Secure tank by sliding the tank retainer wire over shoulder of LP gas tank.




Connecting LP Gas Tank

1. Before connecting, be sure there is no debris caught in the head of the burner or in the regulator valve.
2. Connect regulator/hose assembly to tank by turning clockwise.



Disconnecting LP Gas Tank

1. Before disconnecting, make sure the LP gas tank is turned off.
 2. Disconnect regulator/hose assembly from LP gas tank until it is loose.
- ⚠ **CAUTION: LP gas tank must be properly disconnected and removed prior to moving this grill.**
3. Place the protective cap cover on the LP tank and store in a well-ventilated area out of direct sunlight.



Operating Instructions

Checking for Leaks

Burner Connections

1. Make sure the regulator hose and valve connections are securely fastened to the burner and the tank.
2. Visually check the connection between the burner/venturi tube and orifice.
3. Make sure the burner/venturi tube fits over the orifice.


⚠ **WARNING: Failure to inspect this connection or follow these instructions could cause a fire or an explosion which can cause death, serious bodily injury or damage to property.**

4. Please refer to diagram for proper installation (Figure 1).
5. If the burner/venturi tube does not rest flush to the orifice, as shown, please contact 1.800.694.0013 for assistance.

Tank/Gas Line Connection

1. Make 2-3 oz. of leak detection solution by mixing one part liquid dishwashing soap with three parts

Figure 1: Main Burners



Operating Instructions (continued)

1. Open lid.
2. Check for obstructions of airflow to the burners. Spiders, insects and webs can clog the burner/venturi tube. A clogged burner tube can lead to a fire.
3. All control knobs must be in the "OFF" position (Figure 2).
4. Connect LP gas tank per "Installing LP Gas Tank" section.
5. Turn LP gas tank valve to "OPEN."
6. Push and turn any control knob to HIGH.
7. Press the ⚡ (igniter) button quickly 3 to 4 times to light burner.
8. If ignition does not occur in 5 seconds, turn burner control knob "OFF," wait 5 minutes, and repeat lighting procedure.
9. If igniter does not light burner, use a lit match secured with the lighting rod (included with grill) to light burners. Access the burners through the cooking grid and heat plates. Position lit match near side of burner (Figure 4a and 4b).

Important: Always use the lighting rod (included) when lighting burners with a match.

10. After lighting, observe the burner flame. Make sure all burner ports are lit and flame height matches illustration (Figure 5).

Note: Each burner lights independently - repeat steps 5-9 for the other burners.

Turning Off

1. Turn LP gas tank valve to "CLOSED."
2. Turn all control knobs clockwise to the "OFF" position.
Note: A "poof" sound is normal as the last of the LP gas is burned.
3. Disconnect LP gas tank per "Disconnecting LP Gas Tank" section.

Controlling Flare-ups

1. **If a grease fire develops, turn control knobs to the "OFF" position and LP gas tank valve "CLOSED." Do NOT use water on a grease fire. This can cause the grease to splatter and could result in serious burns, bodily harm or other damage.**
2. **Do NOT leave grill unattended while preheating or burning off food residue on HIGH. If grill has not been cleaned, a grease fire can occur.**

Flare-ups are a part of cooking meats on a grill and add to the unique flavor of grilling.

Excessive flare-ups can over-cook your food and be dangerous.



Important: Excessive flare-ups result from the build-up of grease in the bottom of your grill.

If a grease fire occurs, close the lid **AND** turn the control knob(s) to "OFF" until the grease burns out. Be careful when opening the lid as sudden flare-ups may occur.

If excessive flare-ups occur, **do NOT** pour water onto the flames.

Minimize Flare-ups:

1. Trim excess fat from meats prior to cooking.
2. Cook high fat content meats on LOW setting or indirectly.
3. Ensure that your grill is on a hard, level, non-combustible surface and the grease is allowed to drain into grease receptacle.



Cleaning and Care

	CAUTION	
<ol style="list-style-type: none">1. All cleaning and maintenance should be done when grill is cool and with the fuel supply disconnected.2. Do NOT clean any grill part in a self-cleaning oven. The extreme heat will damage the finish.3. Do NOT enlarge valve orifices or burner		

	NOTICE	
<ol style="list-style-type: none">1. This grill should be thoroughly cleaned and inspected on a regular basis.2. Abrasive cleaners will damage this product.3. Never use oven cleaner to clean any part of grill.		

Cleaning and Care (continued)

6. Lift burners up and away from gas valve orifice.
7. Disconnect wire from spark electrode.
8. Clean venturi of each burner with small bottle brush or compressed air.
9. Remove all food residue and dirt from burner surface.
10. Clean any clogged ports with a stiff wire (such as an opened paper clip).
11. Inspect burners for any damage (cracks or holes). If damage is found, replace with new burner(s) from manufacturer.
12. Re-install burner(s). Checking to insure that gas valve orifice is correctly positioned inside each burner/venturi tube. Also, check position of spark electrode.
13. Replace heat plate(s) and cooking grid(s).
14. Connect LP gas tank per "Installing LP Gas Tank" section.
15. Perform leak test per "Checking for Leaks" section.

Before Storing

1. Turn LP gas tank valve to "CLOSED."
2. Turn all control knobs clockwise to the "OFF" position.
Note: A "poof" sound is normal as the last of the gas is burned.
3. Disconnect LP gas tank per "Disconnecting LP Gas Tank" section.
4. Clean all surfaces.
5. Lightly coat the burner(s) and cooking grid(s) with cooking oil to prevent excess rusting.
6. If storing the grill indoors, disconnect the LP tank per "Disconnecting LP Gas Tank" section.
7. Place the protective cap cover on the LP tank and store the tank outdoors in a well-ventilated area out of direct sunlight.
8. If storing the grill indoors, cover the grill and store in a cool dry place.
9. If storing the grill outdoors, cover the grill with a grill cover for protection from the weather.

Troubleshooting

Problem	Possible Cause	Possible Solution
Burner will not light using igniter	• LP gas tank valve is closed	• Make sure regulator is securely attached to the "LP Gas Tank," then turn LP gas tank valve to "ON"
	• LP gas tank is low or empty	• Exchange, refill or replace LP gas tank
	• LP gas	• Turn LP gas tank valve to "CLOSED" • Wait 5 minutes for gas to clear • Follow "Checking for Leaks" section
	• Wires or electrode covered with cooking residue	• Clean wire and/or electrode with a dry cloth
	• Electrode and burners are wet	• Wipe dry with cloth
	• Electrode cracked/broken - sparks at crack	• Replacement part(s) may be needed. Call Customer Care at 1.800.694.0013
	• Wire loose or disconnected	• Reconnect wire or replacement part(s) may be needed. Call Customer Care at 1.800.694.0013
	• Wire is shorting (sparking) between ignitor and electrode	• Replacement part(s) may be needed. Call Customer Care at 1.800.694.0013
Burner will not light with match	• Bad igniter	• Replacement part(s) may be needed. Call Customer Care at 1.800.694.0013
	• No gas flow	• Check if LP gas tank is empty A. If empty, exchange, refill or replace LP gas tank B. If LP gas tank is not empty, reengage burner and valve to "flame height" (see below)
	• LP gas tank is low or empty	• Exchange, refill or replace LP gas tank
	• LP gas	• Turn LP gas tank valve to "CLOSED" • Wait 5 minutes for gas to clear • Follow "Checking for Leaks" section
	• Coupling nut and regulator not fully connected	• Turn the coupling nut about one full turn until it reaches a solid stop. Tighten by hand only
	• Obstruction of gas flow	• Clear burner/venturi tube • Check for bent or kinked hose
	• Disengagement of burner to valve	• Reengage burner and valve
	• Spider webs or insect nest in venturi	• Clean burner/venturi tube
Sudden drop in gas flow or reduced flame height	• Burner ports clogged or blocked	• Clean burner ports
	• Out of gas	• Exchange, refill or replace LP gas tank
	• Overfilling prevention device may have been activated	1. Turn control knobs to "OFF" 2. Wait 30 seconds and light grill 3. If flames are still too low, reset overfilling prevention device: a. Turn control knob(s) to "OFF" b. Turn LP gas tank valve to "CLOSED" c. Disconnect regulator d. Turn control knobs to "OFF" e. Wait 1 minute f. Turn control knobs to "ON" g. Reconnect regulator and turn LP gas tank valve to fully open valve h. Light grill per "Lighting" section
Irregular flame pattern, flame does not run the full length of burner	• Burner ports are clogged or blocked	• Clean burner ports
Flame is yellow or orange	• New burner may have residual manufacturing oils	• Burn grill for 15 minutes on high
	• Spider webs or insect nest in venturi	• Clean venturi
	• Food residue, grease, etc. on burners	• Clean burner
	• Poor alignment of valve to burner/venturi tube	• Ensure burner/venturi tube is properly aligned
Flame goes out	• High or gusting winds	• Do not use grill in high winds
	• Low on LP Gas	• Exchange, refill or replace LP gas tank
	• Overfilling prevention device may have been activated	• Refer to "Sudden drop in gas flow" section
Flare-up	• Grease buildup	• Remove and clean all grill parts
	• Excess fat in meat	• Trim fat from meat before grilling
	• Excessive cooking temperature	• Adjust to lower cooking temperature