

HOLMES hm5305 Owner's Manual

Shop genuine replacement parts for HOLMES hm5305



Find Your HOLMES Humidifier Parts - Select From 153 Models

----- Manual continues below ------

TROUBLESHOOTING FREQUENTLY ASKED QUESTIONS

TROUBLE	PROBABLE CAUSE	SOLUTION
Power light not illuminated	Unit not plugged in	Plug in Unit
Refill/Reset light illuminated	Water Tank Empty	Refill Tank
	Unit not reset after refill	Follow manual for Reset Instructions
	Scale buildup on heating element	Remove scale from heating element
Mist output minimal to none	Scale buildup on heating element	Remove scale from heating element
Water Leaks from tank	Tank rubber ring is missing	Remove tank cap and replace or reposition ring
	Cap not tight enough	Tighten the cap
	Tank water is Hot	Fill with cool water only
Crack in Tank	Hot water will cause tank to pressurize	Fill with cool water only
	Tanks will crack if hit or dropped	Handle tank with Care
Film on tank	Mineral deposits	Clean/disinfect tank as instructed in weekly cleaning instructions

FREQUENTLY ASKED QUESTIONS QUESTIONS ANSW

What are the variables that affect run time?

The estimated run time for this humidifier is based on average room conditions. The actual run time of your humidifier is dependent on numerous variables such as:

- 1. Air exchange in the room where the humidifier is placed.
- 2. Room construction where the humidifier is placed.
- 3. Temperature of the room where the humidifier is placed.
- 4. Humidity levels in the room where the humidifier is placed.
- Movement of occupants and the opening and closing of doors in the room where the humidifier is placed.
- 6. Home furnishings in the room where the humidifier is placed.

How do I remove film on			
water tank?			

See Daily Maintenance instructions. Regular cleaning is recommended.

How can I extend the run time?

- 1. Run your unit on the lowest setting.
- If your unit has electronics, set it to your desired humidity level. The unit will turn on and off, which will extend the run time.
- 3. Fill the tank all the way full, place it on the base, let the water empty into the base until it stops bubbling, then refill the tank full again. This ensures maximum water capacity and will extend run time.

DÉPANNAGE QUESTIONS FRÉQUEMMENT DEMANDÉES

PROBLÈME	CAUSE PROBABLE	SOLUTION
Témoin d'alimentation éteint	L'appareil n'est pas branché	Branchez l'appareil
Témoin de remplissage	Réservoir d'eau vide	Remplissez le réservoir
réinitialisation allumé	Appareil non réinitialisé après le remplissage Accumulation de tartre sur l'élément chauffant	Suivez le guide pour les consignes de réinitialisation Éliminez le tartre de l'élément chauffant
Jet de vapeur minime ou inexistant	Accumulation de tartre sur l'élément chauffant	Éliminez le tartre de l'élément chauffant
De l'eau s'écoule du réservoir	Un anneau de caoutchouc est manquant	Retirez le bouchon du réservoir et replacez l'anneau
	Le bouchon n'est pas assez serré	Serrez le bouchon
	L'eau du réservoir est chaude	Remplissez d'eau froide seulement
Le réservoir est fendu	L'eau chaude entraîne la pressurisation du réservoir	Remplissez d'eau froide seulement
	Le réservoir fendra s'il est frappé ou échappé	Manipulez le réservoir avec soin
Pellicule sur le réservoir	Dépôts minéraux	Nettoyez/désinfectez le réservoir selon
	les consignes de nettoyage hebdomadaire	

QUESTIONS FRÉQUEMMENT DEMANDÉES

WARRA

3 \
Sunbeam Products, Inc. doing business as .

Limited doing business as Jarden Consume from the date of purchase, this product wi repair or replace this product or any comp Replacement will be made with a new or r replacement may be made with a similar pattempt to repair or adjust any electrical of This warranty is valid for the original retain Keep the original sales receipt. Proof of pucenters, or retail stores selling JCS product conditions of this warranty.

This warranty does not cover normal wear misuse of the product, use on improper vo repair or alteration by anyone other than cover: Acts of God, such as fire, flood, hur

What are the limits on JCS's Liab

JCS shall not be liable for any incidental o statutory warranty or condition.

Except to the extent prohibited by applical particular purpose is limited in duration to JCS disclaims all other warranties, condition JCS shall not be liable for any damages of the product including incidental, special, contract, fundamental or otherwise, or for Some provinces, states or jurisdictions do nor limitations on how long an implied warranty gives you specific legal rightstate to state or jurisdiction to jurisdiction.

How to Obtain Warranty Service

In the U.S.A.

If you have any question regarding this we 1-800-546-5637 and a convenient service In Canada

If you have any question regarding this wall-800-546-5637 and a convenient service

INFORMAT

GAR

Sunbeam Products, Inc. faisant affaires sous (Canada) Limited faisant affaires sous le non période d'trois ans à partir de la date d'acha discrétion, réparera ou remplacera ce produi garantie. Le produit ou composant de remplacerar ou d'ajuster toute fonction électrique Cette garantie est valide pour l'acheteur initivotre facture d'achat originale. Les détaillant n'ont pas le droit d'altérer, de modifier ou de Cette garantie ne couvre pas l'usure norma négligente ou mauvaise utilisation du produinstructions d'utilisation, démontage, réparautorisé de JCS. En outre, la garantie ne colouragans et les tornades.

Quelles sont les limites de la respon JCS ne sera pas tenu responsable de tout de condition expresse, implicite ou réglementa Sauf si cela est interdit par les lois en vigue

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
 To avoid fire or shock hazard, plug the appliance directly into a 120V AC electrical outlet.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs or near
- heat registers.

 DO NOT place humidifier near heat sources such as stoves, radiators, and heaters. DO locate your humidifier on an inside wall near an electrical outlet. The humidifier should be at least 4 inches (10 cm) away from the wall for best results.

 NEVER place humidifier in an area where it is accessible to children. NEVER use humidifier in a closed room, particularly where a child may be sleening resting or playing (a closed room may
- sleeping, resting, or playing (a closed room may result in excessive humidity).
- WARNING: Do not attempt to refill humidifier without first unplugging the unit from its electrical outlet. Failure to heed this warning may cause personal injury. Be sure to unplug the unit by pulling on the plug and not the cord.
- Never place anything over moisture outlet when the unit is running.
- NEVER drop or insert any object into any openings. DO NOT place hands, face or body directly over or near Moisture Outlet while unit is in operation. DO NOT cover Moisture Outlet while the unit is operating.
- DO NOT operate any appliance with a damaged cord or plug, after the appliance malfunctions, or if it has

- been dropped or damaged in any manner. Return appliance to manufacturer for examination, electrical
- or mechanical adjustment, or repair.

 10. Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold the manufacturer may cause hazards.
 11. DO NOT use outdoors.
- 12. Always place humidifier on a firm, flat, level surface.

 A waterproof mat or pad is recommended for use under the humidifier. NEVER place it on a rug or carpet, or on a finished floor that may be damaged by exposure to water or moisture.
- 13. DO NOT allow the Moisture Outlet to directly face the wall. Moisture could cause damage, particularly to wall paper.

 14. Humidifier should be unplugged when not in use.
- NEVER tilt, move, or attempt to empty unit while it is operating. Shut off and unplug before removing the
- operating. Shut off and unplug before removing the water tank and moving the unit. If you have a warm mist humidifier, DO NOT attempt to remove the water tank within 15 minutes after the humidifier is turned off and unplugged. Serious injury may result.

 16. This humidifier requires daily and weekly maintenance to operate appropriately. Refer to daily and weekly cleaning procedures. Use only cleaners and additives recommended by the manufacturer. Never use gasoline, glass cleaner, furniture polish, paint thinner, or other household solvents to clean any part of the humidifier.

 17. Excessive humidity in a room can cause water
- 17. Excessive humidity in a room can cause water condensation on windows and some furniture. If this happens, turn the humidifier OFF.



THIS APPLIANCE HAS A POLARIZED PLUG (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet.

DO NOT ATTEMPT TO MODIFY THIS PLUG OR DEFEAT THIS SAFETY FEATURE IN ANY WAY.

VEUILLEZ LIRE ET CONSERVER CES DIRECTIVES DE SÉCURITÉ IMPORTANTES

Lors de l'usage de tout appareil électrique, des précautions fondamentales doivent être observées pour réduire le risque d'incendie, de choc électrique, et de blessure, y compris celles-ci:

- Lisez toutes les directives avant d'utiliser cet appareil.
- Pour éviter le risque de choc électrique, branchez l'humidificateur directement dans une prise électrique CA 120 V.
- Tenez le cordon d'alimentation éloigné des aires achalandées. Pour éviter tout risque d'incendie, ÉVITEZ de placer le cordon d'alimentation sous des
- moquettes, ou près de tout appareil de chauffage. EVITEZ de placer l'humidificateur près de sources de chaleur comme des cuisinières, radiateurs ou chaufferettes. PLACEZ-LE plutôt près d'un mur intérieur et d'une prise murale. Pour de meilleurs résultats, l'humidificateur doit être placé à au moins 4 po du mur. NE placez JAMAIS l'humidificateur à un endroit où il
- serait accessible aux enfants. N'utilisez jamais l'humidificateur dans une pièce fermée, particulièrement où un enfant dort, se repose ou joue (une pièce fermée peut donner lieu à un niveau excessif d'humidité).

- endommagé de quelque façon. Retournez l'appareil au fabricant à des fins d'examen, de mise au point électrique ou mécanique ou de réparation.
- Ce produit est conçu pour une utilisation domestique SEULEMENT telle que décrite dans ce guide. Tout autre usage non recommandé par le fabricant peut causer des risques d'incendie, de choc électrique ou de blessure.
- risques d'incendie, de choc électrique ou de blessure.
 L'usage d'accessoires non recommandés ou non vendus
 par le fabricant peut présenter des dangers.

 11. Ne PAS utiliser l'humidificateur à l'extérieur.

 12. Toujours placer l'humidificateur sur une surface plane,
 ferme et à niveau. Nous vous recommandons de placer
 un napperon ou tapis imperméable sous l'appareil. Ne
 PAS placer l'humidificateur sur un tapis ou plancher fini
 pouvant être endommagé par l'eau ou l'humidité.

 13. Ne pas permettre à la sortie d'humidité de faire
 directement face à un mur. L'humidité peut causer
 des dommages surfaut au panier neint

- des dommages, surtout au papier peint.

 14. L'humidificateur doit être débranché s'il n'est pas utilisé.

 15. Ne JAMAIS tenter d'incliner ou de déplacer l'appareil pendant qu'il est en marche. Arrêtez et débranchez-

FEATU

- 18. Do not use humidifier in an area wher level is in excess of 50%. Use a hygro available at your local retailer or thro manufacturer to measure the humidity
- 19. DO NOT attempt to repair or adjust an mechanical functions on this unit. Doir your warranty. The inside of the unit of serviceable parts. All servicing should by qualified personnel only.
- 20. Never place housing under water flow,
- 21. DO NOT plug in the cord with wet han shock could result.
- 22. DO NOT pour water in any openings o water tank.
- 23. If you have a warm mist humidifier, a before refilling water tank or mainten heater bulb is hot.
- 24. To prevent damage to surfaces, do not humidifier under overhanging surface
- 25. NEVER operate unit without water in the 26. Do not move unit after it has been use
- cools completely.
 27. Use both hands when carrying full tan

PLEASE READ AND THESE IMPORTA SAFETY INSTRUCT

CONSUMER SAFETY INFORMA

NOTE: This is an electrical appliance attention when in use.

NOTE: If moisture forms on the walls or v room, turn off the humidifier. The room al plenty of humidity and additional moisture damage.

NOTE: DO NOT block air inlet or outlet.

Cord and Plug Installation Safety The length of cord used on this appliance v reduce the hazards of becoming tangled in

CARACTÉRIS

- 18. Ne pas utiliser l'humidificateur dans u l'humidité ambiante excède 50 %. Pou l'humidité, utilisez un hygromètre que
- 19. Ne PAS tenter de réparer ou de mettre fonction électrique ou mécanique de c fait de le faire annulerait la garantie. l'appareil ne contient aucune pièce uti propriétaire. Les réparations et tâches doivent être faites que par du personr 20. Ne jamais placer le boîtier sous l'eau d
- l'immerger dans tout liquide. 21. Évitez de brancher le cordon si vos ma mouillées. Vous risqueriez un choc élec 22. Ne PAS verser d'eau dans les ouvertur
- l'humidificateur, sauf le réservoir. 23. Si yous avez un humidificateur à buée
- refroidir l'appareil avant l'entretien or remplir le réservoir. L'ampoule chauff 24. Pour prévenir les dommages aux surfe
- pas l'humidificateur sous les surfaces (25. Ne JAMAIS faire fonctionner l'appareil