

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



BEMIS 759200 Owner's Manual

[Shop genuine replacement parts for BEMIS 759200](#)



[Find Your BEMIS Humidifier Parts - Select From 274 Models](#)

----- Manual continues below -----

TROUBLESHOOTING

TROUBLE	PROBABLE CAUSE	SOLUTION
Unit does not turn on.	Water spilled in humidistat.	Drain water from base and allow unit to dry for 15 minutes.
	Circuit breaker has been tripped.	Check circuit breaker.
Mist output minimal to none.	Filter has not absorbed water.	Wait 15 minutes before starting humidifier.
	Mineral buildup in tray.	See Weekly Maintenance under Cleaning and Maintenance Instructions. Regular cleaning is recommended to keep the unit functioning properly.
	Humidistat is set too low.	Raise the level of humidity by adjusting the humidistat (see Operating Instructions).
	Filter needs to be replaced.	Replace your filter (755001) by calling 1-800-546-5637.
Water leaks from tank.	Rubber tank ring is missing or improperly placed.	Remove tank cap then replace or reposition ring.
	Cap not tight enough.	Tighten the cap.
Filter turns brown.	The filter needs to be replaced.	Replace your filter (755001) by calling 1-800-546-5637.
	Short filter life.	In areas with hard water the filter will need to be changed more frequently.
Film on water tank.	Mineral deposits cause film on tank to build up.	See Daily Maintenance under Cleaning and Maintenance instructions. Regular cleaning is recommended to keep the unit functioning properly. To order Cleanse Clean™ (S1710), call 1-800-546-5637.
Water in tank appears cloudy.	Filter needs to be replaced.	Replace your filter (755001) by calling 1-800-546-5637.
	Water tank filled with warm water.	Use cool water to fill the water tank – and only use care products recommended in this manual.
Unit cycles on/off.	Humidifier is reacting to room.	Set the 1 Touch™ Electronic Humidistat to a higher or lower desired setting.
Very tight tank cap.	Tank cap over tightened.	Add liquid soap to cap gasket to ease opening.

REPLACEMENT ACCESSORIES

(see included Humidifier Accessory Form)

- Comfort Check hygrometer/thermometer
Reads humidity and temperature levels
- Digital HHG175:\$19.99
- Analog HHG150:\$12.99
- Replacement Filters
- Evenflo® 755001:\$10.99

- SC1720 Cool Mist Care Pack\$14.99
(Complete care for your humidifier:
One bottle each of S1705, 1708, 1710)
- Individual Bottles also available:
- S1705 Water Treatment\$5.99
- S1708 Bacteriostat Solution\$5.99
- S1710 Cleanse Clean™\$5.99
(plus shipping and handling)

STORAGE INSTRUCTIONS

When not using your humidifier for an extended period of time:

1. Dispose of the filter. DO NOT leave in unit.
2. Clean, rinse and thoroughly dry the humidifier as directed in weekly maintenance. DO NOT leave any water in the unit when storing.

WARRANTY

Leaving water in the unit may render the unit in-operable for

3. Place the humidifier in the original carton and store in a cool, dry place.
4. Order your Evenflo® replacement filter (755001) for next year.

SERVICE INSTRUCTIONS

1. Do NOT attempt to repair or adjust any electrical or mechanical functions on this unit.
2. If you have any questions regarding this unit's operation or believe any repair is needed, please contact your local Consumer Service Representative.
3. If you need to exchange the unit, please return it in its original carton, with a sales receipt. If you are returning the unit more than 30 days after the date of purchase, please contact your local Consumer Service Representative.
4. If you have any other questions or comments, feel free to write us:

Evenflo®
P.O. Box 769
Milford, MA 01757-0769

For your own records, staple or attach your sales receipt to this manual. Also, please

STORE NAME _____

LOCATION: _____

DATE PURCHASED: _____

THREE (3) YEAR LIMITED WARRANTY

SAVE THIS WARRANTY

- A. The quality controls used in the manufacture of this Evenflo® product are to ensure that it meets the highest standards of quality.
- B. This Warranty applies only to the original purchaser of this product.
- C. This Warranty applies ONLY to repair or replacement of any supplied or manufactured part that has failed in normal use due to defects in material or workmanship. It does not cover installation expenses.
- D. Operating this unit under conditions other than those recommended or at voltages other than those recommended will render this WARRANTY VOID.
- E. Unless otherwise proscribed by law, Evenflo® shall not be liable for consequential or incidental damages, including water damage, resulting from malfunctions, defects in material or workmanship, or from the use of the product.
- F. All parts of this Evenflo® product are guaranteed for a period of 3 years as follows:
 1. Within the first 30 days from date of purchase, the store from which you purchased the product (provided the store has in-stock replacement.)
 2. Within the first thirty six months from date of purchase, subject to the condition that the product is returned to Evenflo®, freight prepaid, with proof of purchase.
- G. If you have any problem with this product, please write our Consumer Service Department at the address below.
- H. IMPORTANT RETURN INSTRUCTIONS Your warranty depends on your following the instructions below:
 1. Carefully pack the item in its original carton or other suitable box to avoid damage.
 2. Before packing your unit for return; be sure to enclose:
 - a) Your name, full address with zip code and telephone number,
 - b) A dated sales receipt or PROOF OF PURCHASE,
 - c) Your \$7.00 check for return packaging, and
 - d) The model number of the unit and the problem you are having. (Enclose a copy of this warranty with the unit.)
 3. Evenflo® recommends you insure the package (as damage in shipment is not covered by this warranty).
 4. All shipping charges must be prepaid by you (as noted in paragraph F).
 5. Mark the outside of your package:

CONSUMER SERVICE DEPARTMENT
EVENFLO®
2 PULLMAN STREET
WORCESTER, MA 01606

SHIPPING AND HANDLING CHARGES: \$7.00

This warranty gives you specific legal rights, and you may have other rights which vary by state. This warranty does not constitute an offer of, or subtraction from, the statutory warranties and other rights and remedies contained in applicable law, such provision shall be deemed voided or amended, as necessary.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

WHEN USING ELECTRICAL APPLIANCES, ESPECIALLY WHERE CHILDREN ARE PRESENT, YOU SHOULD ALWAYS FOLLOW THESE BASIC PRECAUTIONS TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK AND INJURY TO PERSONS:

1. Read all instructions before using the appliance.
2. To avoid fire or shock hazard, plug the appliance directly into a 120 V AC electrical outlet.
3. Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiator, stoves, or heaters.
4. DO NOT place humidifier near heat sources such as stoves, radiators, and heaters. Do locate your humidifier on an inside wall near an electrical outlet. The humidifier should be at least 4" away from the wall for best results.
5. NEVER place humidifier in an area where it is accessible to children. NEVER use humidifier in a closed room, particularly where a child may be sleeping, resting, or playing (a closed room may result in excessive humidity).
6. WARNING: DO NOT attempt to refill humidifier without first unplugging the unit from its electrical outlet. Failure to heed this warning may cause personal injury. Be sure to pull the plug and not the cord.
7. Never place anything over moisture outlet when the unit is running.
8. NEVER drop or insert any object into any openings.
9. DO NOT operate any appliance with a damaged cord or plug, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Return appliance to manufacturer for examination, electrical or mechanical adjustment, or repair.
10. Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by Evenflo® may cause hazards.
11. DO NOT use outdoors.
12. Always place humidifier on a firm, flat, level surface. A waterproof mat or pad is recommended for under the humidifier. NEVER place it on a rug or carpet, or on a finished floor that may be damaged by exposure to water or moisture.
13. DO NOT allow the Moisture Outlet to directly face the wall. Moisture could cause damage, particularly to wallpaper.
14. Humidifier should be unplugged when not in use.



THIS PRODUCT IS EQUIPPED WITH A POLARIZED AC (Alternating Current) PLUG (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact qualified personnel to install the proper outlet.
DO NOT DEFEAT THE SAFETY PURPOSE OF THIS POLARIZED PLUG IN ANY WAY.

15. NEVER tilt, move, or attempt to empty unit while it is operating. Shut off and unplug before removing the water tank and moving the unit.
16. This humidifier requires daily and weekly maintenance to operate appropriately. Refer to daily and weekly cleaning procedures.
17. NEVER use detergents, gasoline, glass cleaner, furniture polish, paint thinner, or other household solvents to clean any part of the humidifier.
18. Excessive humidity in a room can cause water condensation on windows and some furniture. If this happens, turn the humidifier OFF.
19. DO NOT use humidifier in an area where humidity level is in excess of 50%.
20. DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
21. Never place housing under water flow or immerse in liquids.
22. DO NOT plug in the cord with wet hands: electric shock could result.
23. DO NOT pour water in any openings other than the water tank.
24. To prevent damage to surfaces, do not place humidifier under overhanging surfaces.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

Thank you for choosing a Evenflo® Cool Mist humidifier. To ensure the best performance from your humidifier, please read and save the following instructions.

Consumer Safety Information

Note: This is an electrical appliance and requires attention when in use.

Note: If moisture forms on the walls or windows of the room, turn off the humidifier. The room already has plenty of humidity and additional moisture may cause damage.

Cord and Plug Installation Safety Instructions

The length of cord used on this appliance was selected to reduce the hazards of becoming tangled in, or tripping over a longer cord. If a longer cord is necessary an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the humidifier. Care must be taken to arrange the extension cord so that it will not drape over the countertop or tabletop where it can be pulled on by children or accidentally tripped over.

HOW COOL MIST WORKS

Your Evenflo® Cool Mist humidifier draws dry air through the rear air intake grill area. This air is then passed through a moisture-laden wick filter, which retains the minerals and deposits in the water. The resulting moist air is directed back into the room from the top air grill.

NOTE: This humidification system provides a cool, invisible moisture output. It is normal not to see the mist.

NOTE: A humidity level below 20% can be unhealthy and uncomfortable. The recommended humidity level is between 40%-50%.

PRE-OPERATING INSTRUCTIONS

1. Be sure the unit is OFF and is disconnected from the electrical outlet.
2. Select a location for your humidifier, on a flat surface, about 4" away from the wall. Do not place your humidifier on furniture or a floor location that will not be damaged by moisture is best.
3. Remove the water tank by holding the carry handle and lifting straight upward (see figure 1).
4. Remove the main housing by lifting straight upward. Check to see that the wick filter is properly in place. Replace the humidifier housing.

FILLING THE WATER TANK

NOTE: This humidifier holds about 1 gallon of water in the tank and humidifier base. The humidifier will produce up to 3 gallons of moisture over a 24-Hour period, depending on the room humidity and temperature.

1. Be sure the unit is OFF and is disconnected from the electrical outlet.
2. Remove the tank from the base by holding the handle and lifting straight up (see figure 1).
3. Twist off the tank cap located on the bottom of the tank by turning counter clockwise and fill the water tank with cool, fresh water.
Do not fill with warm water as this may cause leaking.
4. After filling the tank, replace the tank cap by firmly turning clockwise and then replace the water tank on the base. The tank will immediately begin to empty into the base.
5. Plug the power cord into a 120V AC electrical outlet.