


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# LG HMH024WAE/WAC Owner's Manual

[Shop genuine replacement parts for LG  
HMH024WAE/WAC](#)

## 1. Indoor Unit




[Find Your LG Air Conditioner Parts - Select From 2328 Models](#)

----- Manual continues below -----


# Wiring Diagram

## (1) Indoor Unit


1. LS-D1821CL/CM/CD, LS-D1822CL/CM/CD, LS-D1862CL/CM/CD, LS-D1863CL/CM/CD




2. LS-D1862HL/HM/HD, LS-D1863HL/HM/HD



3. LS-D2422CL/CM/CD/HL/HM/HD, LS-D2663CL/CM/CD/HL/HM/HD




4. LS-D2462CL/CM/CD, LS-D2462HL/HM/HD, LS-D2822CL/CM/CD




## (2) Outdoor Unit


### 1. LS-D1821CL/CM/CD, LS-D1822CL/CM/CD, LS-D1862CL/CM/CD, LS-D1863CL/CM/CD




### 2. LS-D1862HL/HM/HD, LS-D1863HL/HM/HD




### 3. LS-D2422CL/CM/CD



### 4. LS-D2462CL/CM/CD, LS-D2663CL/CM/CD



5. LS-D2422HL/HM/HD, LS-D2462HL/HM/HD, LS-D2663HL/HM/HD



6. LS-D2822CL/CM/CD

