


PANASONIC 5995 Owner's Manual

[Shop genuine replacement parts for PANASONIC 5995](#)

Nozzle Housing




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

PANASONIC

Models: MC-5140, MC-5150, MC-5155, MC-5190, MC-5340, MC-5995

Nozzle Housing




PANASONIC

Models: MC-5140, MC-5150, MC-5155, MC-5190, MC-5340, MC-5995

A1	P-0103	Nozzle Housing, 5140	A13	P-938	Lamp Holder
A1	P-010301	Nozzle Housing, 5150	A13	P-93001	Lamp Socket
A1	P-010309	Nozzle Housing, 5155	A13	P-9367	Lamp Socket
A1	P-000072	Nozzle Housing, 5190	A14	P-85210	Bulb Support
A1	P-000221	Nozzle Housing, 5340	A15	N/A	Screw, 5155
A1	P-000257	Nozzle Housing, 5995	A15	P-000276	Screw, 5340
A2	P-78	Plastic Holder	A16	P-000132	Screw, 5155
A3	P-81	Tight Packing	A16	P-00932	Screw, 5340
A4	P-58	Pedal Spring	A17	P-2423	Wire Bushing
A5	P-000132	Screw	A18	P-3820	Wire Cord, le
A6	P-10008	Furniture Guard, 5140	A18	P-000275	Wire Cord, le
A6	P-1000	Furniture Guard, 5150	A19	P-0038	Wire Connect
A6	P-10009	Furniture Guard, 5155	A20	P-000623	Reflection Pl
A6	P-10008	Furniture Guard, 5190, 5340	A20	P-10109	Reflector, 59
A6	P-10107	Furniture Guard, 5995	A21	P-86210	Supporter, re
A7	P-02001	Top Mark, 5140	A22	P-2120	Window, 515
A7	P-02002	Top Mark, 5150	A23	P-2500	Shaft, plastic
A7	P-02003	Top Mark, 5155		P-000076	Nozzle Hose
A7	P-000090	Top Mark, 5190		P-7500	Lower Plate
A7	P-000222	Top Mark, 5340		P-000223	Side Plate, 5
	P-10105	Window, 5995		P-000095	Frame, 5995
A8	P-9113	Lower Plate Assembly		P-000010	Pedal Spring
A8	P-000075	Lower Plate Assembly, 5190, 5340		P-4720	Pedal, 5995
A8	P-000113	Lower Plate Assembly, 5995		P-000132	Screw, frame
	P-2713	Lower Plate Only, 5190, 5340		P-00008	Shaft, pedal,
A82	P-0800	Latch			
A83	P-000132	Screw			
A9	P-43	Belt Cover			
A10	P-7500	Body Packing			
A10	P-81	Body Packing, 5190			
A11	P-2287	Belt, 2 pack			
A11	P-200	Belt, sold each (R)			
A12	P-2810	Bulb, 5155, 5340, 5995			


Agitator Assembly



PANASONIC

Models: MC-5140, MC-5150, MC-5155, MC-5190, MC-5340, MC-5995

Motor Housing, Motor, Handle, Body



PANASONIC

Models: MC-5140, MC-5150, MC-5155, MC-5190, MC-5340, MC-5995

C1	P-40029	Dust Compartment, 5140	C38	P-000504	Wire Cord, 5
C1	P-40020	Dust Compartment, 5150	C39	SS-71B	Wire Nut, 100
C1	P-400209	Dust Compartment, 5155	C40	P-333	Protector Fil
C1	P-000077	Dust Compartment, 5190	C41	P-64209	Handle, 514
C1	P-000225	Dust Compartment, 5340	C41	P-64201	Handle, 515
C1	P-000503	Dust Compartment, 5995	C41	P-6429	Handle, 515
C2	P-8913	Switch, on / off	C41	P-6412	Handle, 519
C3	N/A	Cord Stopper	C41	P-000270	Handle, 599
C4	P-000132	Screw		P-000231	Handle Grip
C5	P-97020	Cord, 5140		P-000249	Handle Grip
C5	P-97021	Cord, 5150	C42	P-53009	Cord Hook, 5
C5	P-97022	Cord, 5155	C42	P-53001	Cord Hook, 5
C5	P-000078	Cord, 5190	C42	P-5309	Cord Hook, 5
C5	P-9703	Cord, 5340	C42	P-000232	Cord Hook, 5
C5	P-000151	Cord, 5995	C42	P-000243	Cord Hook, 5
C6	SS-71B	Wire Nut, 100 pack (R)	C43	P-55009	Cord Storage
C7	P-6601	Packing, dust box, 5140, 5190, 5995	C43	P-55001	Cord Storage
C7	P-66011	Packing, dust box, 5150	C43	P-5509	Cord Storage
C7	P-66	Packing, dust box, 5155	C43	P-000233	Cord Storage
C7	P-000501	Packing, dust box, 5340	C43	P-000244	Cord Storage
C8	P-03029	Switch Cover, 5140, 5190	C44	P-7670	Spring, cord
C8	P-0302	Switch Cover, 5150, 5995	C45	P-587	Washer
C8	P-030209	Switch Cover, 5155	C46	P-54009	Cord Hook, 5
C8	P-000502	Switch Cover, 5340	C46	P-54001	Cord Hook, 5
C9	P-73013	Packing, switch cover, 5140, 5190	C46	P-5409	Cord Hook, 5
C9	P-73012	Packing, switch cover, 5150, 5340, 5995	C46	P-000234	Cord Hook, 5
C9	P-73	Packing, switch cover, 5155	C46	P-000245	Cord Hook, 5
C10	P-000132	Screw	C47	P-430	Screw
C11	P-7301	Screw, handle	C48	P-000084	Dust Cover,
C12	P-2117	Nut	C48	NLA	Dust Cover,
C13	P-3200	Filter Supporter	C48	NLA	Dust Cover,
C14	P-375	Secondary Filter	C48	P-000236	Dust Cover,
C14	P-9829	Secondary Filter, electrostatic, 5340	C48	P-000261	Dust Cover,
C15	P-0107	Roller, 5140, 5155	C49	P-2101	Ornamental
C15	P-0114	Roller, 5150, 5190, 5340, 5995	C49	P-2102	Ornamental
C16	P-161	Shaft, roller	C49	P-2103	Ornamental
C17	P-05	E-Clip, 30 pk	C49	P-000085	Ornamental
C17	N/A	E-Clip, 10 pk, 5190, 5340, 5995		P-000237	Vac Gauge F
C18	P-115P	Paper Bag, type "U", 3 pack	C50	P-34019	Nozzle Hose
C18	P-115PT	Paper Bag, type "U", 12 pack	C50	P-34010	Nozzle Hose
C18	253	Paper Bag, type "U", 3 pack (R)	C50	P-3419	Nozzle Hose
C18	253-12	Paper Bag, type "U", 12 pack (R)	C50	N/A	Nozzle Hose
C18	MF-11	Paper Bag, type "U-U3", microfiltration, 3 pk (R)	C50	N/A	Nozzle Hose
C19	P-60209	Suction Inlet, 5140		P-9300	Indicator Pa
C19	P-0054	Suction Inlet, 5150		P-000147	Indicator Ca
C19	P-6029	Suction Inlet, 5155		P-000148	Indicator Sp
C19	P-000079	Suction Inlet, 5190		P-000149	Indicator Lea
C19	P-000226	Suction Inlet, 5340		P-000150	Indicator Bo
C19	P-000258	Suction Inlet, 5995		P-000277	Screw, 5340
C20	P-2710	Cover, 5140, 5190		P-9425	Attachment
C20	NLA	Cover, 5150		NLA	Wand
C20	P-27109	Cover, 5155		N/A	Wand, 5190
C20	P-000227	Cover, 5340		NLA	Crevice Tool
C20	P-000259	Cover, 5995		P-000088	Crevice Tool
C21	P-000132	Screw		P-0091	Dusting Brus
C22	P-090209	Motor Case, 5140, 5190		P-000087	Dusting Brus
C22	P-09020	Motor Case, 5150		NLA	Upholstery T
C22	P-09029	Motor Case, 5155			
C22	P-000228	Motor Case, 5340			
C22	P-000260	Motor Case, 5995			
C23	P-201	Packing, rear cover			
C24	P-1913	Packing, motor case, 5140, 5190			
C24	P-1912	Packing, motor case, 5150, 5340, 5995			
C24	P-195	Packing, motor case, 5155			
C25	P-000132	Screw			
C26	P-692	Protector			
C27	P-000057	Spring, protector			
C28	P-000056	Case, protector			
C28	P-000056	Case, protector			
C28	P-000056	Case, protector			
C28	P-000056	Case, protector			

FAN REPLACEMENT

1..... P-5371 Fan Case
1..... P-000067 Fan Case, 5340