

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



PANASONIC V7309 Owner's Manual

[Shop genuine replacement parts for PANASONIC
V7309](#)




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----


Models: MC-V5710, MC-V5715, MC-V5720, MC-V5725, MC-V5730, MC-V5740, MC-5750, MC-V5760, V7305, V7309

Nozzle Housi

- 1 P-10326..... Nozzle Housing, V5710
- 1 P-10305..... Nozzle Housing, V5715
- 1 P-10511..... Nozzle Housing, V5720
- 1 P-10363..... Nozzle Housing, V5725
- 1 P-10840..... Nozzle Housing, V5730
- 1 P-10865..... Nozzle Housing, V5740
- 1 P-10841..... Nozzle Housing, V5750
- 1 P-10852..... Nozzle Housing, V5760
- 1 P-10350..... Nozzle Housing, V7305
- 1 P-10516..... Nozzle Housing, V7309
- 2 P-10105..... Window
- 2 P-9854..... Window, V5750, V5760, V7305, V7309
- P-9879..... Light Cover, V5750
- P-10653..... Light Cover, V5760
- P-10352..... Light Cover, V7305
- P-10517..... Light Cover, V7309
- P-8172..... Screw, light cover, V5750, V5760, V7305, V7309
- 3 P-2500..... Shaft, plastic
- 3 P-2530..... Shaft, plastic, V5730
- 3 P-10819..... Shaft, plastic, V5740, V5750, V5760
- 4 P-10302..... Furniture Guard
- 4 P-10351..... Furniture Guard, V5750, V7305, V7309
- 4 P-10541..... Furniture Guard, V5760
- 5 P-81..... Packing, nozzle
- 6 P-000095..... Frame
- 7 P-58..... Spring, pedal
- 7 P-9857..... Spring, pedal, V5750, V7305, V7309
- 8 P-6140..... Screw, pedal spring
- 9 P-10336..... Pedal, V5710
- 9 P-10303..... Pedal, V5715
- 9 P-4720..... Pedal, V5750, V5760, V7305
- P-513..... Shaft, pedal, V5750, V5760, V7305, V7309
- P-4104..... Screw, handle release assy, V5750, V7305, V7309
- 10 P-6140..... Screw, frame
- 10 P-02181..... Screw, frame/pedal, V5760
- 11 P-V270B..... Belt, type U8, 2 pack
- 11 P-00181..... Belt, 2 pack
- 12 P-9197..... Bottom Plate Assy
- 12 P-10724..... Bottom Plate Assy, V5750
- 12 P-9764..... Bottom Plate Assy, V5760
- 12 P-8947..... Bottom Plate Assy, V7305, V7309
- 13 P-2707..... Bottom Plate Only
- 13 P-10725..... Bottom Plate Only, V5750
- 13 P-9765..... Bottom Plate Only, V5760
- 13 P-5893..... Bottom Plate Only, V7305, V7309
- 14 P-7500..... Packing, lower plate
- 14 P-10394..... Packing, lower plate, V5750, V5760, V7309
- 15 P-43..... Belt Cover
- 15 P-9861..... Belt Cover, V5750, V5760, V7305, V7309
- 16 P-6800..... Screw, bottom plate
- 17 P-10304..... Nozzle Hose, short
- 17 P-9862..... Nozzle Hose, short, V5750, V7305, V7309
- 18 P-9367..... Bulb Socket
- 19 P-10109..... Reflector
- 20 P-7550..... Bulb
- 20 P-2810..... Bulb, V7305
- P-78..... Round Plastic Holder
- P-10353..... Slider Support, V5750, V5760, V7305, V7309
- P-6140..... Screw, frame




Body



Models: MC-V5710, MC-V5715, MC-V5720, MC-V5725, MC-V5730, MC-V5740, MC-V5750, MC-V5760, M

1	P-10842	Dust Compartment	17	P-74009	Stopper, wheel	31	P-1032	
1	P-10836	Dust Compartment, V5740	18	P-6115	Washer, wheel	31	P-0867	
1	P-10843	Dust Compartment, V5750	19	P-115P	Paper Bag, type U3, 3 pack	31	P-1847	
1	P-10853	Dust Compartment, V5760	19	P-145M	Paper Bag, type U6 micron, 3pk	31	P-1035	
2	P-00104	Wire Tie	20	P-10315	Protector Cover	31	P-1032	
3	P-0698	Cord Stopper	21	P-6096	Protector	31	P-1032	
4	P-6140	Screw, cord stopper	22	P-10316	Spring, protector, red	31	P-1847	
5	P-11018	Power Cord	23	P-6140	Screw, front cover	32	P-5475	
5	P-6079	Power Cord, V5710	24	P-10602	On/Off Switch	33	P-6088	
5	P-10507	Power Cord, V5720,V5740	25	P-9907	Screw, handle	34	P-6010	
6	P-000623	Wire Connector	26	P-10317	Packing, right	34	P-1078	
7	P-10309	Packing, dust compartment	27	P-5860	Packing, left	35	P-1032	
8	P-10312	Switch Cover	28	P-10330	Dust Cover, V5710	35	P-1084	
9	P-6140	Screw, switch cover	28	P-10318	Dust Cover, V5715	35	P-1032	
10	P-6069	Crevice Tool	28	P-10513	Dust Cover, V5720	36	P-1032	
10	P-10805	Crevice Tool, V5740,V5750, V5760	28	P-10364	Dust Cover, V5725	37	P-1032	
11	P-9894	Packing, suction inlet	28	N/A	Dust Cover, V5730		P-9873	
11	P-10512	Packing, suction inlet, V5720, V5730,V5740,V5750, V5760,V7309	28	P-10866	Dust Cover, V5740			
12	P-4410	Lead Wire	28	P-10844	Dust Cover, V5750			
12	P-10508	Lead Wire, V5760	28	P-10854	Dust Cover, V5760			
13	P-10313	Front Cover	28	P-10354	Dust Cover, V7305			
14	P-10314	Secondary Filter, foam	28	P-10518	Dust Cover, V7309			
15	P-0114	Wheel	29	P-3820	Wire Cord			
16	P-16005	Shaft, wheel	30	P-000040	Exhaust Filter, foam, V5710			
			30	P-10319	Exhaust Filter, electrostatic, V5715,V5725,V7305			
			30	P-10600	Exhaust Filter (HEPA), V5730,			

Motor Case & Motor



1	P-0293	Motor Support Rubber, front	6	P-9911	Motor Support Rubber, rear, V5760	10	P-1035	
2	P-7552	Motor Assy	7	P-9931	Noise Suppressor	10	P-1051	
2	P-9833	Motor Assy, V5710	7	P-10670	Noise Suppressor, V5750,V5760 V7309	11	P-6140	
2	P-10793	Motor Assy, V5740	8	P-000623	Wire Connector	12	P-1033	
2	P-10846	Motor Assy, V5750	9	P-10324	Packing, rear cover	13	P-7805	
2	P-10855	Motor Assy, V5760	10	P-10328	Motor Case, V5710	14	P-8936	
2	P-8181	Motor Assy, V7305,V7309	10	P-10325	Motor Case, V5715	14	P-1071	
3	P-8182	Carbon Brush Assy	10	P-10514	Motor Case, V5720,V5730			
3	P-9834	Carbon Brush Assy, V5710	10	P-10365	Motor Case, V5725			
	P-0036	Brush Retainer Bracket, V5710	10	P-10868	Motor Case, V5740			
	P-0037	Screw, bracket, V5710	10	P-10847	Motor Case, V5750			
4	P-9823	Screw, carbon brush	10	P-10856	Motor Case, V5760			
5	P-8184	Ring Spacer						
6	P-8183	Motor Support Rubber, rear						