


Windsor PASSPORT PSP-ACO Owner's Manual


Shop genuine replacement parts for Windsor PASSPORT PSP-ACO




Find Your Windsor Vacuum Cleaner Parts - Select From 26 Models

----- Manual continues below ------


Models: VAC PAC VP, VP-J, VPH, VPH-J



Models: SSS-MST, XR-4, PSP, PSP-ACO, PSP-CB, PSP-J, PSP-PQ



Models: SSS-MST, XR-4, PSP, PSP-ACO, PSP-CB, PSP-J, PSP-PQ



| 3 WI-70092 | Screw |
|--------------|---|
| 4 | Instruction Card |
| 5 WI-38102 | Handle, upper, main |
| 6 WI-87013 | Washer |
| 7 WI-70011 | Screw |
| 8 WI-57047 | Nut |
| 9 WI-57040 | Nut |
| 10 WI-57104 | Nut |
| 11 WI-20054 | Clamp |
| 12 WI-70088 | Screw |
| 13 WI-73175 | Strap, 12", velcro |
| 14 | Cord End Only |
| 15 WI-23121 | Main Cord Assy |
| 15 WI-23502 | Main Cord Assy, SSS-MST |
| 15 WI-23146 | Main Cord Assy, PSP-CB |
| 16 WI-70199 | [1] 프로그램(A) (1) (1] [1] [1] (1] (1] (1] (1] (1] (1] (1] (1] (1] (|
| 17A WI-50532 | Label, wiring, 115V |
| | |

1 WI-70253 Screw

2 WI-50279 Label, ground symbol

| 18B WI-50556 label, prtct frm freez, japan | 34A WI-7206 |
|--|-------------|
| 19 WI-70082 Screw | 34B WI-7207 |
| 20 WI-62153 Plate, access panel | 35 WI-7025 |
| 21 WI-73200 Strain Relief | 36 WF5045 |
| 22 WI-14942 Boot, circuit breaker | 37A WI-7206 |
| 23 WI-57024 Nut | 37B WI-7206 |
| 24 WI-73195 Strain Relief | 38 WI-6608 |
| 25 WI-70211 Screw | 39 WI-5105 |
| 26 WI-26032 Receptacle, 240 V, VDE | 40 WI-8708 |
| 27 WI-50184 Label, WINDSOR | 41 WI-6709 |
| 28A WI-61215 Panel, 115V control | 42 WI-7316 |
| 28B WI-61180 Panel, 230V control | 43 WI-5900 |
| 29 WI-27376 Clip, switch, retaining | 44 WI-3606 |
| 30 A WI-14700 Breaker, 15A circuit | 45 WI-8839 |
| 30B WI-14312 Breaker, 7A circuit | 45 WI-8864 |
| 31 WI-57106 Nut | 46 WI-3810 |
| 32 WI-14022 Terminal Block, 115/230V | 47 WI-2737 |
| | |

33A WI-1419

33B WF1430

Models: SSS-MST, XR-4, PSP, PSP-ACO, PSP-CB, PSP-J, PSP-PQ

| 4 WI-87029 Washer 5 WI-70296 Shoulder Bolt 6 WI-57022 Nut 7 WI-67131 Rod, pivot 8 WI-73480 Spacer, vac lift 9 WI-70294 Shoulder Bolt 10 WI-66031 Pin 11 WI-14506 Block, height adjustment 12 WI-70417 Adjustment Screw 13 WI-57022 Nut 14 WI-8025 Height Adjustment Knob 16 WI-14508 Mounting Block, height adj 17 WI-70162 Screw 18 WI-70292 Shoulder Bolt 20 WI-87025 Washer 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-20063 Clamp 24 WI-39338 Hose, 1 or x 45', blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame | 3 | WI-85033 | Vac Shoe, w/o pointer |
|--|----|----------|----------------------------------|
| 6 | 4 | WI-87029 | Washer |
| 7 | 5 | WI-70296 | Shoulder Bolt |
| 8 WI-73480 Spacer, vac lift 9 WI-70294 Shoulder Bolt 10 WI-66031 Pin 11 WI-14506 Block, height adjustment 12 WI-70417 Adjustment Screw 13 WI-57022 Nut 14 WI-48025 Height Adjustment Knob 16 WI-14508 Mounting Block, height adj 17 WI-70162 Screw 18 WI-70292 Shoulder Bolt 20 WI-87025 Washer 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-2063 Clamp 24 WI-39338 Hose, 1 12 x 45", blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 6 | WI-57022 | Nut |
| 9 | 7 | WI-67131 | Rod, pivot |
| 10 WI-66031 Pin 11 WI-14506 Block, height adjustment 12 WI-70417 Adjustment Screw 13 WI-57022 Nut 14 WI-48025 Height Adjustment Knob 16 WI-14508 Mounting Block, height adj 17 WI-70162 Screw 18 WI-70292 Shoulder Bolt 20 WI-87025 Washer 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-20063 Clamp 24 WI-39338 Hose, 11er x 45t, blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 8 | WI-73480 | Spacer, vac lift |
| 11 WI-14506 Block, height adjustment 12 WI-70417 Adjustment Screw 13 WI-57022 Nut 14 WI-48025 Height Adjustment Knob 16 WI-14508 Mounting Block, height adj 17 WI-70162 Screw 18 WI-70292 Shoulder Bolt 20 WI-87025 Washer 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-20063 Clamp 24 WI-39338 Hose, 11er x 45", blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 9 | WI-70294 | Shoulder Bolt |
| 12 WI-70417 Adjustment Screw 13 WI-57022 Nut 14 WI-48025 Height Adjustment Knob 16 WI-14508 Mounting Block, height adj 17 WI-70162 Screw 18 WI-70292 Shoulder Bolt 20 WI-87025 Washer 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-20063 Clamp 24 WI-39338 Hose, 1 1 x x 45", blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 10 | WI-66031 | Pin |
| 13 WI-57022 Nut 14 WI-48025 Height Adjustment Knob 16 WI-14508 Mounting Block, height adj 17 WI-70162 Screw 18 WI-70292 Shoulder Bolt 20 WI-87025 Washer 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-20063 Clamp 24 WI-39338 Hose, 1 1 2 x 45 , blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 11 | WI-14506 | Block, height adjustment |
| 14 WI-48025 Height Adjustment Knob 16 WI-14508 Mounting Block, height adj 17 WI-70162 Screw 18 WI-70292 Shoulder Bolt 20 WI-87025 Washer 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-20063 Clamp 24 WI-39338 Hose, 1 1 gr x 45", blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 12 | WI-70417 | Adjustment Screw |
| 16 WI-14508 Mounting Block, height adj 17 WI-70162 Screw 18 WI-70292 Shoulder Bolt 20 WI-87025 Washer 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-2063 Clamp 24 WI-39338 Hose, 1 1 x x 45", blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 13 | WI-57022 | Nut |
| 17 WI-70162 Screw 18 WI-70292 Shoulder Bolt 20 WI-87025 Washer 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-20063 Clamp 24 WI-39338 Hose, 11er x 45', blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 14 | WI-48025 | Height Adjustment Knob |
| 18 WI-70292 Shoulder Bolt 20 WI-87025 Washer 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-20063 Clamp 24 WI-39338 Hose, 1 1 2 x 45 , blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 16 | WI-14508 | Mounting Block, height adj |
| 20 WI-87025 Washer 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-20063 Clamp 24 WI-39338 Hose, 1 1 x x 45", blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 17 | WI-70162 | Screw |
| 21 WI-70020 Screw 22 WI-57104 Nut 23 WI-20063 Clamp 24 WI-39338 Hose, 1 1 2 x 45 , blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 18 | WI-70292 | Shoulder Bolt |
| 22 WI-57104 Nut 23 WI-20063 Clamp 24 WI-39338 Hose, 1 1 x x 45", blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 20 | WI-87025 | Washer |
| 23 WI-20063 Clamp 24 WI-39338 Hose, 11er x 45", blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 21 | WI-70020 | Screw |
| 24 WI-39338 Hose, 1 or x 45', blue, vac 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 22 | WI-57104 | Nut |
| 25 WI-14042 Bushing 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 23 | WI-20063 | Clamp |
| 26 WI-70419 Screw 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 24 | WI-39338 | Hose, 112" x 45", blue, vac |
| 27 WI-34173 Frame 28 WI-14817 Bracket, vac shoe adjustment | 25 | WI-14042 | Bushing |
| 28 WI-14817 Bracket, vac shoe adjustment | 26 | WF70419 | Screw |
| | 27 | WF34173 | Frame |
| 29 WI-57047 Nut | 28 | WI-14817 | Bracket, vac shoe adjustment |
| | 29 | WI-57047 | Nut |

