


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Royal 7920 Owner's Manual

[Shop genuine replacement parts for Royal 7920](#)




Models: 692, 7920



[Find Your Royal Vacuum Cleaner Parts - Select From 772 Models](#)

----- Manual continues below -----

Models: 692, 7920



Models: 692, 7920

	NLA.....	Motor Unit Assy	77	R-008241	Rive
2	NLA.....	Carbon Brush Assy	78	R-074328	Hanc
3	R-003008	Spring, rear fork	79	R-259316	Hoo
4	R-670013	Screw, motor plate ret.	80A	R-670844	Cord
5	R-065028	Oiler Cap	81	R-028580	Hanc
6	R-672103	Brush Holder & Screw Assembly	89	R-692225	Revo
6A	R-380261	Drive Shaft	96	R-880262	Belt
7	R-618016	Screw, field retainer	97	R-003311	Wash
8	R-311031	Screw & Washer Assembly	98	R-004723	Hanc
9	R-608005	Fan, heavy duty	99	R-133714	Hanc
10	R-780002	Field, 120v	100	R-230713	Bolt,
11	R-618772	Spacer, baffle	101	R-285720	Wing
14	R-871101	Motor Housing Assembly	103	R-801708	Bolt,
15	R-801014	Set Screw, brush holder	104	R-801714	Nut,
16	R-801017	Baffle Plate	105	R-990104	Scre
17	R-801019	Brush Holder	106	R-183749	Side
18	R-801034	Brush Holder Protector Cap	107	R-006318	Lock
19	R-801701	Screw, rear bearing retainer	108	R-880707	Scre
	R-061905	Rear Wheel, Fork & Shaft Assy	109	R-360753	Scre
22	R-671705	Wheel, 2 1/2" diam.	110	R-080105	Scre
23	R-801711A	Wheel Retainer	110A	R-608153	Nut
24	R-028574	Rear Fork & Shaft Assembly	111	R-060265	Hea
	R-078007	Motor Plate & Armature Assy	112	R-145734	Scre
26	R-175053	Washer, oil slinger	113	R-606628	Hea
27	R-780001	Armature, 120v	114	R-880629	Hea
	NLA.....	Motor Plate & Bearing Assy	115	R-005138	Wash
29	R-880046	Tolerance Ring	116	R-023309	Scre
30	R-880026	Ball Bearing	118	R-2854270	Gash
31	R-884003	Motor Plate	119	NLA	Whe
32	R-080126	Rear Bearing Assembly	120	R-671705	Whe
33	R-381026	Nozzle Assembly	121	R-672260	Belt
41	R-330329	Rivet, spring clip	122	R-692270	Nozz
42	R-606210	Headlight Spring Clip	123	R-080169	Adju
43	R-062010	Fancase Assembly	124	R-770040	Bag
	R-067030	Handle & Cord Assembly, 50ft	125	NLA	Bag
48	R-230324	Grommet	125A	R-770040	Bag
49	R-003311	Washer, adaptor clamp screw	125B	NLA	Bag
50	R-023311	Lockwasher	126	R-3067247	Pape
51	R-880707	Screw, switch plate	126	R-671075	Pape
52	R-801710	Wingnut, small	126	R-66247	Pape
53	R-801712	Screw, adaptor clamp	126	745	Pape
	R-060831	Switch & Cord Assembly, 50 ft	127	R-110773	Inser
55	NLA.....	Cord & Plug Assembly, 50 ft	128	R-259761	Wire
57	R-259761	Wire Connector	129	R-980743	Scre
59	NLA.....	Cord Protecting Sleeve			