


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# Royal 886 Owner's Manual

[Shop genuine replacement parts for Royal 886](#)



Models: 886



[Find Your Royal Vacuum Cleaner Parts - Select From 772 Models](#)

----- Manual continues below -----

Models: 886



## Model: 886

	NLA	Motor Unit Assy			
2	NLA	Carbon Brush Assy		63	R-259761 Wire
3	R-003008	Spring, rear fork		64	NLA Sleeve
4	R-670013	Screw, motor plate ret.		65	R-322305 Strap
5	NLA	Oiler Cap		66	NLA Short
6	R-672103	Brush Holder & Screw Assembly		67	R-880305 Strain
7	R-311031	Screw & Washer Assembly		68	R-028537 Switch
7A	NLA	Drive Shaft		72	R-249303 Switch
8	R-618016	Screw, field retainer		76	R-004723 Spring
9	R-608005	Fan, heavy duty		77	R-133714 Hand
10	R-618772	Spacer, baffle		79	R-801708 Bolt,
11	R-618002	Field, 120V		80	R-801714 Nut,
	R-871101	Motor Housing Assembly		81	R-990104 Scre
13	NLA	Set Screw, brush holder		82	R-028590 Hand
14	NLA	Baffle Plate		88	R-003311 Wash
15	NLA	Brush Holder		89	R-005138 Wash
16	R-801034	Brush Holder Protector Cap		90	R-023309 Scre
17	R-801701	Screw, rear bearing retainer		91	R-230713 Carri
	R-061805	Rear Wheel, Fork & Shaft Assy		92	R-2854270 Gask
20	R-671705	Wheel, 2 1/2" diameter		93	R-285720 Wing
21	R-801711A	Wheel Retainer		96	R-671705 Wide
22	R-028574	Rear Fork & Shaft Assembly		97	R-801711A Whe
23	R-080126	Rear Bearing Assembly		99	R-880629 Head
	R-068007	Motor Plate & Armature Assy		100	R-880707 Scre
25	R-175053	Washer, oil slinger		101	R-980743 Scre
26	R-680001	Armature, 120V		102	NLA Nozz
	NLA	Motor Plate & Bearing Assy		102A	NLA Sprin
28	R-880046	Tolerance Ring		103	NLA Head
29	R-880026	Ball Bearing		105	R-672260 Belt
30	NLA	Motor Plate		106	R-183749 Side
31	R-080226	Nozzle Assembly		107	R-360753 Scre
38	R-060810	Fancase Assembly		108	R-259762 Conr
	R-099430A	Handle & Cord Assembly		109	R-672270 Nozz
42A	R-230324	Grommet		110	R-673273 Brush
43	R-003311	Lockwasher, adaptor clamp screw		110	R-180273 Brush
44	R-023311	Lockwasher		119	R-088169 Adjus
45	R-801710	Wingnut, small		121	R-880262 Belt
46	R-801712	Screw, adaptor clamp		122	R-90843C Bag
47	R-801701	Screw, switch plate		123	R-3067247 Pape
48	R-065534	Handle Adaptor Assembly		123	R-088147 Pape
52A	R-670844	Cord Clip		123	R-671075 Pape
53	R-088732A	Upper Handle Assy		123	R-66247 Pape
54	R-003884	Spring		123	745 Pape
56	R-259318	Cord Hook, upper		124	R-110773 Inser
57	R-597743	Screw			
58	R-000000	Handle Adaptor Assembly			