


PANASONIC V7348 Owner's Manual

Shop genuine replacement parts for PANASONIC V7348




Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models

----- Manual continues below -----


PANASONIC

Models: MC-V7348, MC-V5257



PANASONIC

Models: MC-V7348, MC-V5257



V

Models: MC-V7348, MC-V5257

1 P-10836 Dust Compartment Unit	25 P-10825 Packing, motor case, V5257
1 P-10880 Dust Compartment Unit, V5257	26 P-6140 Screw, motor case
2 P-8913 On-Off Switch	26 P-8172 Screw, motor case, V5257
3 P-0698 Cord Stopper	27 P-10405 Motor Assy
4 P-6140 Screw, cord stopper	27 P-10882 Motor Assy, V5257
5 P-10802 Power Cord	28 P-8182 Carbon Brush, pair
6 P-000623 Wire Connector	29 P-9823 Screw, carbon brush
7 P-660106 Packing, dust container	30 P-10670 Noise Suppressor
8 P-30606 Switch Cover	31 P-0293 Motor Support, front
9 P-73006 Packing, switch cover	32 P-9911 Motor Support Rubber, rear
10 P-6140 Screw, switch cover	33 P-3820 Wire Cord
11 P-7301 Handle Screw	34 P-000623 Wire Nut, 10pk
12 P-2117 Nut, handle screw	35 P-9835 Handle
13 P-3200 Filter Supporter	36 P-9836 Upper Cord Storage Hook
14 P-9994 Secondary Filter, HEPA	36 P-53007 Upper Cord Storage Hook,
14 P-9829 Secondary Filter, HEPA, V5257	V5257
15 P-0114 Wheel	37 P-9837 Hose Holder
16 P-16005 Shaft, wheel	38 P-7670 Spring, cord hook
17 P-74009 Stopper, wheel	39 P-587 Washer, cord storage hook
18 P-6115 Washer	40 P-9838 Lower Cord Storage Hook
19 P-145M Paper Bag, U6, micro, 3pk	40 P-53007 Lower Cord Storage Hook,
20 P-10340 Hose Hook	V5257
21 P-8972 Cover, suction inlet	41 P-43096 Screw, cord storage hook
22 P-6140 Screw	42 P-10838 Dust Cover
23 P-10837 Motor Case	42 P-10883 Dust Cover, V5257
23 P-10881 Motor Case, V5257	43 P-8946 Hose
24 P-201 Packing, rear	44 P-6088 Dusting Brush
24 P-10916 Packing, rear, V5257	45 P-6069 Crevice Tool
25 P-1906 Packing, motor case	45 P-10805 Crevice Tool, V5257
(Z)	

46 .. P-107 46 .. P-108 47 .. P-610 48 .. P-106 48 .. P-399 49 .. P-106 49 .. P-586 50 .. P-000 51 .. P-104 51 .. P-108 52 .. P-981 53 .. P-000 54 .. P-930 55 .. P-410 56 .. P-818 57 .. P-107 58 .. P-106 58 .. P-108 59 .. P-601 60 .. P-001 61 .. P-106 62 .. P-108

63 .. P-996

P-601 P-108 P-614

Agitator Assembly

