


This Owner's Manual is provided and hosted by Appliance Factory Parts.



PANASONIC 2730 Owner's Manual

[Shop genuine replacement parts for PANASONIC 2730](#)

Main Unit



[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

PANASONIC

Models: MC-2730, MC-2750

Main Unit

- | | | |
|-----|----------|------------------------|
| 1 | P-957 | Caster Unit |
| 2 | P-03700 | Body, lower |
| 3 | P-03710 | Cover, switch |
| 3A | P-517 | Supporter Plate |
| 4 | P-297 | Blower Outlet |
| 5 | P-01 | Wheel |
| 6 | P-6470 | Packing, air intake |
| 7 | P-227 | Bag Clamper |
| 8 | P-3770 | Filter, secondary |
| 9 | P-327 | Supporter, filter |
| 10 | P-387 | Exhaust Filter |
| 11 | P-96001 | Body Partition Unit |
| 11A | P-98001 | Switch Unit, main body |
| 12 | P-98002 | Power Cord / Rail Base |
| 12A | P-01300 | Cord Reel Only |
| 13 | P-99001 | Cord Reel Assembly |
| 14 | P-150PF | Paper Bag |
| 15 | P-027000 | Motor Supporter, front |
| 16 | P-9262 | Motor |
| 17 | P-276 | Carbon Brush </td |
| 18 | P-997 | Noise Suppressor Unit |
| 18A | P-187 | Noise Suppressor |
| 19 | P-039 | Motor Supporter, rear |
| 20 | P-667 | Packing, dust cover |
| 21 | P-60700 | Dust Cover |
| 22 | P-9970 | Indicator Unit |

