


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



KITCHENAID KBNS361TSS0 Owner's Manual


[Shop genuine replacement parts for KITCHENAID
KBNS361TSS0](#)



[Find Your KITCHENAID Grill Parts - Select From 200 Models](#)

----- Manual continues below -----

For Models: KBNS361TSS00, KBSS361TSS00
(Stainless Steel) (STLS w/Jacket)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GRILL PARTS


For Models: KBNS361TSS00, KBSS361TSS00
(Stainless Steel) (STLS w/Jacket)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	18	W10132690	Cover, Wire Terminal	38	W10132701	Flange (RT)
	W10110724	Use & Care Guide			Bushing	39	W10132697	Bracket, Flange
	W10110730	Conversion Instr. (LP to Natural)	19	W10132691	Plastic (#SB22)	40	W10128777	Thermometer
2	W10128619	Cover, Rear		W10132692	Plastic (#SB19)	41	W10128779	Bezel, Thermometer
3	W10133863	Panel, Rear	20	W10133869	Outlet,Transformer	42	W10128780	Insulator, Thermometer(Small)
4	W10133867	Panel, Access	21	W10133876	Harness, Wire Light	43	W10128782	Insulator, Thermometer(Large)
5	W10128634	Bracket, Panel Left	22	W10128664	Cover, Igniter	44	W10133877	Handle, Hood
6	W10128635	Bracket, Panel Right	23	W10281246	Igniter	45	W10128785	Endcap, Handle (Left)
7	W10128636	Bracket, Warming Rack	24	W10128751	Nameplate	46	W10128786	Spacer, Handle
8	W10128637	Cover, Access Panel	25	W10128753	Knob, Main Burner	47	W10128787	Endcap, Handle (Right)
9	W10128638	Clip, Wire	26	W10128756	Knob, Rear Burner	48	W10128788	Hinge, Lid
10	W10133868	Hood Assy	27	W10128759	Bezel, Knob	49	W10133878	Hood
11	W10128640	Hole Plug	28	W10128761	Switch, Light	50	W10128715	Box, Battery
12	W10132699	Panel, Side Left	29	W10136433	Panel, Control	51	W10128711	Cover, Battery Box
13	W10128644	Bracket, Grease Tray (Right)	30	W10128763	Harness, Wire Control	52	W10132698	Washer
14	W10128655	Roller, Drip Tray	31	W10128764	Valve, Main Brnr	53	W10132696	Flange (LF)
15	W10133870	Drip Tray Assy (Includes Rollers)	32	W10128766	Valve, Rear Brnr	54	W10132694	Brkt,Trnsfrmr(Top)
16	W10128657	Bracket, Grease Tray (Left)	33	W10128767	Igniter, Main Gas	55	W10132695	Brkt,Trnsfrmr(Btm)
17	W10128669	Transformer	34	W10133871	Manifold	56	W10132702	Regulator (NG)
			35	W10133873	Baffle, Front	57	W10128747	Fixture,Manifold
			36		Electrode	58	W10128748	Connector (Brass)
				W10128770	Main Burner	59	W10128749	Base, Manifold
				W10133874	Main Burner			Fixture
				W10133875	Main Burner			
			37	W10132700	Side Panel, Right			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNERS, GRATES, AND LIGHTS PARTS

For Models: KBNS361TSS00, KBSS361TSS00
(Stainless Steel) (STLS w/Jacket)



Illus. No.	Part No.	DESCRIPTION
1	W10133859	Rack, Warming
2	W10133860	Rack, Large
3	W10133862	Rack, Small
4	W10128618	Plate, Sear
5	W10128621	Electrode, Rear
6	W10128622	Thermocouple, Rear Burner
7	W10128623	Flex Tube, Rear Burner
8	W10133864	Burner, Rear
9	W10128625	Bracket, Rear Thermocouple
10	W10128626	Cover, Rear Thermocouple
11	W10128627	Orifice, Rear Burner
12	W10128628	Light, Grill
13	W10133866	Light, Grill(Set)
14	W10133865	Socket, Light
15	W10128704	Rod, Lighting
16	W10128703	Bag, Lighting Rod
17	W10128775	Burner, Main
18	W10128776	Bracket, Main Brnr

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KBNS361TSS00, KBSS361TSS00
(Stainless Steel) (STLS w/Jacket)

Illus.	Part	
No.	No.	DESCRIPTION

Miscellaneous

4396540	Altitude 2K-5K LP
4396541	Altitude 5K-8K LP
4396542	Altitude 8K-10K LP
4396544	Altitude 2K-5K NG
4396545	Altitude 5K-8K NG
4396546	Altitude 8K-10K NG
W10118099	Conv.Kit (NG-LP)
W10118098	Conv.Kit(LP-NG)
KBDU271TSS	Smoker Box
KFKU361TSS	36" Rotiss. Kit
W10136977	36" Insulated Jacket

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST