


KITCHENAID KHM720ACS0 Owner's Manual

Shop genuine replacement parts for KITCHENAID KHM720ACS0



Find Your KITCHENAID Mixer Parts - Select From 532 Models

----- Manual continues below ------

PARTS LIST

for



7-SPEED HAND MIXER ARCHITECT SERIES

MODELS

KHM720ACS0 (Cocoa Silver) KHM720ACA0 (Candy Apple) KHM720AWH0 (White) KHM720AER0 (Empire Red)



FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS





Whirlpool corporation

Benton Harbor, Michigan.

UNIT PARTS

Variations of Models: KHM720A_0





Illus No.	. Part No.	DESCRIPTION
1		Literature
	W10250601	Use & Care Guide
	W10276064	Repair Parts List
2	•	Mixer, Complete
3	W10240913	Beaters, Turbo
		(Incl. Rt & Lt)

♦ NOTE:

Parts not sold separately. Must be purchased as a complete unit.

OPTIONAL PARTS NOT ILLUSTRATED

W10275837 Hooks, Dough (Incl. Rt & Lt) 8212341 Rod, Blending 8212340 Whisk