

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# Bissell 3130 Owner's Manual

[Shop genuine replacement parts for Bissell 3130](#)




[Find Your Bissell Vacuum Cleaner Parts - Select From 376 Models](#)

----- Manual continues below -----



Easy Vac Series

Models 3120, 3130, 31305, 31306



**Easy Vac Series**

Models 3130, 3120, 31305, 31306

KEY	PART NO	DESCRIPTION	KEY	PART NO	DESCRIPTION
xx	B-203-7034	Drive Belt			
xx	B-010-0292	User's Guide			
1	B-203-7047	Looped Handle - Marina Blue			
2	B-203-7020	Stretch Hose			
3	B-203-7033	Upholstery Brush			
4	B-203-7046	Foot Hose			
5	B-203-7024	Primary Separator w/Gasket - Marina Blue			
6	B-203-7021	Easy Empty Dirt Cup			
7	B-203-7023	Inner and Outer Circular Filters			
8	B-203-7022	Lower Tank			
9	B-203-7032	Crevice Tool			
11	B-203-7035	Quick Release/Upper Cord Wrap			
12	B-203-7045	Internal Power Switch			
13	B-203-7037	Rear Wheel			
14	B-203-7042	Left/Right Pivot Clamp			
15	B-203-7043	Detent Lever			
16	B-203-7044	Power Switch Pedal			
17	B-203-7029	Floor Brush			
18	B-203-7028	Nozzle Grd. w/Sqege & Frt. Whls			
19	B-203-7039	Motor			
20	B-203-7030	Roller Lifter Assy.			
21	B-203-7031	Pre-Motor Filter			