

PARTS LIST

for

KitchenAid®

ARTISAN 4-SLICE TOASTER

INTERNATIONAL MODELS:

5KTT890APM1 (Pearl Metallic – Australia)

5KTT890ABU1 (Cobalt Blue – Australia)

5KTT890EPM1 (Pearl Metallic – Europe)

5KTT890EBU1 (Cobalt Blue – Europe)




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



HOUSING PARTS

For Models: 5KTT890__1



Literature Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

HOUSING PARTS

For Models: 5KTT890__1

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8204568	Guide, Use & Care
	8212169	Repair Parts List
2	4176839	Knob, Darkness
3	4176819	Support
4	4176831	Screw
5	4176813	Wrap Assembly (Includes Items 2 & 10)
6	4176814	Tray, Crumb
7		Bridge, Rear
	4176824	Pearl Metallic
	4176827	Cobalt Blue
8		Bridge, Front
	4176820	Pearl Metallic
	4176823	Cobalt Blue
9	4176832	Arm, Lifter
10	4176838	Knob, On/Off
11	4176837	Foot, Rubber
12		Chassis (Includes Power Cord, Base, Control Boards, & Heating Elements)
	4176809	Europe
	4176811	Australia
13	4176829	Screw, Grounding
14	4176830	Lock Washer
15	4176828	Screw, Wrap
16	4176840	Wire, Ground
17		Panel Assembly (Includes Badge & Vent)
	4176833	Pearl Metallic
	4176836	Cobalt Blue

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST