

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



KITCHENAID 4KFPW760WH1 Owner's Manual

[Shop genuine replacement parts for KITCHENAID
4KFPW760WH1](#)

KitchenAid®

[Find Your KITCHENAID Small Appliance Parts - Select From 538 Models](#)

----- Manual continues below -----

PARTS LIST

for

KitchenAid®

FOOD PROCESSOR

12 CUP – WIDE MOUTH

MODELS:

KFPW760WH1 (White)
KFPW760OB1 (Onyx Black)
KFPW760ER1 (Empire Red)
KFPW760QWH1 (White)
KFPW760QOB1 (Onyx Black)
KFPW760QER1 (Empire Red)
KFPW760QBU1 (Cobalt Blue)
KFPW760QBW1 (Blue Willow)
KFPW760QGC1 (Gloss Cinnamon)
4KFPW760WH1 (White)
4KFPW760OB1 (Onyx Black)




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



MOTOR AND HOUSING PARTS

For Models: KFPW760__1, 4KFPW760__1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND HOUSING PARTS


For Models: KFPW760__1, 4KFPW760__1

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8211864	Use & Care Guide
	8212142	Repair Parts List
2	8211849	Sleeve, Motor
		Shaft
3	8211828	Seal, Oil
4		Housing, Motor
	8212184	White
	8212238	Onyx Black
	8212236	Empire Red
	8212237	Cobalt Blue
	8212284	Blue Willow
	8212285	Gloss Cinnamon
5	8211610	Clamp, Cable
6	8211731	Screw, Clamp
7	8212186	Motor, Sheet Metal
8	8212188	Grommet, Motor
9		Base, Housing
	8212183	White
	8212190	Onyx Black
	8212187	Empire Red
	8212189	Cobalt Blue
	8212282	Blue Willow
	8212283	Gloss Cinnamon
10		Cover, Screw
	8212185	White
	8212193	Onyx Black
	8212191	Red
	8212192	Blue
	8212286	Blue Willow
	8212287	Gloss Cinnamon
11	8211829	Screw, Motor
		Locking
12	8211848	Bezel, Switch
		Panel
13	8211607	Clip, Capacitor
14		Overlay, Switch
		Assembly
	8211847	Silver
15	8211605	Terminal Block
16	8211852	Cover, Terminal
17	8211842	Nameplate
18	8211608	Capacitor
19	8212011	Relay & Switch
		Assembly
20		Foot
	8211844	White
	8211845	Black
21		Cord, Power
	8211855	Black
	8211856	White

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ATTACHMENT PARTS

For Models: KFPW760__1, 4KFPW760__1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ATTACHMENT PARTS

For Models: KFPW760__1, 4KFPW760__1

Illus. No.	Part No.	DESCRIPTION
1	8211760	Spatula
2		Disc, Slicing
	8211929	2 mm
	8211930	4 mm
3	8212012	Blade, Mini
4	8211858	Adapter, Shaft & Disc
5	8212014	Blade, Multipurpose
6	8212020	Pusher, Double
7		Cover, Work Bowl
	8212242	White
	8212243	Onyx Black
	8212245	Empire Red
	8212244	Cobalt Blue
	8212407	Blue Willow
	8212408	Gloss Cinnamon
8		Bowl, Work
	8212246	White
	8212249	Onyx Black
	8212247	Empire Red
	8212248	Cobalt Blue
	8212288	Blue Willow
	8212289	Gloss Cinnamon
9		Disc, Shredding
	8211933	4 mm
10	8211926	Bowl, Mini
11	8212016	Blade, Dough
12	8211928	Bowl, Chef's
13	8212025	Extractor, Citrus
14	8212033	Whip, Egg-12 cup

OPTIONAL PARTS NOT ILLUSTRATED

8212034	Accessory Box
8211927	Lid, Mini Bowl
	Disc, Slicing
8211931	6 mm
	Disc, Shredding
8211932	2 mm
8211934	6 mm
8211935	Disc, Julienne
8211936	Disc, Grating Parmesan/Ice
8211937	Disc, Cutting French Fry
8211938	Rack, Disc

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST