

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).





Bissell 21K3 Owner's Manual

[Shop genuine replacement parts for Bissell 21K3](#)



[Find Your Bissell Vacuum Cleaner Parts - Select From 376 Models](#)

----- Manual continues below -----



Cleanview Helix

82H1 22C1 21K3 Series

KEY	PART NO	DESCRIPTION
1	B-203-2400	Upper Handle Assembly w/ Turbobrush Holder - Black
1	B-203-2451	Upper Handle Assembly w/ Turbobrush Holder - Intuitive
1	B-203-2452	Upper Handle Assembly w/ Turbobrush Holder - Dangerously Elegant
1	B-203-2471	Upper Handle Assembly w/ Turbobrush Holder - Seawater Blue
3	B-203-1180	Cyclone Assembly
4	B-203-2453	Dirt Cup - Clear
5	B-203-1192	Foam Filter
6	B-203-1464	Pleated Circular Filter
7	B-203-2454	Filter Case
8	B-203-1215	Lever Filter
9	B-203-2455	Lock n' Seal Lever
10	B-203-1198	Cord Release
11	B-203-1495	Power Cord
12	B-203-1035	Switch- Rocker
13	B-32076	Post Motor Filter HEPA
14	B-203-2456	Post Motor Filter Grille
16	B-203-1297	Light Bulb - 12 Volt
19	B-203-2211	Vacuum Motor, Compact
22	B-203-2457	Case Drum Assembly - 13.5" - 82H1
22	B-203-2458	Case Drum Assembly - 15" w/o Window - 22C1
22	B-203-2459	Case Drum Assembly - 15" w/ Window - 21K3
24	B-203-2460	Axle
25	B-203-2461	Rear Wheel
28	B-203-2462	Neck Brush - L&R
29	B-203-2463	Lever Release
30	B-203-2464	Roller Assembly w/Axle
31	B-203-2465	Height Adjustment Knob
33	B-203-2448	Brush - 13.5"
33	B-203-2449	Brush - 15"
34	B-203-2466	Access Plate - 13.5"
34	B-203-2467	Access Plate - 15"
35	B-203-1093	Belt
36	B-203-2450	Hose Assembly
37	B-203-1084	Extension Wand
38	B-203-1063	Crevice Tool
39	B-203-1099	Dust Brush Combo Tool
40	B-203-2447	Turbobrush - Grey
XX	2031003	Screw - Handle/Hose Cuff
XX	1104080	User's Guide

82H1 = Black
22C1 = Intuitive Purple
22C1-2 = Seawater Blue
21K3 = Dangerously Elegant