

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Bissell 2050 Owner's Manual

[Shop genuine replacement parts for Bissell 2050](#)



[Find Your Bissell Vacuum Cleaner Parts - Select From 376 Models](#)

----- Manual continues below -----

Group Name:

Deep Cleaners

Category:

Upright Deep Cleaners

Model No. :

2050

Model Desc:

QUICKSTEAMER POWERBRUSH

Key	Part No.	Part Desc.
01	6032010	Handle Assy w/ Grip
02	2041107	Quick Cord Wrap Cap
03	2041104	Handle - RT Side
04	2041103	Trigger
05	2041108	Handle - LT Side
06	2041106	Push Rod - Upper
07	2041127	Tubing
08	2041102	Handle, Lower Front
09	6032008	Dirty Water Tank
09	6032009	Clean Water Tank Assy
10	2041124	Exhaust Vent Panel w/ Filter
11	2041109	Handle, Lower Back
12	2041128	On/Off Switch
13	2041110	Push Rod - Lower
14	2041126	Receiver Assy
15	2041125	Rear Cover
16	2041123	MOTOR ASSY
17	6032009	Clean Water Tank Assy
18	2041111	Cap & Insert Assy
19	2041112	Formula Measuring Cup
20	2041113	Motor Cover
21	2041114	Detent Lever
22	0106357	GASKET MOTOR REAR 1950 RBO
25	6037825	MOTOR OUTLET GASKE REPL
26	2041122	Motor Intake Gasket
27	2041117	Base Assy w/ Brush Motor
28	2041116	Tank Latches - (2-pack)
29	2041121	Wheel
30	6032007	Brush Belt
31	2041131	Brush Cover
32	2041130	Brush Sup Bushing RT/LT
34	2041120	Front Nozzle Assy
35	2041118	Spray Bar
36	2041115	Metal Detent Dowel
37	6032006	Brush Assy
xx	2041129	Power Cord
xx	2106209	

