



Canister - 8281D



55850-29 TOOL PAK ASSY.
65918-2 B-SHELL GASKET



EACH 1 WIRE & TERMINAL
55951-3 WIRE & TERMINAL

55540-12 LOWER SHELL ASSY.
65919-1 SHELL GASKET
37483 HEAT SHIELD
37403 LATCH PIN




Canister - 8261D


Ref #	Part	Description	Comments	Qty
1	14656-3	CORD REEL ASSY		
2	26440-16	Discontinued, use 26440-25		
3	26442B-8	BUTTON - CORD REEL USE		
4	26443A-8	Discontinued, use 26443A-11		
5	26450-1	GUIDE-CORD		
6	26651-6	CONNECTOR ASY (26651-1)		
7	26663-3	HANDLE - LOWER		
8	26341-2	SWITCH PUSH		
9	37402	EXHAUST FILTER		
10	37403-1	CASTER		
11	37408	SOUND FOAM		
12	37483	HEAT SHIELD		
13	37788	MOTOR FILTER		
14	42797	SPRING - CARPET NOZZLE		
15	52358	PAPER BAG PKG ASSY (STYLE		
16	53141	TIE - CABLE (PURCHASED)		
17	53197-1	SCREWS-PKG 10 (55372-1)		
18	53214-2	Discontinued, use 60192-1		
19	53214-3	WIRE SPLICE 5		
20	53238-11	SCREW PKG (EW312-1018)		
21	53238-22	SCREW PACKAGE		
22	54274-1	TOOL PAK COVER (13890-1)		
23	54292	MOTOR ASSY - CTND		
24	55446	NUT - SWITCH (155437)		
25	55463	GASKET - MOTOR STACK		
26	55919-1	SHELL GASKET use 58853-1		
27	55919-2	SHELL GASKET (NLA)		
28	55940-1	CLIP-FURN GUARD (NLA)		
29	56235-10	EXHAUST COVER (56235- (NLA)		
30	56250	MOTOR CLIP (NLA)		
31	56376	WASHER		
32	57691-1	WIRE & TERMINAL ASSY (NLA)		
33	57691-2	WIRE & TERMINAL ASSY		
	57697	FILTERAIRE C BAGS (NLA)		
35	57720	THERMOSTAT		

Powerhead - 8281D

5770-1 AIR DUCT COVER ASSY.
5568 FELT GASKET



5622-1 DISTURBULATOR COVER ASS'Y.
55971 FELT GASKET
55970 FOAM STRIP




5404-1 POWERHEAD BASE ASS'Y. (INCLUDES)
54824 WHEEL & SLEEVE ASS'Y. (2)
54486 AXLE (2)
55070 FELT GASKET (2)
55688 FELT GASKET
55971 FELT GASKET



54419-1 COMPLETE DISTURBULATOR ASSEMBLY

Powerhead - 8281D

Ref #	Part	Description	Comments	Qty
1	26470	CAP-DISTURB		
2	37434-6	DEJA BLUE (EASY FLO)		
3	37441	DISTURB CAP		
4	37755-1	CORD & SPRING ASSY		
5	38156	STRAP - MOTOR		
6	38177	SHIELD - MOTOR (NLA)		
7	38259	SKT HEADLAMP (155453)		
8	40009A	LAMP - HEADLIGHT		
9	49899	WASHER - FELT (155316)		
10	52201A	BELT PACKAGE ASSY - STYLE		
11	53158	LOCKNUTS-PKG 10 (49175)		
12	53190-1	BUSHING-PKG 10 (155318)		
13	53214-2	Discontinued, use 60192-1		
14	53238-18	SCREW PKG(PKG 10) 53238-25		
15	53238-8	SCREW PKG (15543)(EW312-8 8Z)		
16	54016-34	POWERHEAD HOOD ASSY - PAC		
17	54341-1	KIT - POWER HEAD BASE ASS		
18	54343-1	PH MOTOR ASSY (155506)		
19	54419-1	DISTURB ASY (155402W)		
20	55968	GASKET - FELT		
21	55969	GASKET-FELT		
22	55970	GASKET - FELT		
23	55971	GASKET - FELT		
24	55979	SPRING STRAP (155428)		
25	55980	STRAP use 55980-1		
26	56180	FELT WASHER (155416)		
27	56232-1	DISTURB COVER AS (01561-1		
28	56489	AXLE (155414)		
29	56824	WHEEL		
30	56830-2	HANDLE SOCKET ASSY (NLA)		
31	57421-1	WIRE & TERMINAL ASY		
32	57710-1	AIR DUCT COVER A (14754- (NLA)		




53499-8 HOSE ASSEMBLY COMPLETE

Hose - 8281D

Ref #	Part	Description	Comments	Qty
1	37774-1	SW & CONNECTOR ASSY		
2	37789-9	Discontinued, use 37789-119N		
3	38124-9	Discontinued, use 38124-8		
4	53257-1	SCREWS-PKG-10 (605-507)		
5	53499-8	HOSE ASSEMBLY - CARTONED		
6	53543-1	HOSE ASSY WITHOUT HANDLE		
7	54009-5	HANDLE ASSY 2 WIRE (PACKA		



37738-1 UPPER WAND ASS'Y.



37737 LOWER WAND ASS'Y.



**53455-4 DUSTING BRUSH
33787 INSERT**



53440-3 GREVICE TOOL



**53454-6 UPHOLSTERY NOZZLE
46186 INSERT**



**54308-6 FLOOR & WALL BRUSH
25878-3 ELBOW
33405 BRISTLE STRIP
36877 INSERT
36878 INSERT**

Accessories - 8281D

Ref #	Part	Description	Comments	Qty
1	25878-3	Discontinued, use 38401-1		
2	33405	BR STRIP-FL & WALL BRUSH		
3	33787	INSERT - RINGLOCK BRUSH (NLA)		
4	36877	INSERT-FLOOR & WALL BRUSH		
5	36878	INSERT-FLOOR & WALL BRUSH		
6	37737	WAND-LOWER		
7	37738-1	UPPER WAND ASSEMBLY		
8	46186	BRUSH (NLA)		
9	53440-3	TOOL - CREVICE		
10	53454-6	UPHOLSTERY NOZZLE ASSY -		
11	53455-4	DUSTING BRUSH - PACKAGED		
12	54309-6	FLOOR & WL BRUSH & ELBOW-		