


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



COMFORT-AIRE H6HK020H-21 Owner's Manual


[Shop genuine replacement parts for COMFORT-AIRE
H6HK020H-21](#)



[Find Your COMFORT-AIRE HVAC Parts - Select From 1486 Models](#)

----- Manual continues below -----

H6HK Series Electric Heater Kit



IMPORTANT

- This document is primarily intended to assist qualified individuals experienced in the proper repair or servicing of this appliance. Only factory authorized parts or accessory kits may be used with this product. Improper installation, service, adjustment, or maintenance may cause explosion, fire, electrical shock or other hazardous conditions which may result in personal injury or property damage.
- Some local codes require licensed installation / service personnel to service this type of equipment. Under no circumstances should the equipment owner attempt to install parts or service this equipment. Failure to comply with this warning could result in property damage, personal injury, or death.

H6HK REPLACEMENT PARTS LIST

COMPONENT DESCRIPTION	005H-01	005H-11	008H-01	008H-11	009Q-11	010H-01	010H-11
Set of Wires	288351R	288351R	288361R	288361R	291531R	288361R	288361R
Harness, Low Voltage	2C3351	2C3351	2C3361	2C3361	2C3351	2C3361	2C3361
Element Assy	491214R	491214R	491226R	491226R	491216R 491227R	491225R	491225R
Relay	622210	622210	622210	622210	622210	622210	622210
Limit Switch	626487	626487	626458	626458	626458	626458	626458
Terminal Block	631762	—	631762	—	—	631762	—
Line Cover	257442	257442	257442	257442	257442	257442	257442
Bracket, Circuit Breaker	284861	284861	284861	284861	284861	284861	284861
Circuit Breaker	—	632249	—	632249	632225	—	632249
Harness, 2 Pin Power	288861R	288861R	288861R	288861R	—	288861R	288861R
Harness, 3 Pin	—	—	—	—	—	—	—
Bracket, Circuit Board	—	—	—	—	—	—	—
Circuit Board	—	—	—	—	—	—	—
Contactors	—	—	—	—	621888	—	—
Relay Bracket	288621	288621	288621	288621	288621	288621	288621
Cover Plate, Limit hole	—	—	—	—	292211	—	—

COMPONENT DESCRIPTION	015H-21	015Q-11	020H-21	024H-31	025H-31	029H-31	030H-31
Set of Wires	288371R	291531R	288381R	M0076201R	289011R	M0076202R	288391R
Harness, Low Voltage	2C3371	2C3351	2C3381	2C3441	634668	2C3451	634668
Element Assy	491214R 491225R	491214R 491225R	491225R	491214R 491225R	491214R 491225R	491225R	491225R
Relay	622210	622210	622210	622210	622210	622210	622210
Limit Switch	626458 626487	626458	626458	626458 626487	626458 626487	626458	626458
Terminal Block	—	—	—	—	—	—	—
Line Cover	257442	257442	257442	257443	257443	257443	257443
Bracket, Circuit Breaker	284861	284861	284861	284862	284862	284862	284862
Circuit Breaker	632249	632225	632249	632249	632249	632249	632249
Harness, 2 Pin Power	288861R	—	288861R	288861R	288861R	288861R	288861R
Harness, 3 Pin	—	—	—	—	634670	—	634671
Bracket, Circuit Board	—	—	—	—	289841	—	289841
Circuit Board	—	—	—	—	624664	—	624664
Contactors	—	621888	—	—	—	—	—
Relay Bracket	288621	288621	288621	288621	288621	288621	288621
Cover Plate, Limit hole	—	292211	—	—	—	—	—

Table 4. Replacement Parts for H6HK Heater Kits

NORDYNE
COMPLETE COMFORT. GENUINE VALUE.

Specifications & illustrations subject to change without notice or incurring obligations.
O' Fallon, MO | Printed in U.S.A. (05/13)



709543A (Replaces 7095430)