


This Owner's Manual is provided and hosted by Appliance Factory Parts.





COMFORT-AIRE HAG36-00-1A Owner's Manual

[Shop genuine replacement parts for COMFORT-AIRE
HAG36-00-1A](#)





[Find Your COMFORT-AIRE HVAC Parts - Select From 1486 Models](#)

----- Manual continues below -----



MODEL	DESCRIPTION	BLOWER ASSEMBLY	A BLOWER PLATE	B CAPACITOR	C MOTOR	D WHEEL
AHG24-04	H41-46-26AA2BCCC1X/	BRA46-40/41	R87AP0002	R68DE0008	R65BP0015	R69AC0001
AHG30-0A	H41-37-39AA2BCCC1X/	BRA37-40/41	R87AP0004	R68DE0008	R65BP0013	R69AC0002
AHG36-0A	H15-49-50AA2BCCC1X/	BRA49-14/15	R87AC0003	R68DE0008	R65BP0013	R69AB0001
HAG24-00-1A	S41-45-00-C1BACP1X/	BRA45-40/41	R87AP0002	R68DE0006	R65BP0016	R69AC0001
HAG36-00-1A	S41-34-00-C1BACP1X/	BRA34-40/41	R87AP0004	R68DE0006	R65BP0014	R69AC0002
HAG48-00-1A	S15-55-00-C1BACP1X/	BRA55-14/15	R87AC0003	R68DE0006	R65BP0014	R69AB0001



MODEL	DESCRIPTION	BLOWER ASSEMBLY	A BLOWER PLATE	B CAPACITOR	C MOTOR	D WHEEL	E MOTOR BAND	F ARM GROMET
AHG48-0A	H15-52-67AA2BCCC1X/	BRA52-14/15	R87AC0005	R68DE0009	R65BP0007	R69AC0003	R66AB0058	R66AB0059
AHG60-0A	H15-53-80AA2BCCC1X/	R86HM1153	R87AC0001	R68DE0009	R65BP0007	R69AC0005	R66AB0058	R66AB0059
HAG60-00-1A	S15-51-00-C1BACP1X/	BRA51-14/15	R87AC0005	R68DE0009	R65BP0006	R69AC0003	R66AB0058	R66AB0059