


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



VIKING DUAR150 Owner's Manual

[Shop genuine replacement parts for VIKING DUAR150](#)




[Find Your VIKING Refrigerator Parts - Select From 341 Models](#)


----- Manual continues below -----

Functional Parts


Ref #	Part Number	Qty.	Description
1	PW240012		RUN CAPACITOR (VUWC140) 42242061
2	PW240041		COMPRESSOR 15 (42242896)
3	PW240029		CONDENSER 42242893
4	PW240036		EVAPORATOR ASSEMBLY 42243577
5	PW300152		FAN MOTOR ASSY (VUIM150) 42244701
6	PW240039		LIGHT SWITCH - BLACK GRILLE
7	PW240016		ON / OFF SWITCH
8	PW240040		ON / OFF SWITCH
9	PW240007		PTC STARTER (VUWC140) 42242427
10	PW240033		SSAC CONTROL
11	PW240008		TERMINAL BLOCK VUWC140 42242407




Ref #	Part Number	Qty.	Description
1	Not Replacable		CABINET ASSEMBLY
2	PW240029		CONDENSER 42242893
3	PW300141		POP RIVET, SS (VUIM150) 42243617
4	PW240030		DRIER (42242894)
5	PW300152		FAN MOTOR ASSY (VUIM150) 42244701
6	PW210024		FAN SHROUD
7	PW240041		COMPRESSOR 15 (42242896)
8	PW300168		CARRIAGE BOLT (VUIM150) 42243618
9	PW300143		LOCK WASHER (VUIM150) 42243619
10	PW300169		LOCK NUT
11	PW240031		GROUND WIRE COMPRESSOR (42243623)
12	PW200027		NO. 8 STAR WASHER
13	PW200028		HEX HEAD SCREW
14	PW240007		PTC STARTER (VUWC140) 42242427
15	PW210025		BACK PANEL (42242897)
16	PW200004		SCREW LENS COVER 42243354
17	PW210014		DRIP PAN ASSY. (VUWC140)X42242055
18	PW240008		TERMINAL BLOCK VUWC140 42242407
19	PW200029		SCREW
20	PW240012		RUN CAPACITOR (VUWC140) 42242061
21	PW240033		SSAC CONTROL (AFTER 8/1/01)
22	PW240034		POWER CORD VUWC150 (41006714)
23	PW230004		THERMOSTAT KNOB (VUWC140)X42241950
24	PW200002		SCREW 8204905
25	PW220009		DRAIN TUBE J-TRAP (42242901)
26	PW240035		DRAIN TUBE 41005383




Ref #	Part Number	Qty.	Description
1	PW300138		HOLE PLUG
2	PW240036		EVAPORATOR ASSEMBLY 42243577
3	PW200004		SCREW LENS COVER 42243354
4	PW210026		RACK STRIP
5	PW200042		POP RIVET
6	PW210027		DRIP TRAY (42242903)
7	PW240037		LIGHT EXTRUSION 41005657
8	PW210028		WIRE SHELF 42243598
NI	PW210029		GLASS SHELF 42243597
NI	PW210030		WINE RACK 42243599
9	PW240038		AURA LIGHT ASSY
10	PW200043		LOCK WASHER
11	PW200008		SCREW
12	PW200003		SCREW 42242847 (PKG 20)
	PW300144		SCREW, GRILLE - WH (VUIM) 42243104
13	PW240016		ON / OFF SWITCH
	PW240039		LIGHT SWITCH - BLACK GRILLE
14	PW240040		ON / OFF SWITCH
15	PW210031		GRILLE-BLACK 42242909
	PW210032		GRILLE-WHITE (41005742)
NI	PW300251		LEVELING LEGS



Ref #	Part Number	Qty.	Description
1	PW230039		BUMPER - 41005890
2	PW230044		GASKET (42243747)
3	PW200049		SCREW (PACK OF 2)
4	PW200050		HEX-KEP NUT (42247454)
5	PW230043		DOOR SUB ASSY (42033402)
6	PW300246		HINGE BUSHING
7	PW200052		SUB TO PW200035 - SCREW (41005535)
8	PW230033		DOOR HANDLE FRAME (LH) CLEAR GLASS 42243784
	L9297543BK		SUB TO C9297543BK - SILK SCREEN (DUWC150)
	L9297543WH		SUB TO C9297543WH - SILK SCREEN (DUWC150)
	C9297543BT		SILK SCREEN (DUWC150)
	C9297543GG		SILK SCREEN (DUWC150)
	C9297543SG		SILK SCREEN (DUWC150)
	B9297541		DOOR SKIN - SS (RH)
	L9297541BK		SUB TO C9297541BK - SILK SCREEN (DUAR150)
	L9297541WH		SUB TO C9297541WH - SILK SCREEN (DUAR150)
	C9297541BT		SILK SCREEN (DUAR150)
	C9297541GG		SILK SCREEN (DUAR150)
	C9297541SG		SILK SCREEN (DUAR150)
9	PE030090		DOOR HANDLE - SS
	PE030090PVD		DOOR HANDLE 27 XBRX PVD
10	PW220013		STRIKER PLATE (41006713)
11	PW200051		SCREW
NI	G5098065BK		DOOR ASSY DUWC/DUAR150 XBKX LH
	G5098065BKBR		COMPLETE DOOR ASSEMBLY - BKBR (LH)
	G5098065BT		DOOR ASSY DUWC/DUAR150 XBTX LH
	G5098065BTBR		DOOR ASSY DUWC/DUAR150 XBTBRX LH
	G5098065GG		DOOR ASSY DUWC/DUAR150 XGGX LH
	G5098065GGBR		DOOR ASSY DUWC/DUAR150 XGGBRX LH
	G5098065SG		DOOR ASSY DUWC/DUAR150 XSGX LH
	G5098065SGBR		DOOR ASSY DUWC/DUAR150 XSGBRX LH
	G5098065SS		DOOR ASSY DUWC/DUAR150 XSSX LH
	G5098065SSBR		COMPLETE DOOR ASSEMBLY - SSBR (LH)
	G5098065WH		COMPLETE DOOR ASSEMBLY - WH (LH)
	G5098065WHBR		COMPLETE DOOR ASSEMBLY - WHBR (LH)
NI	G5098066BK		COMPLETE DOOR ASSEMBLY - BK (RH)
	G5098066BKBR		COMPLETE DOOR ASSEMBLY - BKBR (RH)
	G5098066BT		DOOR ASSY DUWC/DUAR150 XBTX RH
	G5098066BTBR		DOOR ASSY DUWC/DUAR150 XBTBRX RH
	G5098066GG		DOOR ASSY DUWC/DUAR150 XGGX RH
	G5098066GGBR		DOOR ASSY DUWC/DUAR150 XGGBRX RH
	G5098066SG		DOOR ASSY DUWC/DUAR150 XSGX RH
	G5098066SGBR		DOOR ASSY DUWC/DUAR150 XSGBRX RH
	G5098066SS		COMPLETE DOOR ASSEMBLY - SS (RH)
	G5098066SSBR		COMPLETE DOOR ASSEMBLY - SSBR (RH)
	G5098066WH		COMPLETE DOOR ASSEMBLY - WH (RH)
	G5098066WHBR		COMPLETE DOOR ASSEMBLY - WHBR (RH)



Ref #	Part Number	Qty.	Description
1	PW210036		CLEAR GLASS (42244130)
2	PW200049		SCREW (PACK OF 2)
3	PW200050		HEX-KEP NUT (42247454)
4	PW200051		SCREW
5	PW220013		STRIKER PLATE (41006713)
6	PE030090		HANDLE - SS
	PE030090PVD		DOOR HANDLE 27 XBRX PVD
7	PW230031		DOOR HANDLE FRAME (LH)
			DOOR HANDLE FRAME (RH)
8	PW200052		SUB TO PW200035 - SCREW (41005535)
NI	G5098067SS		DUAR/WC 150 GLD L SSDF DOOR ASSY
	G5098067SSBR		COMPLETE DOOR ASSY - SSBR (LH)
NI	G5098068SS		DR ASSY DUWC/DUAR150 XSSX CLR. RH 42244074
	G5098068SSBR		COMPLETE DOOR ASSY - SSBR (RH)



Ref #	Part Number	Qty.	Description
1	PW210037		FLUTED DOOR W/O FRAME (42243722)
2	PW200049		SCREW (PACK OF 2)
3	PW200050		HEX-KEP NUT (42247454)
4	PW200051		SCREW
5	PW220013		STRIKER PLATE (41006713)
6	PE030090		HANDLE - SS
	PE030090PVD		DOOR HANDLE 27 XBRX PVD
7	PW230031		DOOR HANDLE FRAME (LH)
			DOOR HANDLE FRAME (RH)
8	PW200052		SUB TO PW200035 - SCREW (41005535)
NI	G5098069SS		DR ASSY DUWC/DUAR150 XSSX FLU. LH
	G5098069SSBR		COMPLETE DOOR ASSY - SSBR (LH)
NI	G5098070SS		COMPLETE DOOR ASSY - SS (RH)
	G5098070SSBR		COMPLETE DOOR ASSY - SSBR (RH)