

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




# VIKING VGSB152T Owner's Manual

[Shop genuine replacement parts for VIKING VGSB152T](#)



[Find Your VIKING Grill Parts - Select From 210 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	PD010012		VALVE BOLT 1/4-20 UNC-2B 5/16 M.S.
2	PD030044		10-24 KEPS NUT SS
3	PD020082		10 X 24 COUNTERSUNK S.S. SCREW
4	PD020067		NO.6 X 3/8 PAN PHIL. TEK SS
5	PA030002		BURNER BOWL
6	014947-000	1	LID, BNR, ASM, SIDE
7	B9205338		CONTROL PANEL SIDE BURNER
8	G3005215		DRIP TRAY SLIDE - RH
9	G3005214		DRIP TRAY SLIDE - LH
10	PC020025		DRIP TRAY WHEEL
11	PA080052		FRONT BURNER
12	B2005333		GRILL BOX FRONT - 30
13	B2005204		PANEL, GRL, LH
14	B2005203		GRILL BOX SIDE RH (PHASE 2)
15	PA060051		GRILL V GRATE (PHASE 2)
16	PB010208		BEZEL, CHROME PLATE
	PB010209		BEZEL BRASS
17	G3005335		LANDING LEDGE ASSY- S/BURNER (PH2)
18	PB040167		MALE COUPLER (PHASE 1 GRILL)
19	PD020056		NO.10-24 X 1/2 PH.TR. M.S. SS
20	B2005260		PHASE II BURNER SUPPORT
21	B2105290		PHASE II GRATE SUPPORT
22	PA050071		MANIFOLD 12 SIDE BURNER PHASE 2
23	PA020036		SPARK MODULE
24	PD020055		NO.10 X 1/2 PAN PHIL. TEK. SS
25	PA080053		REAR TOP BURNER
26	PD030050		10-24 CAGE NUT SS
27	B2005332		SIDE BURNER BOX BACK PHASE 2
28	B2005331		SIDE BURNER BOX BOTTOM PHASE 2
29	G3205340		SIDE BURNER DRIP TRAY ASSY
30	B2005339		SIDE BURNER REAR TRIM
31	PA020014		SPARK IGNITER
32	PE050063		SPARKER SWITCH
33	PA010105		SIDE BURNER VALVE T SERIES-NAT.
	PA010106		SUB TO 003574-000 - SIDE BURNER VALVE T SERIES- L.P.
34	PA010039		TOP GRILL KNOXBKX (VGRC) (N/STYLE
35	PB010163		OVEN LIGHT SWITCH KNOB BK
No.	G3004936		REGULATOR ASSY - NAT (P1 GRILL)
No.	G3004937		REGULATOR ASSY - L.P. W/HOSE