


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# VIKING VEDO275 Owner's Manual

[Shop genuine replacement parts for VIKING VEDO275](#)




[Find Your VIKING Oven Parts - Select From 98 Models](#)


----- Manual continues below -----

# *Functional Parts*


Ref #	Part Number	Qty.	Description
1	PE150004		BAKE ELEMENT (77001092)
2	PE150003		BROIL ELEMENT Y0042138
3	PE150005		CONVECTION ELEMENT 77001135
4	PE110025		CONVECTION FAN MOTOR 0307035
5	PE110001		ELECTRONIC TIMER
6	PE110024		MOTOR FAN Y0042226
7	PE110023		RESISTOR FAN MOTOR(100 OHMS)0042064
8	PE110015		SWITCH FAN SPDT Y0042056
9	PE110015		SWITCH FAN SPDT Y0042056
10	PE110026		HIGH LIMIT THERMOSTAT 0306502
11	PE110009		INDICATOR LIGHT(COLORS ONLY)042183
12	PE110008		INDICATOR LIGHT (SS MODELS)
13	PE110027		DOOR LOCK SWITCH Y0067919
14	PE110007		UPPER/LOWER OVEN LIGHT SW. 0303400
15	PE110017		LOWER OVEN LIMIT SWITCH 0302959
16	PE110010		LOWER OVEN THERMOSTAT
17	PE110028		MOMENTARY SWITCH
18	PE110011		SELECTOR SWITCH (7-POS.) 0305772
19	NLA		SOLENOID - PE110030
20	PE120019		SWITCH MOUNTING SCREW (0041826)
21	PE110021		BLOCK TERMINAL 0042191
22	PE110014		TIME MANUAL SWITCH
23	PE110007		UPPER/LOWER OVEN LIGHT SW. 0303400
24	PE110022		UPPER OVEN LIMIT SWITCH Y0042045
25	PE110010		UPPER OVEN THERMOSTAT



Ref #	Part Number	Qty.	Description
1	PE100001		CONTROL MOUNTING BRACKET
2	SEE DISTRIBUTOR		ELECTRONIC TIMER
3	PE100002		TIMER MOUNTING BRACKET
4	PE100003		CONTROL PANEL TOP TRIM
5	PE100004		VENT GRILL 0301915
6	PE110002BK		SELECTOR KNOB - BK
	PE110002WH		SELECTOR KNOB (WHITE) 0305581
7	PE100033BK		CONTROL PANEL - BLACK 0305476
	PE100033SS		CONTROL PANEL - XSS 0307144
	PE100033WH		CONTROL PANEL - WH 0305477
8	PE100005		CONTROL PANEL BOTTOM TRIM
9	PE110003BK		THERMOSTAT KNOB - BK
	PE110003WH		THERMOSTAT KNOB (WHITE) 0305579
10	PB010113		CLOCK KNOB - BK
	PE110004WH		TIMER/CLOCK KNOB XWH DO/SO 0303448
11	PE110005BK		CLOCK SET KNOB XBK(SO/DO) 0060730
	PE110005WH		CLOCK SET KNOB XWH(SO/DO) 0303420
12	PE110006BK		OVEN LIGHT KNOB (BLACK) 0303405
	PE110006WH		OVEN LIGHT KNOB (WHITE) 0303423
13	PE120001		TERMINAL BUSHING 2-POLE 0042012
14	PE110007		UPPER/LOWER OVEN LIGHT SW. 0303400
15	PE110008		INDICATOR LIGHT (SS MODELS)
	PE110009		INDICATOR LIGHT(COLORS ONLY)042183
16	PE110010		LOWER OVEN THERMOSTAT
17	PE110007		UPPER/LOWER OVEN LIGHT SW. 0303400
18	PE110011		SELECTOR SWITCH (7-POS.) 0305772
19	PE110010		UPPER OVEN THERMOSTAT
20	PE100006		LATCH HANDLE GUIDE
21	PG100007		SOLENOID LEVER BRACKET
22	PE100008		CONTROL PANEL BOTTOM TRIM INSERT
23	PE100010		BEZEL KNOB CHROME 0302084
	PB010085		KNOB BEZEL
24	PE110012BK		BIT GENERATOR SHAFT XBK 0300933B
	PE110012WH		SHAFT - BIT GENERATOR (WH)
25	PE140001		LENS ELEC TIMR LENS VEDO/SO 0302085
26	PE100009		CLOCK WIN BEZEL REPL PE040070
27	PE120002		BEZEL NUT
28	PE100011		BRACKET INDICATOR LIGHT 0305463
29	PE110013BK		TIME/MANUAL KNOB XBKXVESO/DO-0305780
	PE110013WH		KNOB TIME/MANUL XWH VESO/DO 0305781
30	PE110014		TIME MANUAL SWITCH




Ref #	Part Number	Qty.	Description
1	PE130001		CABINET TOP 0040286
2	PE130002		CABINET SIDE PANEL 0052856
3	PE130027		COMPARTMENT PANEL-L.H.
4	PE130004		UPPER BACK CABINET 0305628
5	PE130029		COMPARTMENT PANEL-R.H.
6	PE130006		LOWER OVEN FLUE BOX 0040581
7	PE130007		RETAINER INSULATION REAR 0305420
8	PE130008		UPPER OVEN TOP 0052848
9	PE130009		UPPER OVEN FLUE BOX 0040581
10	PE130010		LOWER OVEN VENT TUBE 0042406
11	PE110015		SWITCH FAN SPDT Y0042056
12	PE110017		LOWER OVEN LIMIT SWITCH 0302959
13	PE100022		SWITCH PLATE 0040783
14	PE100023		REAR SUPPORT 00401021
15	PE130011		RETAINER SIDE INSULATION 0060774
16	PE130012		LOWER BACK CABINET 0059743
17	PE130013		LOWER OVEN CHANNEL 0040755
18	PE120027		SCREW NO.8-18 0305423
19	PE130014		RETAINER SPRING 0060759
20	PE130015		OVEN BOTTOM 0305701
21	PE100012		BASE RUNNER 0041019
22	PE130016		LOWER OVEN TOP
23	PE130017		NLA
24	PE100013		SIDE TRIM-R.H.
25	NLA		SMOKE ELIMINATOR - PE130019
26	PE100021		UPPER OVEN BOTTOM
27	PE100014		BOTTOM TRIM
NI	PE100015		TRIM BOTTOM INSERT 0301918
28	PE110018		OVEN LAMP LENS 74011299
29	PE110019		OVEN LIGHT SOCKET
30	PE110020		BULB OVEN 40 WATT 8009
31	PE100016		SIDE TRIM-L.H. 0301887
32	PE100021		LATCH HANDLE GUIDE
33	PE100018		TRIM CENTER 0301884
NI	PE100019		TRIM INSERT CENTER 0301917
34	PE100020		SUPPORT OVEN FRONT 0060838 - NLA
35	PE120003		HINGE ASSEMBLY
36	NLA		OVEN DOOR SPRING - PE120004
37	PE120005		TRIM SCREW (BLACK)
38	PE100006		LATCH HANDLE GUIDE
39	PE100005		CONTROL PANEL BOTTOM TRIM
40	PE120006		CONDUIT ASSEMBLY 0052947
41	PE130020		LOWER SIDE SHIELD
42	PE130021		UPPER SIDE CABINET 0060774







Ref #	Part Number	Qty.	Description
1	PE130027		COMPARTMENT PANEL-L.H.
2	PE110021		BLOCK TERMINAL 0042191
3	PE110022		UPPER OVEN LIMIT SWITCH Y0042045
4	PE130028		OVEN TOP-UPPER
5	PE110024		MOTOR FAN Y0042226
6	PE110031		BLADE FAN Y0314548
7	PE110015		SWITCH FAN SPDT Y0042056
8	PE100027		BRACKET FAN MOTOR 0305242
9	PE100028		FAN MOUNTING PLATE (0040905
10	PE110023		RESISTOR FAN MOTOR(100 OHMS)0042064
11	PE130029		COMPARTMENT PANEL-R.H.



Ref #	Part Number	Qty.	Description
1	PE130030		BROIL ELEMENT REFLECTOR 0306503
2	PE100029		BROIL ELEMENT SUPPORT
3	PE150001		LOWER OVEN RACK-LONG
	PE150002		UPPER OVEN RACK - SHORT
4	PE100034		GRID BROILER 304451E
5	PE100030		BROILER PAN 314175C6
6	PE150003		BROIL ELEMENT Y0042138
7	PE150004		BAKE ELEMENT (77001092)
8	PE120016		L.H. THREAD NUT (0307037)
9	PE120017		WASHER FRONT CONV FAN 0307038
10	PE120018		WASHER REAR CONV FAN 0307038
11	PE100031		FAN MOUNTING BRACKET (0305627 )
12	PE110025		CONVECTION FAN MOTOR 0307035
13	PE110032		BLADE CONVECTION FAN 0307036
14	PE150005		CONVECTION ELEMENT 77001135
15	PE130031		FAN COVER
16	PE110026		HIGH LIMIT THERMOSTAT 0306502



Ref #	Part Number	Qty.	Description
1	PE110027		DOOR LOCK SWITCH Y0067919
2	PE110028		MOMENTARY SWITCH
3	PE120019		SWITCH MOUNTING SCREW (0041826)
4	PE140007		INSULATOR ESM DOOR LOCK ASY 0091523
5	PE120020		HANDLE MOUNTING SCREW (0041777)
6	PE150006BK		LATCH HANDLE - BK
	PE150006WH		LATCH HANDLE - WH
7	PE150007BK		LATCH ARM - BK
	PE150007WH		LATCH DOOR ARM XWH 040538WHITE
8	PE120021		LATCH ARM SCREW (0041774)
9	PE120022		DOOR LOCK SCREW 0041765
10	PE120023		DOOR LOCK KEP NUT 0097885
11	PE110029		DOOR LOCK
12	PE120024		BRASS SCREW (DOOR LOCK) 0041773
13	PE120025		DOOR LOCK KEP NUT M0282005
14	PE110030		SOLENOID
15	PE100032		DOOR LATCH BRACKET 0060840
16	PE120026		SOLENOID SCREW (0060923)



Ref #	Part Number	Qty.	Description
NI	PE130033AL		COMPLETE UPPER DOOR ASSY. - AL
	PE130033BK		COMPLETE UPPER DOOR ASSY. - BK
	PE130033BU		COMPLETE UPPER DOOR ASSY. - BU
	PE130033FG		COMPLETE UPPER DOOR ASSY. - FG
	PE130033PL		COMPLETE UPPER DOOR ASSY. - PL
	PE130033SS		COMPLETE UPPER DOOR ASSY. - SS
	PE130033VB		COMPLETE UPPER DOOR ASSY. - VB
	PE130033WH		COMPLETE UPPER DOOR ASSY. - WH
NI	PE130034AL		COMPLETE LOWER DOOR ASSY. - AL
	PE130034BK		LOWER DOOR ASSEMBLY - COMPLETE
	PE130034BU		COMPLETE LOWER DOOR ASSY. - BU
	PE130034FG		COMPLETE LOWER DOOR ASSY. - FG
	PE130034PL		COMPLETE LOWER DOOR ASSY. - PL
	PE130034SS		COMPLETE LOWER DOOR ASSY. - SS
	PE130034VB		COMPLETE LOWER DOOR ASSY. - VB
	PE130034WH		LOWER DOOR ASSEMBLY - COMPLETE
1	F0002576SS		HANDLE OVEN DOOR XSS (24.625 LENGTH)
	F0002576BR		HANDLE OVEN DOOR XBR 0301898
2	PE030001		BRACKET, DOOR, HANDLE
	PE030001PVD		END CAP DOOR HANDLE XBR
3	PE100024BK		PANEL DOOR LOWER XBK 306584B
	PE100024SS		PANEL DOOR LOWER XSS 0304629
	PE100024WH		PANEL DOOR LOWER XWH 306584W
	C9002325AL		DOOR PANEL-LOWER XALX (VEDO/VGDO)
	C9002325BU		DOOR PANEL-LOWER XBUX (VEDO/VGDO)
	C9002325FG		DOOR PANEL-LOWER XFGX (VEDO/VGDO)
	C9002325PL		DOOR PANEL-LOWER XPLX (VEDO/VGDO)
	C9002325VB		DOOR PANEL-LOWER XVBX (VEDO/VGDO)
	PE100025BK		UPPER DOOR PANEL - BK
	PE100025SS		UPPER DOOR PANEL - SS
	PE100025WH		UPPER DOOR PANEL - WH
	C9002324AL		DOOR PANEL-UPPER XALX (VEDO/VGDO)
	C9002324BU		DOOR PANEL-UPPER XBUX (VEDO/VGDO)
	C9002324FG		DOOR PANEL-UPPER XFGX (VEDO/VGDO)
	C9002324PL		DOOR PANEL-UPPER XPLX (VEDO/VGDO)
	C9002324VB		DOOR PANEL-UPPER XVBX (VEDO/VGDO)
4	PE140002		GLASS WINDOW 0301912
5	PE130032		BAFFLE INNER DOOR 301896G
6	PE120007		DOOR HANDLE MTG. WASHER (3/4 X 5/16
7	PE100026		TRIM J MOLD XSS 0302082
	PE060028		TRIM J MOLD XBR 306584B
8	PE140003		WINDOW ASSEMBLY
9	PD010014		MACH. SCREW - NO.10-24 X 1-3/4 XSSX
10	PE130032		BAFFLE INNER DOOR 301896G
11	PE120008		DOOR PANEL SCREW AMNO.0041793
12	PE130023		LATCH PLATE 0052039
13	PE120009		LATCH PLATE SCREW 31750410
14	PE140004		LINER INSULATION DOOR 0301899
15	PE140005		DOOR GASKET 31715903
16	PE130024		DOOR PLUG 004023CG
17	PE120010		PLUG MOUNTING SCREW 0041793
18	PE130025		RETAINER DOOR GLASS 0052629
19	PE010016		NAMEPLATE, LOGO, PRO
	PE010061		4.5 LOGO/VIKING PROF XBU/CHR
	PE010062		4.5 LOGO/VIKING PROF XFG/CHR
	PE010063		4.5 LOGO/VIKING PROF XPL/CHR
	PE010065		4.5 LOGO/VIKING PROF XVB/CHR
	PE010017		LOGO (VGSO,VEDO,VGDO,VUD) XWH/CHR
	PE010079		4.5 LOGO/VIKING PROF, BK/BR
	PE010080		4.5 LOGO/VIKING PROF XWH/BR

Ref #	Part Number	Qty.	Description
	PE010080		4.5 LOGO/VIKING PROF XWH/BR
20	PE140006		INSULATION-DOOR LINER
21	PE130026		PLATE INSULATION 0301908
22	PE120011		SUB TO PD020002
23	PE120012		LOGO CLIP 0304065
24	PE120013		DOOR PANEL KEP NUT 0097885
25	PE120014		DOOR PANEL SCREW 0098190
26	PE120015		BAFFLE MOUNTING SCREW 0041808
NI	PG100025		FIBER WASHER
NI	PG100026		FIBER WASHER