


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




VIKING VCQS_SMOKER_GRILL Owner's Manual

[Shop genuine replacement parts for VIKING
VCQS SMOKER GRILL](#)




[Find Your VIKING Grill Parts - Select From 210 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	PD010058		TOP VENT BOLT
2	PC010014		TOP VENT SPRING
3	PM010451		VENT COVER KIT (VCSQ001)
4	PD020057		NO.10 X 1 FLAT HD. TEK. SS
5	PB010216		GRILL THERMOMETER (VCQS)
6	PB010192		THERMOSTAT BEZEL
7	B50015428		TOP GRILL SLEEVE
8	015010-000		OUTDOOR LOGO - 4.5 CHROME
9	PD030006		CAPPED WASHER PAL NUT
10	PC020236		SMOKER HINGE
11	PE030108		SMOKER HANDLE (VCQS)
12	PE030001		BRACKET, DOOR, HANDLE
13	PE030132		CENTER HANDLE BRACKET (VCQS)
14	PE030098		HANDLE SPACER (VCQS)
15	PD020190		BUTTON HEAD SOCKET CAP SCREW
16	PD020134		BUTTON HEAD SOCKET CAP SCREW
17	PD030103		VCQS WELD NUT
18	PD020133		BUTTON HEAD SOCKET CAP SCREW (VCQS)
19	B20013334		HINGE BRACE - 2
20	PD040115		SS FLAT WASHER
21	B20013333		LOWER HINGE BRACE
22	PB070376		FIBERGLASS TAPE (64 INCHES)
23	B50015429		TOP COLLAR
24	B50015427		BOTTOM COLLAR
25	PK040002		GRILL TOP



Ref #	Part Number	Qty.	Description
1	PB060076		CENTER RACK (VCQS)
2	PK040006		CERAMIC FIRE BOX
3	PK040001		BOTTOM CERAMIC
4	PK040004		CHARCOAL RACK (VCQS)
5	B50015426		BOTTOM GRILL SLEEVE
6	PD020164		NO.10 X 1 1/2 FLAT HD TEK SS
7	PK010087		LOWER VENT COVER BASE
8	PK010086		LOWER VENT COVER
9	PC010014		TOP VENT SPRING
10	PD010058		TOP VENT BOLT
11	PM010467		VCQS ASH TOOL