

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Weber 1500090 Owner's Manual

[Shop genuine replacement parts for Weber 1500090](#)



[Find Your Weber Grill Parts - Select From 2037 Models](#)

----- Manual continues below -----

Buy now, pay later.




with Affirm. [Apply Now](https://www.affirm.com/shop) (<https://www.affirm.com/shop>)
(<https://www.weber.com/US/en/home/>)



SUMMIT® GC38 E GRILL CENTER (NATURAL GAS) - 1500090

SUMMI



1 2400486 Thermometer, Summit '24



(<https://www.weber.com/US/en/home/>)

2 64545 Thermometer bezel, Genesis/Summit

3 64650 Logo Plate, SS

4 2400260 Lid Assembly, Black, Summit '24+

5 2401001 Lens nut for Integrated Surface Lighting, handle (qty 2)

6 2400267 Handle with integrated light

7 63823 Battery sleeve for handle

8 2400430 IR Broiler cover straps, SS, set of 2

9 2400432 IR Broiler rear cover, Summit '24+

10 2400921 IR Broiler Assembly, NG

11 2400434 IR broiler guard

12 2400265 Cookbox, black, Summit '24+

13 64608 Clip for ignition wire routing (qty 3)

14 2400284 Igniter wiring harness, Summit

15 2400917 Manifold, NG, Summit '24+

16 2400268 Heat shield, Summit cookbox

17 2400281 Lighted control panel LED harness

18 2400912 Control panel, NG/BI

19 2400283 Bezel for main burners, Summit '24+, set of 5

20 2400437 Lighted main control knob kit, set of 5

21 69282 Light/momentary switch, Genesis/Summit

22 2400439 Lid, side burner

23 64589 Side burner grate/trivet, Genesis/Summit

24 66400 Side burner cap

25 64596 Side burner tray, Genesis/Summit

26 64691 Side Burner assembly, NG, Genesis/Summit

27 2400724 Igniter Kit, side burner, Summit

28 2400970 LHS Table with S/B Assembly, LP, Summit GC '24+

29 2400971 Table Rail, Summit GC

40 2401019 LHS Cabinet rear panel,



(<https://www.weber.com/US/en/home/>)

41	2401020	LHS Cabinet bottom panel, black
42	2400278	Front frame, black, Summit '24+
43	2401007	RHS cabinet panel, black
44	2400978	Leg kit, adjustable, set of 2
45	2401017	LHS Frame cabinet, black
46	2400472	Door hinge kit, soft close, set of 1
47	2400473	LHS Door assembly, Black, Summit '24+
48	2400474	RHS Door assembly, Black, Summit '24+
49	70302	Hardware kit, Summit Lid
49	2400277	Door handle kit, Summit '24+, qty. 1
50	2401016	LHS Door Assembly, black Summit GC
51	2400277	Door handle kit, Summit '24+, qty. 1
52	2400453	Upper cooking grate, SS, Summit '24+
53	2400452	Cooking grates, 9mm SS, set of 3
54	64687	WEBER CRAFTED frame kit
54	64688	WEBER CRAFTED inset spacer
55	2400286	Smoker assembly, Summit '24+
56	2400288	Flavorizer bars, SS, Summit '24+, set of 5
57	66686	Heat deflector, Genesis/Summit (qty 4)
58	64560	Burner tube clamp set, Genesis 400 series (2022) (qty 5)
59	2400455	Crossover Tube, Summit '24+
60	2400920	Burner kit, NG, Summit '24+, set of 5
61	2400491	Igniter electrode, 59", white
61	2400494	Igniter electrode, 36", black
61	2400492	Igniter electrode, 51", blue
61	2400495	Igniter electrode, 32", red
61	2400460	Igniter Kit, Summit, '24+
61	2400493	Igniter electrode, 46", green



73	2400468	Bracket assembly, tuck a
74	65579	Rotisserie motor, Type B, "15
75	2400972	RHS Table w/Tuck Away Rotisserie, Summit 24+
76	2400971	Table Rail, Summit GC
77	2400914	Rear panel, NG, black, Summit '24+
78	2401005	RHS Rear panel, cabinet, black
79	2401008	RHS cabinet shield for rotisserie bracket
80	2401006	Bottom panel, cabinet, black
81	2400915	Tank blocker bracket, black, NG/BI
82	2400916	Bottom panel, NG, black
83	2401007	RHS cabinet panel, black
84	2401004	RHS inside Panel w/Cabinet, black
85	2400461	Battery holder assembly
86	2400901	Controller Cover, Summit '24+
87	69564	Cable kit, Genesis EX
88	69563	Genesis II EX/SX, controller board
89	64570	Power bank bracket
90	2400459	Igniter Module, Summit '24+
91	2401003	RHS Frame cabinet, black
92	2401002	RHS Door Assembly, black Summit GC
93	69257	Grease scraping tool
94	66534	Match holder assembly, Genesis LX, 440/640
95	2400277	Door handle kit, Summit '24+, qty. 1
470	2400994	Hardware Kit, NG, black, FS/GC (bags A,B,C&D)
470	2401010	Hardware bag C, Summit '24+ FS/GS Side Table
470	2401297	Hardware Bag E, Side Cabinet, black
470	70302	Hardware kit, Summit Lid
470	2400998	Hardware bag A, NG, tank blocker/wire clips
470	2401011	Hardware bag D, FS/GC, cabinet hooks



*For more details on how we use your information, see our privacy policy.

Company

Customer Support

Replacement Parts

Explore
