

Weber 1500013 Owner's Manual

Shop genuine replacement parts for Weber 1500013




Find Your Weber Grill Parts - Select From 2037 Models

----- Manual continues below -----



SLATE™ 30" RUST-RESISTANT GRIDDLE WITH EXTENDABLE SIDE TABLE - 1500013



1	2400762	Hard cover, black, 30" Slate
2	2400764	Logo plate, Griddle
3	2400793	Handle, 30" Hard cover
4	2400532	Burner tube kit, 30" Griddle
6	2400790	LHS folding table assembly, 30"
7	2400928	Brackets, Front/Rear, fold down table
8	2400761	Cookbox assembly, 30" griddle
9	2400537	Manifold assembly, LP, 30" griddle
10	2400775	Control Panel, 30" griddle
12	2400780	Control knob kit, set of 3
13	2400740	Digital temperature display, 30" griddle
14	6498	Drip pan (qty 10) Large Grills
15	2400782	Catch pan kit, 30/36" griddle
16	2400788	LHS Frame, 30" griddle
17	2400878	Middle Shelf, 30 griddle w/bins
18	2400924	Bin Rails
19	2400924	Bin Rails
20	2400800	Rear panel, 30" griddle
21	2400787	Bottom panel, 30" griddle
23	2400797	Flat top griddle, 30"
24	2400929	Grease chute, 30/36" griddle
25	2400743	Thermometer probe and bracket
26	2400778	Table insert
27	2400777	RHS Table assembly, 30" griddle
28	2400811	Corrugated gas line
29	67157	LP/NG Bulkhead assembly, Spirit II
30	69891	QCC1 hose and regulator, 17"
31	2400779	RHS flip up table assembly
32	2400744	Temperature display Battery pack w/wire

<u>Ema</u>			
Δdd^{i}			

*For more details on how we use your information, see our privacy policy.

Company	
Customer Support	
Replacement Parts	
Explore	

© 2024 Weber. All Rights Reserved.