

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Weber 1500029 Owner's Manual

[Shop genuine replacement parts for Weber 1500029](#)




[Find Your Weber Grill Parts - Select From 2037 Models](#)

----- Manual continues below -----



SUMMIT® FS38 E GAS GRILL (LIQUID PROPANE) - 1500029

SUMMIT



1	2400486	Thermometer, Summit '24+
2	64545	Thermometer bezel, Genesis/Summit
3	64650	Logo Plate, SS
4	2400260	Lid Assembly, Black, Summit '24+
5	2401001	Lens nut for Integrated Surface Lighting, handle (qty 2)
6	2400267	Handle with integrated light
7	63823	Battery sleeve for handle
8	2400430	IR Broiler cover straps, SS, set of 2
9	2400432	IR Broiler rear cover, Summit '24+
10	2400900	IR Broiler Assembly, LP
11	2400434	IR broiler guard
12	2400265	Cookbox, black, Summit '24+
13	64608	Clip for ignition wire routing (qty 3)
14	2400284	Igniter wiring harness, Summit
15	2400436	Manifold, LP, Summit '24+
16	2400268	Heat shield, Summit cookbox
17	2400281	Lighted control panel LED harness
18	2400282	Tank scale sensor, Summit '24+
19	2400266	Control panel assembly w/light
20	2400283	Bezel for main burners, Summit '24+, set of 5
21	2400437	Lighted main control knob kit, set of 5
22	69282	Light/momentary switch, Genesis/Summit
23	2400439	Lid, side burner
24	64589	Side burner grate/trivet, Genesis/Summit
25	66400	Side burner cap
26	64596	Side burner tray, Genesis/Summit
27	64989	Side Burner assembly, LP, Genesis/Summit
28	2400724	Igniter Kit, side burner, Summit
29	2400463	LHS Table with S/B Assembly, Summit '24+

39	2400278	Front frame, black, Summit '24+
40	2400447	Locking Caster, w/insert Right Front
40	2400446	Locking Caster, w/insert Left Front
41	2400472	Door hinge kit, soft close, set of 1
42	2400473	LHS Door assembly, Black, Summit '24+
43	2400474	RHS Door assembly, Black, Summit '24+
44	2400277	Door handle kit, Summit '24+, qty. 1
45	2400453	Upper cooking grate, SS, Summit '24+
46	2400452	Cooking grates, 9mm SS, set of 3
47	64687	WEBER CRAFTED frame kit
47	64688	WEBER CRAFTED inset spacer
48	2400286	Smoker assembly, Summit '24+
49	2400288	Flavorizer bars, SS, Summit '24+, set of 5
50	66686	Heat deflector, Genesis/Summit (qty 4)
51	64560	Burner tube clamp set, Genesis 400 series (2022) (qty 5)
52	2400455	Crossover Tube, Summit '24+
53	2400454	Burner kit, LP, Summit '24+, set of 5
54	2400460	Igniter Kit, Summit, '24+
54	2400493	Igniter electrode, 46", green
54	2400491	Igniter electrode, 59", white
54	2400494	Igniter electrode, 36", black
54	2400492	Igniter electrode, 51", blue
54	2400495	Igniter electrode, 32", red
55	64561	Bottom tray rails, Genesis/Summit
56	64533	Grease tray, Genesis/Summit
57	6417	Aluminum drip pans - package of 10
58	2400469	Catch pan holder, Wire
59	70379	Catch pan kit
60	2400276	Top trim, rear, black

71	2400274	Rear panel, LP, Black, Summit '24+
72	2400273	Tank enclosure, black, Summit '24+
73	2400450	Tank blocker bracket, black, LP
74	2400461	Battery holder assembly
75	2400272	RHS panel, black, Summit '24+
76	2400901	Controller Cover, Summit '24+
77	69564	Cable kit, Genesis EX
78	69563	Genesis II EX/SX, controller board
79	2400271	Bottom panel, LP, black, Summit '24+
80	2400459	Igniter Module, Summit '24+
81	64570	Power bank bracket
82	69257	Grease scraping tool
83	66534	Match holder assembly, Genesis LX, 440/640
470	69600	Hardware, tank glide buttons, Genesis II/'22 Genesis/Summit +'24
470	2400996	Hardware bag A, LP, tank blocker/wire clips
470	2401011	Hardware bag D, FS/GC, cabinet hooks
470	70302	Hardware kit, Summit Lid
470	2400999	Hardware bag B, ignition, Summit FS/GC
470	2400992	Hardware Kit, LP, black, FS/GC (bags A,B,C&D)
470	2401010	Hardware bag C, Summit '24+ FS/GS Side Table

Join Our Community

Sign up to receive new product news, exclusive offers, grilling tips & recipes, and more from Weber and its affiliates / subsidiaries

[privacy_policy_\(https://www.weber.com/US/en/privacypolicy.html\)](https://www.weber.com/US/en/privacypolicy.html).

