

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Weber 1500040 Owner's Manual

[Shop genuine replacement parts for Weber 1500040](#)




[Find Your Weber Grill Parts - Select From 2037 Models](#)

----- Manual continues below -----



SUMMIT® FS38 E GAS GRILL (NATURAL GAS) - 1500040

SUMMI



1	2400486	Thermometer, Summit '24+
2	64545	Thermometer bezel, Genesis/Summit
3	64650	Logo Plate, SS
4	2400260	Lid Assembly, Black, Summit '24+
5	2401001	Lens nut for Integrated Surface Lighting, handle (qty 2)
6	2400267	Handle with integrated light
7	63823	Battery sleeve for handle
8	2400430	IR Broiler cover straps, SS, set of 2
9	2400432	IR Broiler rear cover, Summit '24+
10	2400921	IR Broiler Assembly, NG
11	2400434	IR broiler guard
12	2400265	Cookbox, black, Summit '24+
13	64608	Clip for ignition wire routing (qty 3)
14	2400284	Igniter wiring harness, Summit
15	2400917	Manifold, NG, Summit '24+
16	2400268	Heat shield, Summit cookbox
17	2400281	Lighted control panel LED harness
18	2400912	Control panel, NG/BI
19	2400283	Bezel for main burners, Summit '24+, set of 5
20	2400437	Lighted main control knob kit, set of 5
21	69282	Light/momentary switch, Genesis/Summit
22	2400439	Lid, side burner
23	64589	Side burner grate/trivet, Genesis/Summit
24	66400	Side burner cap
25	64596	Side burner tray, Genesis/Summit
26	64691	Side Burner assembly, NG, Genesis/Summit
27	2400724	Igniter Kit, side burner, Summit
28	2400500	LHS Table w/o S/B Assembly, Summit '24+
29	2400464	LHS Table Rail

39	2400472	Door hinge kit, soft close, set of 1
40	2400473	LHS Door assembly, Black, Summit '24+
41	2400474	RHS Door assembly, Black, Summit '24+
42	2400277	Door handle kit, Summit '24+, qty. 1
43	2400453	Upper cooking grate, SS, Summit '24+
44	2400452	Cooking grates, 9mm SS, set of 3
45	64688	WEBER CRAFTED inset spacer
45	64687	WEBER CRAFTED frame kit
46	2400286	Smoker assembly, Summit '24+
47	2400288	Flavorizer bars, SS, Summit '24+, set of 5
48	66686	Heat deflector, Genesis/Summit (qty 4)
49	64560	Burner tube clamp set, Genesis 400 series (2022) (qty 5)
50	2400455	Crossover Tube, Summit '24+
51	2400920	Burner kit, NG, Summit '24+, set of 5
52	2400492	Igniter electrode, 51", blue
52	2400495	Igniter electrode, 32", red
52	2400460	Igniter Kit, Summit, '24+
52	2400493	Igniter electrode, 46", green
52	2400491	Igniter electrode, 59", white
52	2400494	Igniter electrode, 36", black
53	64561	Bottom tray rails, Genesis/Summit
54	2400597	Grease tray, Genesis 4B/Summit
55	6417	Aluminum drip pans - package of 10
56	2400469	Catch pan holder, Wire
57	70379	Catch pan kit
58	2400276	Top trim, rear, black
59	84116	Rotisserie hardware for tuckaway rotisserie, w/forks, '10
60	2400285	Rotisserie shaft, Summit '24+
61	2400275	Rear frame, black, Summit '24+

72	2400272	RHS panel, black, Summit '24+
73	2400901	Controller Cover, Summit '24+
74	69564	Cable kit, Genesis EX
75	69563	Genesis II EX/SX, controller board
76	2400916	Bottom panel, NG, black
77	2400459	Igniter Module, Summit '24+
78	64570	Power bank bracket
79	69257	Grease scraping tool
80	66534	Match holder assembly, Genesis LX, 440/640
470	70302	Hardware kit, Summit Lid
470	2400999	Hardware bag B, ignition, Summit FS/GC
470	2400994	Hardware Kit, NG, black, FS/GC (bags A,B,C&D)
470	2401010	Hardware bag C, Summit '24+ FS/GS Side Table
470	2400998	Hardware bag A, NG, tank blocker/wire clips
470	2401011	Hardware bag D, FS/GC, cabinet hooks

95

Join Our Community

Sign up to receive new product news, exclusive offers, grilling tips & recipes, and more from Weber and its affiliates / subsidiaries

[privacy_policy_\(https://www.weber.com/US/en/privacypolicy.html\)](https://www.weber.com/US/en/privacypolicy.html).

Eme

Addr

*For more details on how we use your information, see our privacy policy.

Company

Customer Support