


SUMMIT - GC38 E/S LP - US 2024



1	2400486	Thermometer, Summit '24+
2	64545	Thermometer bezel, Genesis/Summit
3	64650	Logo Plate, SS
4	2400260	Lid Assembly, Black, Summit '24+
5	2401001	Lens nut for Integrated Surface Lighting, handle (qty 2)
6	2400267	Handle with integrated light
7	63823	Battery sleeve for handle
8	2400430	IR Broiler cover straps, SS, set of 2
9	2400432	IR Broiler rear cover, Summit '24+
10	2400900	IR Broiler Assembly, LP
11	2400434	IR broiler guard
12	2400265	Cookbox, black, Summit '24+
13	64608	Clip for ignition wire routing (qty 3)
14	2400284	Igniter wiring harness, Summit
15	2400436	Manifold, LP, Summit '24+
16	2400268	Heat shield, Summit cookbox
17	2400281	Lighted control panel LED harness
18	2400282	Tank scale sensor, Summit '24+
19	2400266	Control panel assembly w/light
20	2400283	Bezel for main burners, Summit '24+, set of 5
21	2400437	Lighted main control knob kit, set of 5
22	69282	Light/momentary switch, Genesis/Summit
23	2400439	Lid, side burner
24	64589	Side burner grate/trivet, Genesis/Summit
25	66400	Side burner cap
26	64596	Side burner tray, Genesis/Summit
27	64989	Side Burner assembly, LP, Genesis/Summit
28	2400724	Igniter Kit, side burner, Summit
29	2400970	LHS Table with S/B Assembly, LP, Summit GC '24+
30	2400971	Table Rail, Summit GC
31	2400287	Control knob, S/B
31	2400478	Bezel, S/B
32	66259	Igniter module, Gen II 2B or Gen II/LX/Summit S/B
33	2400470	Side burner corrugated gas line
34	70309	Corrugated gas line, main, Summit
35	2401018	LHS inside Panel w/Cabinet, LP, black
36	64539	Tank scale assembly
37	2400487	Bulkhead assembly, LP
38	2400489	QCC1 Hose and Regulator, 21", Summit
39	2401022	LHS S/B heat shield panel

40	2400977	Cabinet mat, black
41	2401009	Cabinet shelf, black
42	2401019	LHS Cabinet rear panel, black
43	2401020	LHS Cabinet bottom panel, black
44	2400278	Front frame, black, Summit '24+
45	2401007	RHS cabinet panel, black
46	2400978	Leg kit, adjustable, set of 2
47	2401017	LHS Frame cabinet, black
48	2400472	Door hinge kit, soft close, set of 1
49	2400473	LHS Door assembly, Black, Summit '24+
50	2400474	RHS Door assembly, Black, Summit '24+
51	70302	Hardware kit, Summit Lid
51	2400277	Door handle kit, Summit '24+, qty. 1
52	2401016	LHS Door Assembly, black Summit GC
53	2400277	Door handle kit, Summit '24+, qty. 1
54	2400453	Upper cooking grate, SS, Summit '24+
55	2400452	Cooking grates, 9mm SS, set of 3
56	64687	WEBER CRAFTED frame kit
56	64688	WEBER CRAFTED inset spacer
57	2400286	Smoker assembly, Summit '24+
58	2400288	Flavorizer bars, SS, Summit '24+, set of 5
59	66686	Heat deflector, Genesis/Summit (qty 4)
60	64560	Burner tube clamp set, Genesis 400 series (2022) (qty 5)
61	2400455	Crossover Tube, Summit '24+
62	2400454	Burner kit, LP, Summit '24+, set of 5
63	2400460	Igniter Kit, Summit, '24+
63	2400493	Igniter electrode, 46", green
63	2400491	Igniter electrode, 59", white
63	2400494	Igniter electrode, 36", black
63	2400492	Igniter electrode, 51", blue
63	2400495	Igniter electrode, 32", red
64	64561	Bottom tray rails, Genesis/Summit
65	64533	Grease tray, Genesis/Summit
66	6417	Aluminum drip pans - package of 10
67	2400469	Catch pan holder, Wire
68	70379	Catch pan kit
69	2400276	Top trim, rear, black
70	84116	Rotisserie hardware for tuckaway rotisserie, w/forks, '10
71	2400285	Rotisserie shaft, Summit '24+
?	2400275	Rear frame, black, Summit '24+

73	2400467	Grommet, snap-in, for tuck away bracket
74	2400468	Bracket assembly, tuck away rotisserie, Summit '24+
75	2400468	Bracket assembly, tuck away rotisserie, Summit '24+
76	65579	Rotisserie motor, Type B, '15
77	2400972	RHS Table w/Tuck Away Rotisserie, Summit 24+
78	2400971	Table Rail, Summit GC
79	2400274	Rear panel, LP, Black, Summit '24+
80	2401005	RHS Rear panel, cabinet, black
81	2401008	RHS cabinet shield for rotisserie bracket
82	2401006	Bottom panel, cabinet, black
83	2400450	Tank blocker bracket, black, LP
84	2400273	Tank enclosure, black, Summit '24+
85	2400271	Bottom panel, LP, black, Summit '24+
86	2401007	RHS cabinet panel, black
87	2401004	RHS inside Panel w/Cabinet, black
88	2400461	Battery holder assembly
89	2400901	Controller Cover, Summit '24+
90	69564	Cable kit, Genesis EX
91	69563	Genesis II EX/SX, controller board
92	64570	Power bank bracket
93	2400459	Igniter Module, Summit '24+
94	2401003	RHS Frame cabinet, black
95	2401002	RHS Door Assembly, black Summit GC
96	69257	Grease scraping tool
97	66534	Match holder assembly, Genesis LX, 440/640
98	2400277	Door handle kit, Summit '24+, qty. 1
470	69600	Hardware, tank glide buttons, Genesis II/'22 Genesis/Summit +'24
470	2400992	Hardware Kit, LP, black, FS/GC (bags A,B,C&D)
470	2401010	Hardware bag C, Summit '24+ FS/GS Side Table
470	2401297	Hardware Bag E, Side Cabinet, black
470	70302	Hardware kit, Summit Lid
470	2400996	Hardware bag A, LP, tank blocker/wire clips
470	2401011	Hardware bag D, FS/GC, cabinet hooks
470	2401298	Hardware Bag F, Soft Close Door hinges
470	2400471	Tool hooks, set of 3
470	2400999	Hardware bag B, ignition, Summit FS/GC
470	2401295	Hardware Bag E & F, black

# Join Our Community

Sign up to receive new product news, exclusive offers, grilling tips & recipes, and more from Weber and its affiliates / subsidiaries! To learn how we use your information, see our [privacy policy \(https://www.weber.com/US/en/privacypolicy.html\)](https://www.weber.com/US/en/privacypolicy.html).

Emē  
Add

[Sign up\(https://weber.com\)](https://weber.com)

\*For more details on how we use your information, see our [privacy policy](#).

---

Company

---

Customer Support

---

Replacement Parts

---

Explore

---