

Broil King 952-74 Owner's Manual

Shop genuine replacement parts for Broil King 952-74



Find Your Broil King Grill Parts - Select From 1350 Models

----- Manual continues below part list -----

Available Replacement Parts for Broil King 952-74

04200	electrode
90401	rock grate, 11.15625 x 21.8125; BK, BK,
94881	heat plate, ss, 11.75 x 23; BK,
11219	CI COOKING GRID - 50M BTU
68488	HEAVY DUTY PVC/PLYSTER COVER-BARON 500'S
<u>10711-K521</u>	SHELF LWR STL BLK
CG21SS	Cooking Grid Stainlss st Warm Morning G4

Broîl Kîng

REDDI-BILT BARBECUES

ASSEMBLY MANUAL & PARTS LIST

MANUAL DE MONTAGE & LISTE DE PIECES















RETAIN FOR FUTURE REFERENCE


VEUILLEZ CONSERVER POUR REFERENCE ULTERIEURE


MANUFACTURED BY / FABRIQUES PAR LA


ONVIC ONWARD MULTI-CORP INC. 585 KUMPF DRIVE, WATERLOO, CANADA N2V 1K3
































































PARTS LIST/LISTE DES PIECES

KEY#	ITEM#	DESCRIPTION	DESCRIPTION	947 74	040.44	050.04			
				<u>942-24</u> <u>942-27</u>	<u>942-44</u> 942-47	<u>952-24</u> <u>952-27</u>	<u>952-44</u> 952-47	952-74	<u>952-94</u>
				3.22.	- 12 - 11	<u> </u>	332-47	<u>952-77</u>	<u>952-97</u>
, 1.	10909-T32	CASTING BOTTOM	FOND DU FOYER	1	1	•	•	•	
	10909-T42	CASTING BOTTOM	FOND DU FOYER	•	•	1	1	1	1
2.	10473-T32	CASTING TOP	COUVERCLE DU GRIL	1	1	•	•		•
•	10473-T42	CASTING TOP	COUVERCLE DU GRIL	•	•	1	1	1	1
3.	10081-BK321	NAMEPLATE	PLAQUE DIDENTIFICATION	1	1	•	•	•	•
	10081-BK428	NAMEPLATE	PLAQUE D'IDENTIFICATION		•	1	. 1	•	
_	10081-BK429	NAMEPLATE	PLAQUE D'IDENTIFICATION	•	•	•	•	1	1
5.	10571-5	HEAT INDICATOR	INDICATEUR DE CHALEUR	1	1	1	1	1	1
7.	\$21233	HINGE CLIP	ATTACHE DE CHEVILLE	2	2	2	2	2	2
8.	10222-T32	GRATE	GRILL POUR BRIQUETTES	1	1	•	•	•	•
_	10222-T42	GRATE	GRILL POUR BRIQUETTES	•	•	1	1	1	1
9.	10225-T326	GRID - CAST IRON	GRILLE	2	2	•	•	•	•
	10225-T426	GRID - CAST IRON 1	GRILLE	•	•	2	2	2	2
11.	10225-T327	GRID RETRACTABLE	GRILLE RETRACTABLE	1	1	•	•		
	10225-T428	GRID RETRACTABLE	GRILLE RETRACTABLE	•	•	1	1	1	1
14.	10010-45	BRIQUETS - CERAMIC	BRIQUETTES - CERAMIQUE	1	1	•	•	•	
	10010-55	BRIQUETS - CERAMIC	BRIQUETTES - CERAMIQUE	•	•	1	1	1	1
15.	10390-T401	BURNER ASSY	ENSEMBLE DE BRULEUR	1	1	•		•	•
	10390-T501	BURNER ASSY	ENSEMBLE DE BRULEUR	•	•	1	1	1	1
17.	10342-21	IGNITOR	ALLUMEUR	1	•	1	•	1	•
	10342-22	IGNITOR	ALLUMEUR	•	1		1	•	1
18.	10342-T301	ELECTRODE	ELECTRODE	1	1	1	1	1	1
21.	10440-K40	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	1	•	•	•	•	·
	10440-K41	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	1		•		•	•
	10440-K42	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	1	•	•	•	
	10440-K43	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	1		•		
	10440-K50	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•		1	•		
	10440-K51	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•		1	•	•	-
	10440-K52	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	• 4	•	1		
,	10440-K53	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	• ;		1	•	
	10440-K58	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•		•	•	1
	10440-K59	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•		•	•	1
	10440-K62	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	•		1	
	10440-K63	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•	•		1	
21A.	S10125	HOSE - SIDE BURNER LP	TUYAU DU BRULEUR LATERAL PL	•	1	•	1	•	1.
	S10126	HOSE - SIDE BURNER NG	TUYAU DE BRULEUR LATERAL GN	•	1	•	1		1
218.	S10133	HOSE - REARBURNER LP	TUYAU DE BRULEUR ARRIERE PL	•	•	ŧ •	•	1	•
	S10139	HOSE - REARBURNER NG	TUYAU DE BRULEUR ARRIERE GN	•	•	•	•	1	
	S10134	HOSE - REARBURNER LP	TUYAU DE BRULEUR ARRIERE PL	•	•	•	•	•	1
	S10140	HOSE - REARBURNER NG	TUYAU DE BRULEUR ARRIERE GN	•		•			1
22.	10114-17	HOSE & REGULATOR LP - QCC1	TUYAU ET REGULATEUR PL - QCC1	1	1	1	1	1	1
	10111-K47	HOSE NATURAL GAS	TUYAU (GAZ NAUTREL)	1	1	1	1	1	1
23.	10472-K36	CONTROL KNOB	BOUTON DE CONTROLE	2	3	2	3	3	4
30,	1008 6 -K401	DECO PLATE	PLAQUE DECORATIVE	1	•	•	•	•	•
	10086-K411	DECO PLATE	PLAQUE DECORATIVE	•	1	•		•	
	10086-K501	DECO PLATE	PLAQUE DECORATIVE	•	•	1		•	
	10086-K511	DECO PLATE	PLAQUE DECORATIVE	•		•	1	•	
	10086-K521	DECO PLATE	PLAQUE DECORATIVE	•	•	•	•		1
	10086-K531	DECO PLATE	PLAQUE DECORATIVE	•	•	•	•	1	•
31	10194-K401	CONTROL COVER	PANNEAU DE CONTROLE	1	1	•	•		
22	10194-K501	CONTROL COVER	PANNEAU DE CONTROLE	•	•	1	1	1	1
33.	10338-K571	POST WHEEL	PIEDS DE ROUE	4	4	4	4	4	4
35.	10184-K561	SUPPORT - CASTING - LEFT	SUPPORT GAUCHE DU FOYER	1	1	1	1	1	1
36.	10184-K571	SUPPORT - CASTING - RIGHT	SUPPORT DROIT DU FOYER	1	1	1	1	1	1
37.	10184-K581	SUPPORT - SIDE SHELF - LEFT	SUPPORT TABLETTE DE GAUCHE	2	2	2	2	2	2
38.	10184-K591	SUPPORT - SIDE SHELF - RIGHT	SUPPORT TABLETTE DE DROITE	2	2	2	2	2	2
39.	10956-K401	BRACE - UPPER REAR	SUPPORT ARRIERE	1	1	•	•	•	•
	10956-K501	BRACE - UPPER REAR	SUPPORT ARRIERE	•	•	1	1	1	1
						-	•	•	•

PARTS LIST/LISTE DES PIECES

KEY#	ITEM#	DESCRIPTION	DESCRIPTION	<u>942-24</u> <u>942-27</u>	942-44 942-47	952-24 952-27	952-44 952-47	952-74 952-77	952-94 952-97
4 0.	10711-K401	SHELF - LOWER	TABLETTE INFERIEURE	1	1		•	_	_
•	10711-K501	SHELF - LOWER	TABLETTE INFERIEURE	•	·	1		•	•
46.	S17105	BRACKET - CYLINDER LP	SUPPORT DU RESERVOIR PL	1	1		1	1	1
49.	10711-K441	CONDI-BIN	CONDI-BIN	1	1	1	1 -	1	1
	10711-K541	CONDI-BIN	CONDIBIN	•		•	•	•	•
50.	10711-K551	SHELF - SIDE	PLANCHETTE LATERALE	2		1	1	1	1
53,	S16142-2	SHELF BOARD - FRONT	PLANCHETTE AVANT		1	2	. 1	2	1
	S16144-2	SHELF BOARD - FRONT	PLANCHETTE AVANT	1	1	•	•	•	•
54.	10088-14	FRONT PANEL	PANNEAU AVANT	1	1	1	1	1	1
	10088-15	FRONT PANEL	PANNEAU AVANT			-	•	•	•
55,	10184-K631	FRONT PANEL BRACKET	SUPPORT POUR PANNEAU AVANT	2	2	1	1	1	1 -
56,	10892-18	WHEEL	ROUE	2	2	2	2	2	2
57.	10156-K40	SHIELD	ECRAN	1		2	2	2	2
	10156-K55	SHIELD L			1		•	•	•
65.	S13003	BURNER ROTISSERIE	BRULEUR A ROTISS	•		1	1	1	1
6 6.	10339-K901	BRACKET ORIFICE	SUPPORT D'ORIFICE	-			•	1	1
6 8.	S21361	SPRING	RESSORT	•	•	-	•	1	1
69.	S21381	SCREW - 12 X 1/2	VIS - 12 X 1/2				•	1	1
74.	Y-6616	BOLT	BOULON	2	•		•	2	2
75 .	10338-145	HANDLE	POIGNEE	2	2	2	2	2	2
76.	10239-6	WASHER - HANDLE	RONDELLE DE LA POIGNEE	2	2	2	2	2	2
7 7.	S15111	GREASE CUP HOLDER	PORTE CONTENANT A GRAISSE	. 1		2	2	2	2
78.	10892-12	CASTOR	ROULETTES	2	1 2	1	1	1	1
80.	Y-11549	BOLT - 1/4:20 X 1-7/8	BOULON - 1/4:20 X 1-7/8	20	20	2 20	2	2	2
82.	Y12860	SCREW -1/4:20 X 1*	VIS -1/4:20 X 1*	4	4	4	20	20	20
83.	S21141	BOLT - 1/4:20 X 5/8	BOULON - 1/4:20 X 5/8	1	1	1	4	4	4
85.	S21255	WASHER	RONDELLE	1	1		1	1	1
8 6.	Y-12656	, PLUG - BUTTON	BOUCHON	2	2	. 2	1 2	1	1
87.	Y-11793	NUT - 1/4	ECROU - 1/4	10	10 ,			2	2
3.	Y-11598	NUT WING - 1/4	ECROU PAPILLON - 1/4	19	19	10	10	10	10
69 .	Y-11212	NUT TINNERMAN - 1/4	ECROU TINNERMAN - 1/4	6	6	, 19 6	19 6	19	19
91.	Y-11967	BOLT - 3/8:16 X 1-3/4	BOULON - 3/8:16 X 1-3/4	2	2	2	2	6	6
94.	Y-12287	NUT - 3/8	ECROU - 3/8	2	2	2	2	2	2
96.	Y-29305	BOLT 10:24 X 3/8	BOULON 10:24 X 3/8	4	8	4	8	6	2
97.	10240-13	WHEEL BOLT	ROUE BOULON	2	2	2	2	•	8
98.	S21123	SCREW - 8 X 1/2	VIS - 8 X 1/2	20	17	20	17	20	
99.	Y-12646	SCREW - SHOULDER	VIS	4	4	į,	4	4	17
101,	Y-12853	WASHER - #8	RONDELLE - #8	4	8	·4	8	4	4 8
104	Y- 12835	SCREW 6-32 X 1/4	VIS 6-32 X 1/4	. 8	9	8	9	8	9
105.	Y-29307	NUT - 10:24	ECROU - 10:24	•	13	•	13	-	
108,	PB20-60	LID HANDLE	POIGNEE	•	1	•	1	-	13 1
110.	10225-T10	GRID	GRILLE	•	1	•	1	-	1
111.	10390-T10	SIDE BURNER	BRULEUR DE COTE	•	1	•	1		1
113.	10342-T08	ELECTRODE - SIDE BURNER	ELECTRODE - BRULEUR DE COTE	•	1	•	1	•	1
114,	10393-K40	COVER - SIDE BURNER	COUVERCLE LATÉRAL	•	1	•	1	•	;
1 15.	Y-29305	SCREW 10:24 X 3/8	VIS 10:24 X 3/8	•	4		4	•	4
117.	10393-K50	SHELF - SIDE BURNER	SUPPORT DE BRULEUR DE COTE	•	1		1	•	1
118.	10393-T221	SHIELD - SIDE BURNER	ECRAN DE CUVETTÉ LATÉRAL	•	1	•	1	•	1

