

This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://www.appliancefactoryparts.com).



LASKO 1128 Owner's Manual

[Shop genuine replacement parts for LASKO 1128](#)



[Find Your LASKO Humidifier Parts - Select From 20 Models](#)

----- Manual continues below -----

TROUBLE SHOOTING GUIDE

TROUBLE	PROBABLE CAUSE	SOLUTION
Fan not working or Humidifier doesn't turn on	<ul style="list-style-type: none"> No power Humidistat not set correctly 	Make sure Unit is plugged in Check that the Power Switch is on Set Humidistat to higher humidity level
Water leaking	<ul style="list-style-type: none"> Base is overfilled Filter is old and dirty 	Reduce water level in Base Replace Filter
Foul odor	<ul style="list-style-type: none"> Filter needs to be replaced Base needs to be cleaned Whole Humidifier needs cleaning 	Replace Filter Follow <i>Cleaning Instructions</i> Follow <i>Cleaning Instructions</i>
Filter discoloration	<ul style="list-style-type: none"> Mineral deposits in water 	Replace Filter
Water discoloration	<ul style="list-style-type: none"> Humidifier needs to be cleaned Hard water - Iron in water Some humidifier additives can cause discoloration 	Follow <i>Cleaning Instructions</i> Use filtered or distilled water
Lights don't work: Humidistat Light Off, Power Light On Power Light Off, Humidistat Light On	<ul style="list-style-type: none"> Humidity is not yet achieved in room Room has reached desired Humidity level 	Let Humidifier continue to run Set Humidity Knob for more Humidity
No water show	<ul style="list-style-type: none"> Hose not connected to Pump Hose not connected to Water Show No Water in Unit 	Connect Hose to Pump Connect Hose to Water Show Refill Unit

LIMITED WARRANTY

SHOULD ACCESSORY PARTS BE NEEDED, CONTACT THE MANUFACTURER FOR IN-WARRANTY REPLACEMENT PARTS. A COPY OF PROOF-OF-PURCHASE MUST BE INCLUDED ALONG WITH THE TYPE AND STYLE, WHICH IS LOCATED ON THE BOTTOM OF YOUR APPLIANCE.

This product is warranted for one year from the date of original purchase against defects in workmanship and/or materials. At our option, parts that prove to be defective will either be repaired or replaced or the whole product will be replaced.

Should electrical or mechanical repair become necessary during the warranty period, send your complete product, postage or freight prepaid to the nearest service center. Call the number below for the service station nearest you.

Should a part need replacement, you must give us the type and style of your appliance. You will find this at the bottom of the appliance. In either case, a copy of your proof of purchase is requested.

This warranty does not apply if the damage occurs because of accident, improper handling or operation, shipping damage, abuse, misuse, unauthorized repairs made or attempted, or the use of the product for commercial service.

ALL WARRANTIES, EXPRESSED OR IMPLIED, LAST FOR ONE YEAR FROM THE DATE OF ORIGINAL PURCHASE. THIS WARRANTY DOES NOT COVER LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR ANY CAUSE WHATSOEVER.

Some states do not allow limitations on how long any implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so that the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

FOR PARTS:

For Replacement Parts or Filters please call: **1-800-966-2028, MONDAY - FRIDAY, BETWEEN the HOURS of 8 AM and 4 PM EST. "PLEASE DO NOT RETURN PRODUCT TO PLACE OF PURCHASE."** Reference model number **1128** when you call.

FOR TECHNICAL ASSISTANCE and SERVICE CENTER LOCATIONS:

For any questions, comments or the location of your nearest service center, **PLEASE CALL OUR TOLL-FREE "HOTLINE" AT 1-800-233-0268, MONDAY - FRIDAY, BETWEEN the HOURS of 8 AM and 5 PM EST.** Please reference model number **1128** when you call.

Appliance Service Dept. • 300 Confederate Drive
Franklin, TN 37065-0569

PLEASE DO NOT SEND PRODUCT TO THIS LOCATION!


FILLING and OPERATION

CAUTION: Do not pour water through the Exhaust Grill on the Upper Housing. Doing so may cause damage and personal injury.



- CAUTION:**
- **Unplug Unit when filling.**
 - Always place Humidifier on a firm level surface. Locate the Power Cord so the Humidifier is not resting on it, and is away from traffic.
 - Be careful not to overfill.
 - **Do not pour water through Exhaust Grill,** doing so may cause damage and personal injury.
 - Take extra care to prevent water spillage that may damage furniture or flooring. The manufacturer will not accept responsibility for damage to property caused by water spillage.
 - Always be sure the Power Knob is in the **OFF** position when plugging Humidifier into a grounded 120 volt AC wall outlet.
 - To prevent risk of electrical shock and injury to persons, do not plug Humidifier into electrical outlet with wet hands.

1. It is recommended that all Humidifiers be cleaned prior to use. Please read **Cleaning Instructions** for Base and Jug cleaning.
2. Use the convenient Carrying Handle found on the bottom of the Water Jug to bring it to a faucet. The Water Jug features a 'Quick Fill/Quick Empty' Spout. To fill, hold Jug upside down by the Handle. Use thumb to press down Stopper Lever, and fill Jug. Fill the Water Jug with cool tap water. **Never use hot water.** (Figure 3)



When the Jug is replaced back into the Base it will quickly empty to fill Base.

NOTE: While carrying filled Water Jug back to the Humidifier, hold the Handle with one hand, while supporting bottom of Water Jug with other hand.


3. Place the Water Jug securely in the Base. If positioned properly, water will quickly pour into Base and automatically stop when reaching desired amount.
4. When gurgling noise stops lift up the Water Jug to see if it is empty. Refill if empty. When the Unit is full some water will remain in the Jug.
5. Even though your Humidifier will produce approximately 9.0 gallons in a 24 hour period*, the water capacity (amount of water the Humidifier will hold at one time) is 4.5 gallons. (3 FULL Jugs).

6. Turn Power **ON** to desired speed. (Figure 4)


- 3 - For fast humidification of a large room or house, approximately 9 gallon per day.*
- 2 - For normal operation.
- 1 - For quiet, night time operation or after desired moisture level is reached.

* Calculations based on ambient room conditions of 70° F and 30% relative humidity in a room of average insulation.


NOTE: Power Light and Fan are on only when the Humidistat is turned to a high enough moisture setting.



The presence of water flow in the Water Show Window indicates the circulation of water to the Filter. (Figure 5)



7. To set Humidistat to desired level turn Knob towards HIGH until the power is ON. After the room has reached a comfortable humidity level, turn the Humidistat Knob slowly towards LOW until the fan shuts off and the Green Light turns on, the Humidifier will automatically restart when humidity falls below this setting. (Figure 6)



NOTE: The Humidifier will only turn on when the Humidistat is set to a high enough setting or when the room humidity is low enough.